

Instructions for Use

Fabius GS *premium*

WARNING!

For a full understanding of the performance characteristics of this medical device, the user should carefully read these Instructions for Use before use of the medical device.

**Anesthesia Workstation
Software 3.n**

Working with these Instructions for Use

Header Line

The header line on each page contains the title of the chapter.

Page Body

The page body in these Instructions for Use combines text and illustrations. The information is presented as sequential steps of action, giving the user hands-on experience in learning how to use the Fabius GS *premium* machine.

Left-Hand Column – the Text

The text in the left-hand column provides explanations and step-by-step instructions on the practical use of the machine.

- Bullet points indicate separate actions.
- 1 Where several actions are described, numbers are used to refer to relevant details in the illustrations. On each page the numbering restart with “1”.
- Dashes indicate the listing of data, options or objects.

Right-Hand Column – the Illustrations

The illustrations provide visual reference for the text and for locating the various parts of the equipment. Elements mentioned in the text are highlighted. Renderings of screen displays guide the user and provide a way to reconfirm actions performed.

Typing Conventions in this Manual

- User controls, such as hard keys and soft keys, and screen pages are printed in bold within quotation marks, e.g., »PEEP« or »Volume Settings«.
- Screen messages are printed in bold within quotation marks, e.g., »Flow Calibration in progress«.
- Alarm messages are printed in bold within quotation marks, including the exclamation marks that indicate their alarm urgency level, e.g., »APNEA PRESSURE!!!«.

Configuration

Configuration Functions in Standby Mode

The configuration functions available in Standby include calibrations, system tests, and the management of default settings.

To access Standby mode:
1 Press the »Standby« key.

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

104

Instructions for Use Fabius GS premium SW 3.n

2

Instructions for Use Fabius GS *premium* SW 3.n

Trademarks

DrägerService[®], Spirolog[®], SpiroLife[®], Drägersorb[®], D-Vapor[®], Fabius[®] GS *premium*, Vapor[®], and Vitalink[®] are registered trademarks of Dräger.

Selectatec[®] is a registered trademark of Datex-Ohmeda.

All other products or brand names are trademarks of their respective owners.

Definitions

WARNING

A WARNING statement provides important information about a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

A CAUTION statement provides important information about a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to the user or patient or in damage to the equipment or other property.

NOTE

A NOTE provides additional information intended to avoid inconvenience during operation.

Abbreviations and Symbols

Please refer to "Abbreviations" on page 28 and "Symbols" on page 29 for explanations.

Notice

This document is provided for customer information only, and will not be updated or exchanged without customer request.

Depending on the configuration of the individual medical device, the images in the Instructions for Use may differ.

Definition of the Target Group

The following group of users is defined with respect to the use of the medical device:

Professionals

These users are persons

- who have been instructed on the medical device, and
- who are medical professionals, or have received technical training, and
- who are authorized to use and reprocess or to instal and maintain the medical device in accordance with the intended use.

Dräger recommends that the medical device is used exclusively by professionals.

This page intentionally left blank

Contents

Working with these Instructions for Use	2	Connecting the Waste-Gas Outlet Port	48
Trademarks	3	Installing the Flexible Bag Arm or Breathing Bag Extension* and Bag	48
Definitions	3	Connecting Pipeline Supply of N ₂ O, AIR and O ₂	49
Abbreviations and Symbols	3	Connecting the Reserve Gas Cylinders (for Pin-Index Mounting)	50
Notice	3	Connecting the Reserve Gas Cylinders (for Cylinders with Threaded Connectors)	53
Definition of the Target Group	3	Connecting the AGS Anesthetic Gas Receiving System	54
For Your Safety and that of Your Patients	7	Connecting the Passive Scavenger	56
Intended Use	13	Connecting the Suction System	57
Intended Use	14	Connecting the Breathing Hoses	58
System Overview	15	Inserting a new O ₂ Sensor Capsule	60
Front View	16	Connecting the O ₂ Sensor	60
Compact Breathing System (Top View)	17	Connecting the Pressure Sensor	61
Rear View (Pin-Index Connector)	18	Connecting the Pressure Breathing Gauge	61
Interface Panel	19	Connecting the Flow Sensor	62
Vaporizers (Optional)	20	Connecting the APL Bypass and PEEP/PMAX Hoses	62
Vaporizer Exclusion Systems	20	Installing the COSY Shielding	63
Auxiliary Oxygen Flowmeter	23	Attaching the Manual Ventilation Bag	63
APL Valve	24	Preparing the Ventilator	64
Communication Ports	25	Ventilator Safety Features	64
Accessory Weight Limits	27	Installing Vaporizers	65
Abbreviations	28	Additional Equipment	65
Symbols	29	Equipotential Bonding	66
Operation Concept	31	Connecting AC Power	66
Control Panel	32	Auxiliary power outlets	67
The Screen Display	33	Daily and Pre-use Checkout	67
Rotary Knob	34	Getting Started	69
Fixed Function Keys	34	Powering-Up the Machine	70
Soft Keys	35	Power-Up Standby Screen	71
Fresh-Gas Control	39	Checking Readiness for Operation	71
LED Indicators	42	Operation	73
Gas System Color Coding	42	Power-Up Standby Screen	74
Screen Color Concept	42	Setting Fresh-Gas Flow	74
Assembly	43	Setting Vaporizer Concentration	76
Activating the Battery	44	O ₂ Flush	77
Fitting the CO ₂ Absorber on the Compact Breathing System	44	Low Flow Anesthesia	78
Installing the Drägerisorb CLIC Adapter	45	Nitrogen Wash-Out (If Required)	78
Connecting the Compact Breathing System	46	Replacing CO ₂ Absorbent	78
Inserting the Flow Sensor	47		

Ventilation	81	Disposal	183
Ventilator Safety Features	97	Disposal of the Medical Device	184
Changing Patients	98	Technical Data	185
Ending Operation	99	Ambient Conditions	186
Preparing for Storage or Transport.	100	Machine Data	186
Monitoring	103	Electromagnetic Compatibility (EMC)	189
Main Screen	104	Electrical Safety Conformance	194
Alarms	104	General Safety Standards for Anesthesia	194
Oxygen Monitoring	108	Freedom from Latex	194
O ₂ Low Supply Alarm	112	Ventilator	194
Respiratory Volume Monitoring	113	Anesthesia Gas Supply Module	197
Breathing Pressure Monitoring	115	Anesthetic Agent Vaporizer Interface	198
Configuration	117	Breathing System	200
Configuration Functions in Standby Mode	118	Low Oxygen Supply Pressure Alarm.	202
Configuration during Operation	138	S-ORC (Sensitive Oxygen Ratio Controller)	202
Fault-Cause-Remedy	145	Serial Interface	203
Power Failure Backup	146	Diagram	204
Ventilator Fail State	148	Appendix – Daily and Pre-use Checkout	
Overriding the Ventilator	148	Form	205
Fault-Cause-Remedy	150	Index	213
Cleaning	157		
Safety information on reprocessing	158		
Pre-cleaning	158		
Reprocessing methods.	158		
Removing the Compact Breathing System.	161		
Removing Parts of the Ventilator	163		
Removing anesthetic gas scavenging system (AGSS).	164		
Removing the Suction System	164		
Reprocessing Breathing system	164		
Care List for Fabius GS <i>premium</i>			
Components	166		
Reassembling the Breathing System	168		
Reinstalling the Ventilator	170		
Reinstalling the Scavenger System	171		
Reinstalling the Suction System	173		
Checking Readiness for Operation	174		
Maintenance	175		
Overview	176		
Routine Maintenance	179		
Checking Readiness for Operation	181		

For Your Safety and that of Your Patients

Strictly follow these Instructions for Use	8
Maintenance	8
Accessories	8
Not for use in areas of explosion hazard	8
Safe connection with other electrical equipment	8
Safe networking of computers	8
Patient safety	9
Patient monitoring	9
General WARNINGS and CAUTIONS	10
Note on EMC/ESD risk for the device function	10
Accessories in sterile packaging	10
Software	11

Strictly follow these Instructions for Use

WARNING

Strictly follow these Instructions for Use. Any use of the medical device requires full understanding and strict observation of all portions of these instructions. The medical device is only to be used for the purpose specified under "Intended Use" on page 14 and in conjunction with appropriate patient monitoring (see page 9). Strictly observe all WARNING and CAUTION statements throughout these Instructions for Use and all statements on medical device labels.

Maintenance

WARNING

The medical device must be inspected and serviced regularly by trained service personnel. Repair of the medical device may also only be carried out by trained service personnel. Dräger recommends that a service contract be obtained with DrägerService and that all repairs also be carried out by them. Dräger recommends that only authentic Dräger repair parts be used for maintenance. Otherwise the correct functioning of the medical device may be compromised. See chapter "Maintenance".

Accessories

WARNING

Only the accessories indicated on the list of accessories 9052228 (1. edition or higher) have been tested and approved to be used with the medical device. Accordingly it is strongly recommended that only these accessories be used in conjunction with the specific medical device. Otherwise the correct functioning of the medical device may be compromised.

Not for use in areas of explosion hazard

WARNING

This medical device is neither approved nor certified for use in areas where combustible or explosive gas mixtures are likely to occur.

Safe connection with other electrical equipment

WARNING

Electrical connections to equipment which is not listed in these Instructions for Use should only be made following consultation with the respective manufacturers.

Safe networking of computers

When networking with electrical devices, the operator is responsible for ensuring that the resulting system meets the requirements set forth by the following standards:

- EN 60601-1 (IEC 60601-1)
Medical electrical equipment
Part 1: General requirements for safety
- EN 60601-1-1 (IEC 60601-1-1)
Medical electrical equipment
Part 1-1: General requirements for safety
Collateral standard: Safety requirements for medical electrical systems
- EN 60601-1-2 (IEC 60601-1-2)
Medical electrical equipment
Part 1-2: General requirements for safety
Collateral standard: Electromagnetic compatibility; Requirements and tests
- EN 60601-1-4 (IEC 60601-1-4)
Medical electrical equipment
Part 1-4: General requirements for safety
Collateral standard: Programmable electrical medical systems

Follow Assembly Instructions and Instructions for Use.

Patient safety

The design of the medical device, the accompanying literature, and the labeling on the medical device take into consideration that the purchase and use of the medical device are restricted to trained professionals, and that certain inherent characteristics of the medical device are known to the trained operator. Instructions, warnings, and caution statements are limited, therefore, largely to the specifics of the Dräger design.

This publication excludes references to various hazards which are obvious to a medical professional and operator of this medical device, to the consequences of medical device misuse, and to potentially adverse effects in patients with abnormal conditions. Medical device modification or misuse can be dangerous.

Patient monitoring

The operators of the medical device must recognize their responsibility for choosing appropriate safety monitoring that supplies adequate information on medical device performance and patient condition.

Patient safety may be achieved through a wide variety of different means ranging from electronic surveillance of medical device performance and patient condition to simple, direct observation of clinical signs.

The responsibility for the selection of the best level of patient monitoring lies solely with the medical device operator.

General WARNINGS and CAUTIONS

The following WARNINGS and CAUTIONS apply to general operation of the device. WARNINGS and CAUTIONS specific to subsystems or particular features appear with those topics in later sections of these Instructions for Use or in the device-specific Instructions for Use.

Note on EMC/ESD risk for the device function


General information on electromagnetic compatibility (EMC) pursuant to international EMC standard IEC 60601-1-2: 2001

Electromedical devices are subject to special precautionary measures concerning electromagnetic compatibility (EMC) and must be installed and put into operation in accordance with the EMC information included, see page 189.

Portable and mobile RF communications equipment can affect medical electrical equipment.

WARNING

Risk of electric shock



Connecting devices to the Medical Power Outlet Strip can cause an increase in leakage current beyond permissible values if the protective conduc-

tor of a device fails. Check the leakage current when connecting devices to the Medical Power Outlet Strip. If connecting a device (or devices) increases the leakage current to a value which exceeds the permissible value, do not use the auxiliary outlets of the Fabius GS premium: use a separate wall socket.

The system must meet the requirements for medical equipment in accordance with IEC/EN 60601-1-1 and IEC/EN 60601-1-2 and the particular standards of the connected devices.

WARNING



Connector pins with an ESD warning sign should not be touched and no connections should be made between these connectors without implementing ESD protective measures. Such precautionary procedures may include antistatic clothing and shoes, the touch of a ground stud before and during connecting the pins or the use of electrically isolating and antistatic gloves. All staff involved in the above shall receive instruction in these ESD precautionary procedures.

Accessories in sterile packaging

Do not use accessories in sterile packaging if the packaging has been opened, damaged or if there are other signs that the accessories are not sterile. Reprocessing and resterilization of single-use accessories is not permitted.

CAUTION

Risk of patient injury

An incorrect diagnosis or misinterpretation of measured values, or other parameters, may endanger the patient.

Do not base therapy decision on individual measured values or monitoring parameters.

Software

The device's software has been developed and tested carefully in accordance with Dräger's high quality standards. It is therefore highly improbable that software errors can become a hazard to the patient.

Additionally, independent protective functions are extensively implemented in the software, as well as in electronics and mechanics, for all safety-related functions of the device.

Through this, the probability that an error in the software or other functions can be detected before it affects the patient's safety is very high. Regular automated or manual tests ensure the effectiveness of all protective measures.

WARNING

Do not use conductive breathing hoses or face masks.

They may cause burns during HF surgery.

WARNING

Any person involved with the setup, operation, or maintenance of the Fabius GS *premium* anesthesia workstation must be thoroughly familiar with this instruction manual.

WARNING

This anesthesia workstation will not respond automatically to certain changes in patient condition, operator error, or failure of components. The anesthesia workstation has to be operated under the constant supervision and control of a qualified operator in order to provide immediate corrective action.

WARNING

No third-party components shall be attached to the anesthesia workstation, ventilator, or breathing system (except for certain approved components), otherwise the correct functioning of the medical device may be compromised. For more information, contact DrägerService or your local authorized service organization.

WARNING

Each institution and user has a duty to independently assess, based on its, his, or her unique circumstances, what components to include in an anesthesia workstation. However, Dräger, in the interest of patient safety, strongly recommends the use of an oxygen analyzer, pressure monitor, volume monitor, and end-tidal CO₂ monitor in the breathing circuit at all times.

WARNING

Risk of unintentional movement of the anesthesia workstation

Apply the caster brakes when the anesthesia workstation is in use.

WARNING

Remove any equipment mounted to the machine before transport. The writing table should also be free of all objects and pushed back in the locked position.

If these precautions are not followed, the device may tip over and pose a risk to safety.

WARNING

Risk of fire

Drugs or other substances based on inflammable solvents, such as alcohol, must not be introduced into the patient system.

Adequate ventilation must be ensured if highly inflammable substances are used for disinfection.

WARNING

Explosive anesthetics, such as ether or cyclopropane, must not be used due to the risk of fire.

WARNING

Always keep a breathing bag at hand. If ventilation of the patient is compromised, the patient must be immediately ventilated with a separate emergency ventilator.

WARNING

Do not apply unregulated suction to the patient circuit when using this device.

WARNING

To avoid electrical shock hazard: Due to the risk of electrical shock, do not remove any component cover. Refer any servicing to DrägerService. Use only hospital-grade grounded electric outlets and power cord. This device is to be used only in rooms with line power installations complying with national safety standards for hospital patient rooms (e.g. IEC 60601-1 "Safety of Medical Electrical Equipment"). Make sure the external equipment is hospital-grade grounded (regarding national regulations) before connecting the equipment. Disconnect the power supply from the electrical outlet before cleaning or servicing. Let it dry completely before reconnecting it to the electrical outlet. Always ensure that the clamp for the power cord at the power supply end is tight, thus preventing an accidental disconnect from the unit. Do not connect additional external equipment other than equipment specified by Dräger.

CAUTION

Communications with external equipment may be temporarily affected by electromagnetic interference due to the use of electrosurgical equipment.

CAUTION

Do not use Fabius GS *premium* during magnetic resonance (MRT, NMR, NMI).
Device operation may be affected, thus placing the patient at risk.

CAUTION

Risk of physical injury

To avoid physical injury, pay special attention to edges, moving parts and corners when working with:

- drawers,
 - the ventilator module,
 - the writing tray,
 - swivel arms for mounted devices,
 - gas cylinders,
 - vaporizer units,
 - CLIC absorbers and CLIC adapters,
- as well as other accessories.

CAUTION

Risk of pinching fingers or breathing hoses and objects falling down

If the writing table is not engaged correctly, objects can fall down and fingers or breathing hoses can be pinched.

CAUTION

Risk of device failure

If the anesthesia workstation is operated when tilted, components may be damaged or may function improperly.

Do not operate the anesthesia workstation if it is tilted more than 5°.

NOTE

Software must be installed by qualified personnel. We recommend to contact DrägerService for software installation.

NOTE

If the error-free state of the protective earthing conductor or its connection to the medical device is doubtful, the device must be operated using the internal power supply (battery).

Intended Use

Intended Use	14
MEDIBUS and Vitalink Protocols	14
Restriction of Distribution	14

Intended Use

Fabius GS *premium* is an inhalation anesthesia machine for use in operating, induction and recovery rooms.

It may be used with O₂, N₂O, and AIR supplied by a medical gas pipeline system or by externally mounted gas cylinders.

Fabius GS *premium* is equipped with a compact breathing system, providing fresh-gas decoupling, PEEP, and pressure limitation.

The following ventilation options are available:

- Volume Controlled Ventilation
- Pressure Controlled Ventilation (optional)
- Pressure Support (optional)
- SIMV/PS (optional)
- Manual Ventilation
- Spontaneous Breathing

Fabius GS *premium* is equipped with an electrically driven and electronically controlled ventilator and monitors for airway pressure (P), volume (V), and inspiratory oxygen concentration (FiO₂).

As per IEC 60601-2-13 (Anesthetic Workstations and their Modules-Particular Requirements), additional monitoring of the concentrations of CO₂ and anesthetic agent is required when the machine is in use.

IEC 60601-2-13: 2003 requires that a manual ventilation bag must be available for emergency use. Fresh-gas enrichment is provided by the Dräger Vapor anesthetic vaporizer.

MEDIBUS and Vitalink Protocols

MEDIBUS and Vitalink are software protocols for use in transferring data between the Fabius GS *premium* and an external medical or non-medical device (e.g., hemodynamic monitors, data management systems, or a Windows-based computer) via the RS-232 interface (see 9038530, 3rd edition or higher).

WARNING

Data transferred via MEDIBUS and Vitalink interfaces are for information only and are not intended as a basis for diagnosis or therapy decisions.

WARNING

In order to protect patients and users from electrical hazards, is it imperative that all systems consisting of electrical medical devices and other electrical devices, such as but not limited to PCs, printers, etc., be mounted exclusively by trained personnel.

The system must meet the requirements about medical electrical equipment in accordance to IEC/EN 60601-1-1 and IEC/EN 60601-1-2.

Restriction of Distribution


CAUTION

Device for use in health care facilities only and exclusively by persons with specific training and experience in its use.

System Overview

Front View	16
Compact Breathing System (Top View)	17
Rear View (Pin-Index Connector)	18
Interface Panel	19
Vaporizers (Optional)	20
Vaporizer Exclusion Systems	20
Dräger Vapor Interlock 2 System (Optional) ..	20
Selectatec (Optional)	21
Dräger Auto Exclusion 2 Vaporizer Mount (Optional)	21
Dräger Auto Exclusion 3-Vaporizer Mount (Optional)	22
Auxiliary Oxygen Flowmeter	23
APL Valve	24
Communication Ports	25
Recommended Device Configuration	25
Accessory Weight Limits	27
Abbreviations	28
Symbols	29


Front View



- | | |
|--|------------------------------------|
| 1 Ventilator control panel (settings for ventilation parameters and airway monitoring) | 9 Storage drawers |
| 2 Total fresh-gas flow meter | 10 Central brake |
| 3 Display screen | 11 Absorber |
| 4 Interlock Vapor mount | 12 Oxygen Flush |
| 5 Lamp* | 13 Compact Breathing System (COSY) |
| 6 Fresh-gas control | 14 Ventilator |
| 7 Gauges for Pin index O ₂ , AIR and N ₂ O cylinders* | 15 Auxiliary oxygen flowmeter* |
| 8 Writing table* | |

* optional

Compact Breathing System (Top View)




- 1 PEEP/P_{MAX} valve connection port
- 2 Bag holder
- 3 Expiratory valve
- 4 Flow-sensor guard (flow-sensor protection) or COSY shielding (not pictured)
- 5 Expiratory port
- 6 Connector for breathing bag
- 7 Inspiratory port
- 8 Inspiratory valve
- 9 Fresh-gas decoupling valve
- 10 APL bypass valve connection port
- 11 Breathing system mount with locking bolt
- 12 Selecting knob for »MAN« and »SPONT« on pressure limiting (APL) valve
- 13 Sample gas return port

NOTE


Graphic depicted without COSY shielding.

Rear View (Pin-Index Connector)



- 1 Sealed connector
- 2 Connector for medical gas pipeline supply (central supply)
- 3 Power cable connection
- 4 Interface panel
- 5 Ventilator hose connection
- 6 ON/OFF switch
- 7 Fuse
- 8 Compact Breathing System (COSY)
- 9 Potential equalization pin
- 10 Pin-Index system

Interface Panel



- 1 COM 1
- 2 COM 2*
- 3 APL
- 4 Oxygen Sensor
- 5 Pressure Breathing
- 6 Volume Sensor
- 7 ON/OFF switch
- 8 Fuse
- 9 Power cable connection
- 10 PEEP

* optional

Vaporizers (Optional)

The Dräger Vapor anesthetic agent vaporizers are used to enrich the fresh gas with a precisely metered quantity of vapor from the liquid anesthetic agent being used, i.e., Isoflurane, Halothane, Enflurane, Sevoflurane, or Desflurane.

When using a Desflurane vaporizer, it must be connected to mains power.

For complete information, consult the appropriate Instruction for Use provided with the vaporizer.


Vaporizer Exclusion Systems

The exclusion systems available for the Fabius GS *premium* are described below.


Dräger Vapor Interlock 2 System (Optional)

The Dräger Interlock 2 system is used to ensure that only one of two vaporizers can be used at a time. It has a selector lever used to select which vaporizer is enabled.

Moving the selector lever away from the desired vaporizer allows that vaporizer to be used and the other to be locked out of use.



Note that the selector lever is shown in the center position. This ensures that both vaporizers are in the locked position. Also, this is the recommended position for the selector lever when moving the Fabius GS *premium*.



Selectatec (Optional)

The interlock system for the Selectatec is built into the vaporizers. When a vaporizer is selected for use, the interlocking index pins will protrude from the sides of the vaporizer thereby not allowing the adjacent vaporizer to be opened. For more specific information on the Selectatec, refer to the Selectatec Vaporizer's instruction manual.

Dräger Auto Exclusion 2 Vaporizer Mount (Optional)

This system has an automatic interlock system that ensures only one vaporizer can be used at a time. When one of the two vaporizers is selected for use (opened), the interlock mechanism within that vaporizer's mounting system is activated automatically, preventing the other vaporizer from being used.

NOTE

Only Dräger vaporizers labeled as "AUTO EXCLUSION" vaporizers are compatible with the Dräger Auto Exclusion 2-Vaporizer Mount. See table for the Auto Exclusion Vaporizer technical data.

Normal Operating Range	≤ 10 L/min	Dräger Vapor 2000 Instruction for Use Manual's delivered concentration accuracy values apply.
Extended Operating Range	>10 to ≤ 15 L/min	Dräger auto exclusion vaporizer concentration output accuracy may be reduced.

When using a Desflurane vaporizer, it must be connected to mains power.

Dräger Auto Exclusion 3-Vaporizer Mount (Optional)

This system has an automatic interlock system that ensures only one vaporizer can be used at a time. When any one of the three vaporizers is selected for use (opened), the interlock mechanism within that vaporizer's mounting system is activated automatically, preventing the other two vaporizers from being used.


NOTE

Only Dräger vaporizers labeled as "AUTO EXCLUSION" vaporizers are compatible with the Dräger Auto Exclusion 3-Vaporizer Mount. See table on page 21 for the Auto Exclusion Vaporizer technical data.

When using a Desflurane vaporizer, it must be connected to mains power.

NOTE

The Desflurane vaporizer must be installed in the far right position with the Dräger Auto Exclusion 3-Vaporizer Mount. Do not install the Desflurane vaporizer in the other two mounting positions.



Auxiliary Oxygen Flowmeter*

The auxiliary oxygen flowmeter delivers a metered flow of pure oxygen, used, for example in the delivery of oxygen through a nasal cannula. Auxiliary oxygen can be used in any ventilation mode, in standby, or even if the machine is switched off.

The auxiliary oxygen flowmeter may be used to provide supplemental inspired oxygen to a patient under spinal, epidural, or other regional anesthesia. It may also be used to enrich the inspired gas mixture provided by a manually powered self-inflating resuscitator bag**.

- Test the auxiliary oxygen flowmeter. Adjust the flow knob (1) and make sure the float moves freely over the full range of the flowmeter.

WARNING

Risk of patient injury

Do not connect the patient directly to the auxiliary oxygen outlet.

High pressure will be applied and the patient endangered.

WARNING

Risk of fire

Cauterizing close to a source of oxygen can lead to fire.

When finishing oxygen therapy, make sure the flow meter is completely closed:


- Turn the flow knob (1) clockwise until it can no longer be turned.

Only then the oxygen flow is completely off.

WARNING

Risk of fire

Before cauterizing, close the flow meter, remove the mask and wait a few moments to ensure that any oxygen accumulation has dissipated.



* optional

** ASTM F1850-22(2005) §76

APL Valve

WARNING

Risk of patient injury

Route all lines/cables away from the APL valve to prevent interference with the APL valve adjustment knob. Lines/cables caught underneath the APL valve adjustment knob could interfere with proper functioning of this valve.

The APL valve has two functions. It limits the maximum pressure during manual ventilation. It also exhausts excess gas into the scavenger system during manual and spontaneous ventilation.

The APL valve is connected to the patient airway through the ventilator. It functions only when the ventilator is in ManSpont mode or ventilator override condition.

The APL valve has a labeled knob for selecting between spontaneous and manual modes of ventilation and for indicating approximate pressure settings.


- When the APL valve knob is rotated fully counterclockwise, pressure is released for spontaneous ventilation. Spontaneous ventilation automatically eliminates resistance to patient exhalation.
- In manual mode, the APL valve knob can be rotated to change the pressure threshold at which gas will flow through the valve and into the scavenging system. Clockwise rotation of the APL valve knob increases the pressure threshold, and counterclockwise rotation of the APL valve knob decreases the pressure threshold. Lifting the top of the APL valve knob will temporarily relieve pressure.

NOTE

The APL valve is automatically excluded from the breathing circuit whenever an automatic ventilation mode is selected.

NOTE

Even in automatic ventilation, the APL valve must be adjusted to a pressure that is safe for the patient.



Communication Ports


- 1 The Fabius GS *premium* has two ports on the back panel for communication with external devices. The ports are labeled **COM 1** and **COM 2*** and support MEDIBUS and Vitalink communications.

WARNING

A test for leakage current must be performed by qualified engineering personnel before use if the Fabius GS *premium* is interfaced with other equipment.

CAUTION

Only the combinations of Dräger approved monitors, mounting parts and interface cables, may be used. Otherwise the correct functioning of the device may be compromised.




Recommended Device Configuration

Configuration 1:

- Fabius GS *premium*
- Gas Analyzer
- port COM 2*

- 2 Connect gas analyzer to either COM 1 or COM 2*.




* optional

Configuration 2:

NOTE

Data Pass Through (gas analysis data) must be enabled by DrägerService or your local authorized service organization.


- Fabius GS *premium*
- gas analyzer
- automatic record keeper
- port COM 2*



- 1 Connect gas analyzer to COM 2.
- 2 Connect anesthesia record keeper to COM 1.

Configuration 3:


- Fabius GS *premium*
- multi parameter monitor with one COM port
- automatic anesthesia record keeper
- port COM 2*



- 3 Connect monitor to anesthesia record keeper.
- 4 Connect anesthesia record keeper to COM 1 or COM 2*.

Configuration 4:

- Fabius GS *premium*
- multi parameter monitor with two COM ports
- automatic anesthesia record keeper
- port COM 2*



- 5 Connect monitor to anesthesia record keeper.
- 6 Connect anesthesia record keeper to COM 1.
- 7 Connect monitor to COM 2.

* optional

Accessory Weight Limits

CAUTION

Only mount accessories according to the Dräger mounting instructions.

CAUTION

Risk of tip-over and personal injury
Front GCX rails have a maximum accessories weight load of 5 lb/2.3 kg, extended out at 3 in/ 7.6 cm from the rail, at any position on the rail.

CAUTION

Risk of tip-over and personal injury
Do not place more than 40 lb (18 kg) on top of the Fabius GS *premium* monitor housing.

CAUTION

Risk of tip-over and personal injury
Do not place more than 22 lb (10 kg) on top of the Fabius GS *premium* optional pull out writing tray.

CAUTION

Risk of tip-over and personal injury
Do not place more than 15 lb (6.8 kg) in any drawer.

CAUTION

Risk of tip-over and personal injury
Trolley mounted units with left hand COSY: the combined weight of the accessories shall not exceed 30 lb (14 kg) at 16" (40 cm) on the side of the Fabius GS *premium* where the COSY is mounted, and shall not exceed 39 lb (18 kg) at 12" (30 cm) on the side opposite the COSY.

CAUTION

Risk of tip-over and personal injury
Trolley mounted units with right hand COSY: the combined weight of the accessories shall not exceed 22 lb (10 kg) at 12" (30 cm) on the side of the Fabius GS *premium* where the COSY is mounted, and shall not exceed 30 lb (14 kg) at 16" (40 cm) on the side opposite the COSY.

CAUTION

Risk of tip-over and personal injury
Trolley mounted units: The total combined weight of all accessories and monitors mounted on the top and sides of the Fabius GS *premium* shall not exceed 80 lb (36 kg).

CAUTION

Risk of tip-over and personal injury
Wall mounted units: the combined weight of the accessories shall not exceed 60 lb (27 kg) on the Fabius GS *premium*.
If necessary, additional accessories must be mounted onto wall rails.

Abbreviations

Abbreviation Meaning






AGS	Anesthetic Gas Receiving System
AGSS	Anesthetic Gas Scavenging System
AIR/Air	Compressed air for medical use
APL	Adjustable Pressure Limitation
bpm	Breaths per minute
CAL	Calibration
cmH ₂ O	Centimeters of water
CO ₂	CO ₂ concentration
COSY	Compact Breathing System
ΔPPS	Pressure difference for pressure support in pressure support mode
Des.	Desflurane
EMC	Electromagnetic Compatibility
ESD	Electro-static-discharge
Exp	Expiratory
FiO ₂	Inspiratory O ₂ concentration
f	Breathing frequency
FLOW	Expiratory flow
Freq	Frequency
Freq Min	Mandatory minimum frequency in pressure support mode
hPa	Hectopascal
in./insp.	Inspiratory
Insp Flow	Inspiratory flow
L/min	Liters per minute
Man	Manual ventilation
MAN	
mbar	Millibar
MEAN	Mean pressure
MV	Minute volume
N ₂ O	Nitrous oxide
O ₂	Oxygen
PAW	Airway pressure

Abbreviation Meaning









PCB	Printed Circuit Board
PEAK	Peak pressure
PEEP	Positive end-expiratory pressure
P _{INSP}	Pressure limitation in Pressure Control mode
PLAT	Plateau pressure
P _{MAX}	Pressure limitation in Volume Control mode
PS	Pressure support
psi	Pounds per square inch
SIMV	Synchronized Intermittent Mandatory Ventilation
S-ORC	Sensitive Oxygen Ratio Controller
spont	Spontaneous breathing
SPONT	
STP	Standard conditions for temperature and pressure
T _I :T _E	Ratio of inspiratory to expiratory time
T _{IP} :T _I	Ratio of inspiratory pause time to inspiratory time
T _{INSP}	SIMV Inspiratory time
Trigger	Trigger Level
UPS	Uninterruptable power supply
VAC	Vacuum (e.g. for secretion suction)
V _E	Expiratory minute volume
V _T	Tidal volume







Symbols

The following symbols appear on the labels on the back of the Fabius GS *premium* and are defined below:

	Caution: Refer to accompanying documents before operating equipment.
	Caution: Risk of electric shock, do not remove.
	Degree of protection against electric shock: Type BF
	Conformité Européenne Directive 93/42/EEC on Medical Products
	Year manufactured

The following symbols are used on other locations of the Fabius GS *premium* to provide quick and easy recognition of product functions.

	Connection for equipotential bonding
	Oxygen Concentration Sensor Port
	Breathing Pressure Sensor Port
	Breathing Volume Sensor Port
	Ventilator Port
	Pipeline, Gauge, Pipeline inlet
	Breathing Bag
	Flowmeter Level Indicator

	Indicates Direction
	Total Power Applied
	Partial Power Applied
	Cylinder Gauge, Remote Cylinder Inlet
	Do Not Oil
	ESD warning symbol: Do not touch contacts of interface if not electrostatically discharged.



Consult Instructions for Use



Use by date



Observe leakage current














Transportation Label

Rx only

CAUTION: USA Federal law restricts this device to sale by or on the order of a physician.


The following symbols are used on the Fabius GS *premium* monitoring user interface.

	Upper and Lower Alarm Limits
	Return to Home Screen
	Suppress Alarm Tone for Two Minutes
	Standby Mode
	Available Operating Capacity of UPS
	Close Menu, Back to Previous Menu
	Upper Alarm Limit
	Lower Alarm Limit
	Mains Applied/Mains Power
	Alarm Off
	Setup Screen

Operation Concept

Control Panel	32
The Screen Display	33
Rotary Knob	34
Fixed Function Keys	34
Soft Keys	35
Selecting/Setting Monitoring Functions	36
Selecting/Setting Ventilation Parameters	38
Fresh-Gas Control	39
Total Flow Meter	40
Fresh-Gas Flow Monitoring Resolution	41
LED Indicators	42
Gas System Color Coding	42
Screen Color Concept	42

Control Panel




The control panel on the Fabius GS *premium* is characterized by a small number of elements, clear layout, and ease of operation.

Its main elements are:

- 1 A screen displaying all monitoring and ventilation information in numeric and graphic form.
- 2 Fixed-function ("hard") keys beside the screen for quick access to major functions.
- 3 Keys with variable functions (referred to as "soft keys" in this manual).
- 4 Rotary dial knob for selecting and confirming screen settings.
- 5 LED indicators.

All controls and LEDs are described in detail beginning on page 34.


The Screen Display



The screen shows status, ventilation, and monitoring data at a glance. The various screen pages use largely the same layout to enable the user to find information quickly.

- 1 Status bar displays the following status information (from left to right):
 - Current ventilation mode.
 - Time remaining in the alarm silence period.
 - Status of Desflurane compensation.
 - Status of reserve battery power.
 - Current time.
- 2 Alarm window which displays up to four of the highest priority alarms.
- 3 Oxygen monitoring window which displays the inspiratory oxygen concentration in percent (%) along with high and low alarm limits.
- 4 Respiratory volume monitoring window which displays the patient's respiratory rate in breaths per minute (Freq), tidal volume, minute volume, and the minute volume high and low alarm limits.

- 5 Breathing pressure monitoring window which displays the patient's positive end expiratory pressure (PEEP), mean or plateau airway pressure (MEAN or PLAT), and peak airway pressure (PEAK) with high and low alarm limits.
- 6 Breathing pressure trace window which displays a trace (waveform) of the patient's breathing pressure.
- 7 Soft key labels.
- 8 Flow Meter Monitor Window which displays a graphical display of flow rates for O₂, AIR, and N₂O in L/min.



956






Rotary Knob

- 1 The rotary knob is the main control used to select and confirm all monitoring and system settings.
 - **Turn** the rotary knob to change or select a value or parameter (clockwise rotation increases a value; counterclockwise rotation decreases a value). This function is indicated in the examples and instructions in this manual by "select".
 - **Press** the rotary knob to set a value or confirm a selection. If the selection is not confirmed, the value or parameter will not change. This function is indicated in the examples and instructions in this manual by "confirm".

Fixed Function Keys

The fixed function keys positioned on both sides of the screen provide access to major machine and monitoring functions. Most fixed function keys must be confirmed by pressing the rotary knob.

- 2 The »**ManSpont**« key selects the Manual/Spontaneous ventilation mode.
- 3 The »**Lamp**« key turns the tabletop light and the ventilator lamp on and off.
- 4 The »**SIMV/PS**« key is used to select the SIMV/PS ventilation mode (optional).
- 5 The »**Pressure Support**« key is used to select the Pressure Support ventilation mode (optional).


- 6 The »**Pressure Control**« key is used to select the Pressure Control ventilation mode.
- 7 The »**Volume Control**« key is used to select the Volume Control ventilation mode.
- 8 The »« key (**Alarms**) displays the Alarm Limits window.
- 9 The »« key (**Setup**) provides two different functions, depending on mode:
 - If pressed during Standby mode, it displays the Standby Setup screen which enables the user to define site defaults and configure system settings (see page 118).
 - If pressed during a ventilation mode, it allows the user to view and change monitoring settings.
- 10 The »« key (**Home**) displays the main screen from any other screen currently displayed.
- 11 The »« key (**Silence**) silences all active alarm tones for two minutes.
- 12 The »« key (**Standby**) switches the machine to standby mode. Monitoring and alarms are turned off and the ventilator stops. Fresh-gas monitoring continues.

Soft Keys


The functions of the six soft keys located below the the screen are indicated by the labels shown above each key. The labels change depending on the current mode:


- 1 In Standby mode, the following soft key labels appear at the bottom of the Standby screen:
 - »Run System Test«
 - »Calibrate Flow Sensor«
 - »Calibrate O2 Sensor«
 - »Leak / Compl Test«
 - »Access Alarm Log«
 - »Restore Site Defaults«

See "Configuration Functions in Standby Mode" on page 118 for complete information.



- 2 In any ventilation mode, the soft key labels show the ventilation parameters and functions that are available in that particular ventilation mode (Volume Control mode parameters are shown in the example illustration).




- 3 If the »« key (**Setup**) is pressed in any ventilation mode, the following soft keys appear at the bottom of the screen:

- »Volume Alarms On/Off«
- »Auto Set«
- »Calibrate O2 Sensor«
- »Des Comp On/Off«
- »Access Alarm Log«
- »Access Alarm Volume«

NOTE

The »Volume Alarms On/Off« soft key label does not appear in ManSpont mode because it is selectable on the ManSpont screen.




See "Configuration during Operation" on page 138 for complete information.

Selecting/Setting Monitoring Functions

The following example describes changing alarm limits in the Standby Setup Screen.


Example:

- Press the »⏻« key (**Standby**) and confirm to display the Standby screen.




501

- Press the »⏻« key (**Setup**) and enter the desired password to display the Standby Setup screen. (Selecting and confirming the return arrow on the right of the Setup screen will exit the Standby Setup screen and redisplay the Standby screen.)




504

- The rotary knob enables you to select the »Default Settings« or »Configuration« label. Select and confirm the »Default Settings« label. The Default Settings column is selected. (Selecting and confirming the return arrow will exit the Default Settings column and redisplay the main Setup screen.)




505


- Select and confirm the »Alarm Limits« label. The Default Alarm Limits window appears.



- Select the alarm limit value that needs to change.




- Confirm the alarm limit value and select a new value. (For example in the illustration on the right, the alarm limit was changed from 20 to 25.)
- Confirm the new value for the alarm limit. The new alarm limit is saved and cursor moves to the return arrow.




Selecting/Setting Ventilation Parameters

The following example describes changing the VT (tidal volume) parameter in Volume Control mode:

- 1 In Volume Control mode, press the »Volume Control« key. The Volume Control Ventilation Settings window replaces the Wave-form window.




- 2 Press the »VT« soft key. The key becomes highlighted.



- Select a new value.
- Confirm the new value.

NOTE
There is a 15-second timeout period for making ventilation mode changes, with a 3-tone audible sequence after the first 10 seconds. If the new setting is not confirmed within the timeout period, the current ventilation setting remains in effect and the Ventilation Settings window returns to the Wave-form window.

Fresh-Gas Control



The Flow Meter and Pressure Gauge assembly is located on the front panel of the machine below the screen. There are three control knobs for the adjustment of N₂O, AIR, and O₂. The knobs are labeled and color-coded, see page 42. The O₂ control is also touch-coded with a fluted knob.

- to increase flow, turn the appropriate flow control knob counterclockwise
- to decrease flow, turn the appropriate flow control knob clockwise

- 1 N₂O flow control valve
- 2 AIR flow control valve
- 3 O₂ flow control valve
- 4 Total flow meter which displays the flow measurement of all applied gases combined
- 5 N₂O electronic fresh-gas flow indicator
- 6 AIR electronic fresh-gas flow indicator
- 7 O₂ electronic fresh-gas flow indicator
- 8 N₂O central supply pressure gauge
- 9 AIR central supply pressure gauge
- 10 O₂ central supply pressure gauge

11 O₂ cylinder pressure gauge*

12 AIR cylinder pressure gauge*

13 N₂O cylinder pressure gauge*

14 O₂ Low Supply Pressure Alarm LED which flashes when the supply is below the factory set minimum pressure, nominally 20 psi (1.4 kPa x 100).

The displayed fresh-gas flow ranges from 0 L/min to 12 L/min. In case of a greater fresh-gas flow, the electronic fresh-gas flow indicator (5, 6, 7) is blinking and in the flow meter monitor window appears the sign "+" above the graphical display of the flow rates.

NOTE

The electronic fresh-gas flow meter is altitude-corrected.

* Only used with Pin-Index connectors (not present with threaded connectors).

Total Flow Meter

NOTE

The total flow meter is calibrated for a 50/50 mixture of N₂O and O₂. The accuracy of the flow meter may degrade with other gas mixtures. (See the Technical Data section for specifications.)

The total flow meter serves two purposes. The total flow meter provides a reference of the total fresh gas applied to the breathing circuit. (Flow rate measurements for each individual gas, N₂O, AIR and O₂, are provided by their respective electronic flow indicators.)

Should a fault develop in the electronic flow sensing, digital display, or power circuitry, the total flow meter is still functional. The measurement will indicate the total flow rate prior to the fault condition. To adjust the fresh-gas ratios while under the fault condition, shut off all flows (O₂ may be left on), and then restore each gas flow individually. For example, start with 2 L/min O₂. The total flow meter will read 2 L/min.

If 1 L/min of N₂O is needed, open the N₂O flow control knob until the total flow meter reads 3 L/min: 2 L/min O₂ plus 1 L/min N₂O.



Fresh-Gas Flow Monitoring Resolution

The Fabius GS *premium* can be configured by DrägerService or your local authorized service organization to display fresh-gas flow rates either in a standard resolution mode or in a high resolution mode:

- 1 If **standard resolution** is configured, the electronic fresh-gas flow indicators support 100 mL/min increments (format xx.x L/min), and the flow meters on the monitor screen indicate a range of 0 to 12 L/min.
- 2 If **high resolution** is configured, the electronic fresh-gas flow indicators support 10 mL/min increments (format x.xx L/min), and the flow meters on the monitor screen indicate a range of 0 to 10 L/min with an emphasis on resolution at the lower end of the scale.

High-resolution data is displayed when all individual gas flows are below 9.99 L/min.


Switching to standard resolution occurs when the highest flow rate is greater than 9.99 L/min. Switching to high resolution occurs when the highest flow rate drops below 9.00 L/min.



LED Indicators

A number of LED indicators are located on the front panel of the machine.

- 1 Mains Power LED is illuminated when the machine is connected to a Mains power source
- 2 Alarm LEDs are illuminated to indicate the degree of urgency of currently active alarms:
 - Warning: red blinking
 - Caution: yellow blinking
 - Advisory: yellow continuous



In addition, there are small LEDs on the Standby key and all the ventilation mode keys to indicate the currently active mode.

Gas System Color Coding

Each connection, valve, gauge, and flow meter on the Fabius GS *premium* is color-coded for the appropriate gas, as shown the table below:

Gas	USA	ISO
AIR	Yellow	Black/White Checkered
N2O	Blue	Blue
O2	Green	White

Screen Color Concept*

The Fabius GS *premium* displays screen elements such as soft keys, alarms, virtual flow tubes, and screen backgrounds in different colors for improved visibility.

* optional


Assembly

Activating the Battery	44	Connecting the Pressure Breathing Gauge .	61
Fitting the CO₂ Absorber on the Compact Breathing System	44	Connecting the Flow Sensor	62
Installing the Dräger sorb CLIC Adapter . . .	45	Connecting the APL Bypass and PEEP/PMAX Hoses	62
Connecting the Compact Breathing System	46	Installing the COSY Shielding	63
Inserting the Flow Sensor	47	Attaching the Manual Ventilation Bag	63
Connecting the Waste-Gas Outlet Port	48	Preparing the Ventilator	64
Installing the Flexible Bag Arm or Breathing Bag Extension* and Bag	48	Ventilator Safety Features	64
Connecting Pipeline Supply of N₂O, AIR and O₂	49	Installing Vaporizers	65
Connecting the Reserve Gas Cylinders (for Pin-Index Mounting)	50	Additional Equipment	65
Connecting the Reserve Gas Cylinders (for Cylinders with Threaded Connectors)	53	Equipotential Bonding	66
Connecting the AGS Anesthetic Gas Receiving System	54	Connecting AC Power	66
Connecting the Passive Scavenger	56	Auxiliary power outlets	67
Connecting the Suction System	57	Daily and Pre-use Checkout	67
Connecting the Breathing Hoses	58		
Instructions for Use of Bacterial Filters, Endotracheal Tubes, Y-pieces, Breathing Hoses, Soda Lime and other Breathing System Accessories	59		
Resistance summation of the breathing system and connected accessories	59		
Inserting a new O₂ Sensor Capsule	60		
Connecting the O₂ Sensor	60		
Connecting the Pressure Sensor	61		

Activating the Battery

The Fabius GS *premium* anesthesia workstation is shipped with the battery fuse disconnected in order to prevent discharge during shipment and storage prior to installation.

- Remove the battery fuse from the top drawer of the machine.
 - Remove the battery fuse from its packaging.
- 1 Insert the battery fuse into the battery fuse holder. Turn the fuse holder 1/4-turn clockwise until it is snug.



Fitting the CO₂ Absorber on the Compact Breathing System

- Fill the absorber with fresh CO₂ absorbent. Dräger recommends the use of Drägersorb 800 Plus or Drägersorb FREE. For detailed information on filling and installing the reusable absorber, see page 179.


CAUTION

Risk of unintended perioperative awareness
Make sure that during ventilation the absorber canister is tightly connected to the COSY.

NOTE

Ensure that no CO₂ absorbent dust/particles have been deposited between the gaskets and sealing surfaces. Such dust and particles can cause leaks in the system.

- 2 Fit the absorber canister into position below the breathing system and turn it counterclockwise as far as possible.



Installing the Drägersorb CLIC Adapter*

The disposable absorber:
 Drägersorb CLIC 800+, or
 Drägersorb CLIC Free, or
 Infinity ID CLIC Absorber 800+, or
 Infinity ID CLIC Absorber Free
 can be used on the Fabius GS *premium* by using
 the Drägersorb CLIC adapter.
 For information on installing the Drägersorb CLIC
 adapter, consult its Instructions for Use.


WARNING

The disposable absorber must be clicked into place before switching on the Fabius GS *premium*, so that the absorber is included in the leak and compliance test for the machine.

Otherwise breathing circuit leaks could be undetected.

To click the absorber into place:


- 1 Press the button; the mounting swings open.
- Before fitting, shake the disposable absorber, e.g. by turning it upside down several times in order to loosen up the soda lime.
- Remove seal from new disposable absorber.
- Slide the new disposable absorber onto the mounting and
- 2 Push the disposable absorber into the machine until it engages.




* optional

Connecting the Compact Breathing System

- 1 Pull out locking bolt to its full extension and hold.
- 2 Fit the compact breathing system onto the compact breathing system mount.
- Release the locking bolt and rotate the compact breathing system until the locking bolt locks into position.




- 3 Connect the fresh-gas hose from the Fabius GS *premium* to the compact breathing system.



- 1 Connect the ventilation hose to the ventilator and
- 2 attach it to the conical connector ventilator port on the compact breathing system.


If the Fabius GS *premium* is equipped with a threaded connector, the sealing rings on the threaded connector must be undamaged and clean.

Only hand-tighten the threaded connector. Do not use tools.




Inserting the Flow Sensor

- Unscrew and remove the expiration port and the flow-sensor guard (flow sensor protection)
- 3 Insert the flow-sensor guard.
 - 4 Reinstall the flow-sensor guard.
 - 5 Reinstall the expiration port.



Connecting the Waste-Gas Outlet Port

- Screw the waste-gas port into the compact breathing system from underneath.



048

Installing the Flexible Bag Arm* or Breathing Bag Extension* and Bag


WARNING

Risk of use of toxic or incompatible materials
Breathing bags used on the Fabius GS *premium* must comply with current ANSI standards.

CAUTION

Risk of unintended perioperative awareness
Make sure that during ventilation the bag is tightly connected to the bag arm.

- 1 Remove the expiratory hose terminal from the breathing system.
- 2 Slide the bag arm assembly (breathing bag extension assembly*) onto the breathing bag port on the side of the breathing system.
- Align the bracket on the assembly with the holes on the breathing system.
- 3 Tighten the two thumb screws to secure.
- 4 Attach the 90° fitting to the end of the flexible bag arm, and attach the breathing bag to the other end of the fitting (breathing bag extension assembly*).



055

* optional

Connecting Pipeline Supply of N₂O, AIR and O₂

WARNING

Carefully check hoses each time you connect a machine to a wall outlet to ensure that both ends of the hose are indexed for the same gas. Pipeline delivery hoses used between wall outlets and anesthesia workstations have caused accidents when, during assembly, an oxygen fitting was placed on one end of the hose and a nitrous oxide fitting on the other end.


- 1 Connect the gas fitting on each pipeline supply hose to the corresponding fitting on the rear of the machine.
- 2 Connect the other end of each pipeline supply hose to the appropriate functioning wall outlet.

CAUTION

To ensure that gas supplies are at adequate pressure, pipeline pressure gauges must indicate steady pressures of between 50 and 55 psi (3.4 and 3.8 kPa x 100).

NOTE

The loss of the pipeline supply could cause the loss of combined devices.



Connecting the Reserve Gas Cylinders (for Pin-Index Mounting)*

WARNING

When attaching a cylinder, ensure that only one washer is installed between the cylinder and the yoke gas inlet. The use of multiple washers will inhibit the pin-index safety system. Be sure to verify the presence of the index pins each time a cylinder is installed. Never attempt to override the pin-index safety system.


CAUTION

Even if the gas supply is connected to a medical gas pipeline, the cylinders should remain on the device as a reserve.

NOTE

If cylinder valves are leaky or difficult to open or close, they must be repaired in accordance with the manufacturer's specifications.

* optional




- Connect a gas cylinder (1) to its yoke as specified below:
- Remove the old washer (2) and install a new washer on the seat of the yoke gas inlet connection.
- Verify that the two index pins (3) below the gas inlet (4) are present.
- Insert the head (5) of the gas cylinder into the yoke from below. Ensure that the gas outlet and indexing holes on the cylinder head align with the gas inlet and index pins of the yoke assembly (6).
- Engage the indexing holes with the index pins.
- Turn the yoke handle (7) clockwise against the cylinder head, so that the point of the yoke handle bolt is aligned with the indent on the back of the cylinder head. Verify that the washer is in place, the index pins are engaged, and the cylinder hangs vertically.
- Tighten the yoke firmly.
- When required, the cylinder valve (8) is opened using the cylinder wrench (9) that is provided.
- When a cylinder is removed, place the yoke plug (10) in the yoke assembly and tighten.

- 1 Open the cylinder valves.
- To ensure that the cylinder pressures are adequate, check that the cylinder gauges indicate pressures recommended in the table below.
 - Close the cylinder valves.

Cylinders attached to the hanger yokes must contain gas at the recommended pressures shown in the table below. (Indicated pressures are for E-size cylinders at 70 °F/21 °C.) Cylinders measuring less than the minimum recommended pressure (PSI - MIN) should be replaced with new, full cylinders.

Gas	PSI/kPa x 100 - FULL (typical full load)	PSI/kPa x 100 - MIN
AIR	1900/131	1000/69
N ₂ O	745/51	600/42
O ₂	1900/131	1000/69



Connecting the Reserve Gas Cylinders (for Cylinders with Threaded Connectors)*

CAUTION

Risk of explosion

Do not oil or grease the O₂ cylinder valves and O₂ pressure regulator.

CAUTION

Even if the gas supply is connected to a medical gas pipeline, the cylinders should remain on the device in reserve.

CAUTION

Risk of patient injury

Do not connect the cylinders to the pressure inlet without pressure reducers listed in the accessories list 9052228.

NOTE

If cylinder valves are leaky or difficult to open or close, they must be repaired in accordance with the manufacturer's specifications.

NOTE

The cylinder valves must only be opened or closed manually. Never use tools.


NOTE

Risk of unintentional emptying of cylinders

Reserve gas cylinders should remain closed when not in use.

- 1 Place the full cylinders in the cylinder holders and secure them in position.
- Screw the pressure regulators onto the cylinder valves.
- 2 Screw the compressed gas hoses to the pressure regulators and to the connections of the gas inlet block.
- Open the cylinder valves.

* optional



Connecting the AGS Anesthetic Gas Receiving System*

Every Anesthetic Gas Scavenging System (AGSS) used on the Fabius GS *premium* must follow ISO standard 8835-3.

The scavenging system is used with vacuum waste-gas disposal systems.

The AGS is not applied as an independent system. It is used as one of the three components of the AGSS.

WARNING

Risk of patient injury


If the side openings of the receiving system are blocked, negative pressure may result in the breathing system and the patient's lungs. Always make sure the side openings of the receiving system are not blocked.

NOTE

Remove the socket from the scavenger hose before connecting.

NOTE

The scavenger hoses must not be pinched, kinked, or blocked in any manner.



- Hook receiving system with the slots over the appropriate pins of the basic device and allow it to slide down into place.
- 1 Connect the scavenging hose to the relevant socket of the receiving system.
- Connect the connector of the scavenging hose to the terminal unit of the disposal system.
- 2 Close the connection that is not used with a screw cap.
- Push the transfer hose on the designated socket.
- Connect the other end of the transfer hose to the waste-gas port located on the underside of the breathing system.

* optional

NOTE

Activate hospital vacuum system before using scavenger system.


NOTE

During use, the float indicator in the flow indicator (1) should stay between the upper and lower marks. If necessary, regulate flow using the optional flow adjustment valve (2).

WARNING**Danger to the patient**

Do not cover the side openings of the receiving system. Otherwise there may be a shortage of fresh gas in the breathing system.

For detailed information on the AGS, refer to the specific Instructions for Use provided with the anesthetic gas receiving system AGS (9038579).



Connecting the Passive Scavenger*

The passive scavenger system is used only with non-recirculating exhaust systems. It is not meant to be used with vacuum disposal systems.

NOTE

The scavenger hoses must not be pinched, kinked, or blocked in any manner.


- Install the passive scavenger on the machine by sliding its bracket onto the two shoulder screws located on the scavenger mounting bracket on the side of the machine.

NOTE

Remove the socket from the scavenger hose before connecting.

- 1 Connect one end of the transfer hose to the side fitting on the scavenger.
- Connect the other end of the transfer hose to the waste-gas port located on the underside of the breathing system.
- 2 Connect the waste-gas hose to the bottom connection on the scavenger.
- Connect the other end of the hose to the hospital waste-gas disposal system.

For detailed information on the passive scavenger system, refer to separate Instructions for Use.



* optional

Connecting the Suction System*


The optional suction system for the Fabius GS *premium* consists of a suction regulator and a bracket that attaches to the side of the anesthesia workstation. The bracket is used to hold the regulator and a suction bottle assembly of the customer's choice.

- Attach the suction system bracket to the side rail on the side of the anesthesia workstation.
- 1 Mount the suction regulator onto the bracket.
- 2 Install the bottle assembly in the slide mount on the bracket.
- Prepare the suction system according to the Instructions for Use provided with the suction system.

WARNING

Risk of equipment damage

The suction system should be used only in ManSpont mode or with the Y-piece disconnected.



* optional

Connecting the Breathing Hoses


NOTE

Take care not to damage the breathing hoses.

When connecting and disconnecting, always hold the breathing hoses by the end sleeve, not by the spiral reinforcement. Otherwise, the spiral reinforcement may be torn loose.

Breathing hoses with a damaged spiral reinforcement can kink or become occluded.

Before each use, check the breathing hoses for damage.



049

WARNING

Risk of use of toxic or incompatible materials
Breathing hoses used on the
Fabius GS *premium* must comply with current
ANSI standards.

WARNING

Do not use antistatic or conductive breathing hoses. There is a risk of burns when using high frequency electrosurgical equipment.


Fabius GS *premium* has no components containing latex.

For latex-free use:

- Use latex-free breathing bag and breathing hoses!
- 1 Push patient breathing hoses onto both the inspiratory and expiratory connectors or onto optional microbial filters.
- 2 Connect both patient breathing hoses to the Y-piece.
- 3 Push hose with bag onto the connector.

WARNING

Risk of strangulation
Use caution when connecting the patient.



050

Instructions for Use of Bacterial Filters, Endotracheal Tubes, Y-pieces, Breathing Hoses, Soda Lime and other Breathing System Accessories

WARNING

When using accessories in breathing systems or configurations that deviate from standard hose systems, the inspiratory and expiratory breathing resistances may exceed normal requirements.

The user should exercise particular care and monitoring when using such configurations.

With increased breathing resistance, more effort is required on the part of the patient during spontaneous breathing. With volume-controlled ventilation, increased breathing resistance during inspiration has a negligible effect on the administered volume. The peak pressure is however increased during constant plateau pressure. Therefore, during the expiration phase, the time constant (RC) increases. When expiratory times are too short, this may result in the lungs not fully emptying, leading to dynamic lung air trapping. With pressure-controlled ventilation, increased airway resistances may result in reduced inspiratory or expiratory volumes.

Before performing the self test on the device used, the accessory to be used for the application must first be connected. Expander hoses must be pulled out to the appropriate length in order for compliance to be accurately determined and, in the case of volume-controlled ventilation, for the correct tidal volume to be administered.

When using coaxial hoses, leaks between the inner and outer hoses cannot be detected during the self test/leak test.

Resistance summation of the breathing system and connected accessories

In the chapter Technical Data, the inspiratory and expiratory breathing resistance of the breathing system is given without considering the breathing hoses. This allows for the determination of the resistance at the patient using different hose sets and/or filters.

To calculate the Resistance (R) use the following formula:

$$R_{\text{Expiration}} = R_{\text{Breathingsystem_exp}} + R_{\text{ExpHose}} + R_{\text{ExpFilter}}$$

$$R_{\text{Inspiration}} = R_{\text{Breathingsystem_insp}} + R_{\text{InspHose}} + R_{\text{BagHose}} + R_{\text{InspFilter}}$$

Ensure that only accessory resistance data is used for system resistance calculation using the peak flow applicable for the accessory and patient category, e.g. for adults resistance data at 60 L/min, for children at 30 L/min, and for neonates at 5 L/min.


If a filter is used on the Y-piece, the resistance for the inspiratory and expiratory direction must be considered.

The standard for anesthesia breathing systems (ISO 8835-2:2007) allows an overall resulting pressure loss at 60 L/min of max. 6.0 cmH₂O (6.0 hPa) both inspiratory and expiratory.

- Refer to the Instructions for Use of the respective accessory.

Inserting a new O₂ Sensor Capsule


- 1 Unscrew the cap from the sensor housing.
- Remove the new sensor capsule from its packaging.
- 2 Insert the capsule in the housing, with the ring-shaped conductors against the contacts in the housing.
- Screw the cap on firmly by hand.



051

Connecting the O₂ Sensor


- 3 Push the O₂ sensor into the port opening of the inspiratory port dome, and
- 4 plug the connector into the fitting labeled OXYGEN SENSOR on the connector panel on the back of the machine.



016

Connecting the Pressure Sensor


- 1 Press the pressure measuring line onto the hose barb on the underside of the breathing system until it engages.
Do not squeeze the pressure measuring line when pressing it onto the hose barb.
- 2 Connect the pressure measuring line to the bacterial filter, and plug it firmly onto the port labeled PRESSURE BREATHING on the connector panel on the back of the machine.



017

Connecting the Pressure Breathing Gauge*

- Push the pressure measuring line onto the hose barb (3), the breathing pressure gauge port (4) to the pressure gauge connector, and then to the bacterial filter and onto the port labeled PRESSURE BREATHING on the connector panel on the back of the machine (5).




018

* optional

Connecting the Flow Sensor

- 1 Connect the volume line cable onto the connector on the underside of the breathing system.
- 2 Connect the volume line cable to the port labeled VOLUME SENSOR on the connector panel on the back of the machine.




019

Connecting the APL Bypass and PEEP/PMAX Hoses

- 3 Plug the control hose to the connection port on the PEEP/PMAX valve and to the connection port marked PEEP on the connection panel.
- 4 Plug the control hose to the connection port on the APL Bypass valve and to the connection port marked APL on the connection panel.

NOTE


The APL bypass hose is larger than the PEEP/PMAX hose.



020


Installing the COSY Shielding*

Install the COSY shielding on top of the breathing system, being careful to guide all cables through the provided slots.



Attaching the Manual Ventilation Bag

- 1 Hang the fully prepared and tested bag on the rail at the right.




* optional

Preparing the Ventilator

Use only disinfected/sterilized components.

- 1 Open the ventilator door with the attached ventilator unit.
- 2 Unlatch the three clasps.
- 3 Remove the cover.
- 4 Insert the diaphragm.
- Fit the cover and lock the three clasps.
- 5 Connect pressure sensor line of the ventilator chamber to the respective connector.
- 1 Close the ventilator door with the attached ventilator unit.



Ventilator Safety Features

- High pressure safety relief valve (**A**).
- Negative pressure safety relief valve (**B**).
- Ventilator chamber pressure sensor.

Installing Vaporizers

Install vaporizers as directed in the appropriate Instructions for Use supplied with the vaporizers available for use with the Fabius GS *premium*. The anesthetic vaporizer used with the anesthetic system shall comply with ISO 8835-4.

The anesthesia workstation must be used with anesthetic gas monitoring complying with ISO 21647, if an anesthetic vaporizer is used.

WARNING

Risk of spillage or mix-up

Use only suitable adapters for filling and emptying the vaporizer.

Additional Equipment

CAUTION

Risk of tip-over and personal injury

If monitors and other equipment are placed on top of the Fabius GS *premium*, the risk of tipping over the unit is increased, especially when rolling over thresholds etc.

Remove all monitors and other equipment from the top of the Fabius GS *premium* before moving the unit.

CAUTION

Risk of tip-over and personal injury


Do not place more than 40 lb (18 kg) on top of the Fabius GS *premium* monitor housing.

Prepare additional equipment as specified in the specific Instructions for Use.

Equipotential Bonding

e.g. intra-cranial and intra-cardiac operations.

- Use cable e.g. 83 01 349.
- 1 Connect the terminal on the back to an equipotential bonding point in the operating room.
- Connect one end of the earth cable to one of the connecting pins located on the back of the Fabius GS *premium*
 - Connect the other end of the earth cable to the specified equipotential bonding point, e.g., on the operating table or ceiling lamp.
 - Connect equipotential bonding to the auxiliary equipment



Connecting AC Power

Fabius GS *premium* can be operated at mains voltages from 100 V to 240 V.

- Push power plug into supply mains socket.
- 2 Switch on the machine by using the ON/OFF switch on the rear of the machine.

WARNING

Only connect device to approved "hospital grade" outlets having the appropriate grounding reliability.

WARNING

Do not connect life-supporting devices to the auxiliary power outlet(s) of the anesthesia workstation; if the mains/hospital power supply fails, devices connected to the auxiliary power outlet(s) (optional) will not be supplied by the anesthesia workstation's battery backup and will discontinue operation.

Auxiliary power outlets

WARNING

Risk of electric shock

Connecting equipment to the auxiliary power outlets may cause the patient leakage current to rise above the permitted values if a protective earth conductor should fail. The risk of electric shock cannot be excluded in such cases.

WARNING

Do not connect life-supporting devices to the auxiliary power outlets of the anesthesia workstation. The auxiliary power outlets are not powered by the uninterruptible power supply (UPS) in the event of a power failure.

WARNING

Risk of increased leakage current

Do not connect HF surgical devices to the auxiliary power outlets.

WARNING

Risk of increased leakage current

Additional power adapter outlets must not be connected to the auxiliary power outlets.

Daily and Pre-use Checkout

At the completion of the assembly of the Fabius GS *premium*, perform the Daily and Pre-use Checkout procedure provided in the Appendix of this manual to ensure that the machine is ready for operation.

This page intentionally left blank

Getting Started

Powering-Up the Machine	70
Power-Up Standby Screen	71
Checking Readiness for Operation	71

Powering-Up the Machine

- 1 Turn the ON/OFF switch to the ON position. When the ON/OFF switch is turned to the ON position, the Fabius GS *premium* performs extensive self tests on its internal hardware. As these diagnostics are performed, each test and its result appear on the screen. The result, Pass or Fail, indicates the status of the tested component.

We recommend the user to remain close to the device within a range of up to 4 m (13 feet), to ascertain the verification by the acoustic tones of the speakers.

During this self test, two test tones are emitted to show speakers functionality.

CAUTION

The user must verify the acoustic tones are emitted as the device can only verify the presence of the speakers.

If no or only one tone is sounded, the device is conditionally functional.

The complete loss of ventilation and monitoring functionality might not be noticed.

Contact DrägerService.

At the end of the self-diagnostics, one of three possible conclusions to the self tests is posted on the screen:


FUNCTIONAL

Every component of the monitoring system is in satisfactory operational order. After a brief delay, the Standby screen appears.

CONDITIONALLY FUNCTIONAL

A non-critical fault was detected. The Fabius GS *premium* may be used, but call DrägerService or your local authorized service organization.

Press the rotary knob to continue operation.



SYSTEM DIAGNOSTICS		Fabius G5 <i>premium</i>
Watch Dog Timer	Pass	
Systen RAM	Pass	
Program Menory	Pass	
Video Test	Pass	
Interrupts	Pass	
A/D Converter	Pass	
NV RAM	Pass	
Serial Port	Pass	
Clock	Pass	
Speaker	Pass	
Main Power	Pass	
Battery	Pass	
		FUNCTIONAL

Dräger

MEDICAL

Fabius G5 *premium* SW 3.32 CRC D225

NON-FUNCTIONAL

A serious fault was detected and operation of the monitor and ventilator is inhibited. Do not use the machine. Immediately call DrägerService or your local authorized service organization to correct the problem.

WARNING

The power-on self test should be carried out once a day.


Switch Fabius GS *premium* off and on or start the self test by pressing the soft key »Run System Test«.

Power-Up Standby Screen

Following a successful power-up, the Standby screen appears and provides instructions on starting the operation of the Fabius GS *premium*.

Checking Readiness for Operation

Check the readiness of the Fabius GS *premium* by testing all required components as specified in the daily and pre-use checkout provided in the appendix of this manual. If all checks are satisfactorily completed, begin operation as specified in "Operation" on page 73.




This page intentionally left blank

Operation

Power-Up Standby Screen	74
Setting Fresh-Gas Flow	74
S-ORC (Sensitive Oxygen Ratio Controller) ..	74
Setting Vaporizer Concentration	76
O₂ Flush	77
Low Flow Anesthesia	78
Nitrogen Wash-Out (If Required)	78
Replacing CO₂ Absorbent	78
CLIC Adapter	80
Ventilation	81
Manual/Spontaneous Ventilation Mode	81
Volume Control Ventilation	84
Pressure Control Ventilation	87
Pressure Support Ventilation	89
SIMV/PS Ventilation	92
When Changing Between Ventilation Modes ..	95
Ventilator Safety Features	97
Behaviour during Lack of Fresh-Gas	97
Changing Patients	98
Ending Operation	99
When Fabius GS premium is not in use	99
Preparing for Storage or Transport	100

Power-Up Standby Screen

Following a successful power-up, the Standby screen appears and provides instructions on starting the operation of the Fabius GS *premium*.



Setting Fresh-Gas Flow

Set the fresh-gas flow to the desired concentration using the flow control knobs on the front of the machine.

S-ORC (Sensitive Oxygen Ratio Controller)

S-ORC is a control element which provides a minimum O2 concentration in the fresh-gas flow. From a flow rate of approx. 300 mL/min, the N2O concentration in the fresh gas can be set between 0 and 75 %.

During O2 shortage S-ORC limits the N2O concentration in the fresh gas, so that the O2 concentration does not drop below 23 Vol.%.

S-ORC prevents N2O flow if the N2O metering valve is open and O2 metering valve closed or if the O2 flow is less than 0.2 L/min.

During N₂O failure O₂ may still be administered. No alarm sounds. The float in the N₂O measuring tube drops to zero.

CAUTION

Risk of inaccurate measuring values

After the O₂ supply has been restored, a supply pressure of at least 2.7 kPa x 100 must be applied for at least 20 seconds before another O₂ shortage signal can be emitted.

During this period, do not activate any devices that consume O₂ (e.g. O₂ flush, O₂ fresh-gas flow or secretion aspiration).

However, S-ORC is not an oxygen-specific monitoring device and therefore cannot provide any protection against the effects of accidental use of the wrong gas.

Therefore **always** monitor the O₂ concentration.

WARNING

Damage to materials and health risks


Never switch off fresh-gas flow before the vaporizer is switched off. A vaporizer must never be left switched on without a fresh-gas flow, because high-concentration anesthetic vapor may leak into machine lines and ambient air, causing damage to materials and health risks.

Setting Vaporizer Concentration

Refer to the appropriate Instructions for Use for the vaporizer being used. Vapor 2000 is shown and described below.


For the Dräger Interlock 2 system:

- Ensure that the vaporizer is properly seated.
- 1** Lock the unused vaporizer by moving the selector lever completely towards it. For example, to lock the left vaporizer, move the lever to the left.
- 2** With the handwheel set to »T« position on the unlocked vaporizer, press the button and engage the handwheel at »0«. Wait five seconds for the pressure to balance.
- 3** Press the button and turn the handwheel counterclockwise to set the required anesthetic gas concentration.
- Regularly check the filling level on the sight glass. When reaching the minimum mark, fill the vaporizer with anesthetic agent.



For the Dräger Auto Exclusion system:

- Close any open vaporizers.
- Ensure that the vaporizer is properly seated.
- 4** With the handwheel set to »T« position, press the button and engage the handwheel at »0«. Wait five seconds for the pressure to balance.
- 5** Press the button and turn the handwheel counterclockwise to set the required anesthetic gas concentration.
- Regularly check the filling level on the sight glass. When reaching the minimum mark, fill the vaporizer with anesthetic agent.




O₂ Flush

A manually operated O₂ flush valve is located on the front of the machine. When actuated, the valve delivers an unmetered flow of at least 35 L/min to the breathing system and breathing bag while bypassing the ventilator. The Fabius GS *premium* does not need to be switched on in order to use the O₂ flush.

- Press the O₂ flush button. Additional O₂ flows into the compact breathing system as long as the button is pushed in. The flow control elements and the anesthetic agent vaporizer (Vapor) are bypassed.

NOTE

In ManSpont mode, pressure may rise rapidly up to the setting of the APL valve.



Low Flow Anesthesia

With low flow anesthesia (means flow ≤ 1.0 L/min) the condensation of patients humidity from the expired breath is natural. Condensation occurs in the hoses. To avoid water accumulating in the hoses, a water trap (optional) should be integrated in the ventilator hose. In long term low flow anesthesia the additional use of water traps in the expiratory hose is recommended. Empty water traps if their water level exceeds the maximum water level limit.

Nitrogen Wash-Out (If Required)

During anesthesia induction, air containing about 77 % nitrogen (N₂) remains in the compact breathing system (and in the patient's lungs). If the unit will be used for a low-flow anesthesia case, press the O₂ Flush to remove this N₂.

Replacing CO₂ Absorbent

The CO₂ absorbent in the compact breathing system should be replaced when two-thirds of the CO₂ absorbent has changed color. Dräger recommends the use of Drägersorb 800 Plus or Drägersorb FREE. The color change indicates that the CO₂ absorbent can no longer absorb CO₂ (Drägersorb 800 Plus and Drägersorb FREE change from white to violet).

WARNING

Do not flush dry gas continuously for unnecessarily long periods through the soda lime in the anesthesia workstation.

Otherwise the soda lime will dehydrate. If the moisture level falls below a minimum level, undesirable reactions generally occur, regardless of the type of soda lime and the inhalation anesthetic used:

- **reduced CO₂ absorption,**
- **increased heat generation in the absorber and therefore increased breathing gas temperature,**
- **CO formation,**
- **absorption and/or breakdown of the inhalation anesthetic.**

The above mentioned reactions may endanger the patient, e.g.:

- **CO poisoning**
- **insufficient depth of anesthesia**
- **burns of the airway.**

CAUTION

Soda lime irritates the skin and there is a risk of serious damage to eyes.

If soda lime has leaked:

- Powdered soda lime must not be inhaled or swallowed.
- Put on protective gloves and goggles, or a face mask.
- In case of coming in contact with eyes, rinse immediately with large amounts of water and consult a physician immediately, otherwise it may lead to eye damage.
- Powdered soda lime on the skin must be washed off immediately, because it may irritate the skin.

NOTE

Please refer to the specific Instructions for Use for "Drägersorb 800 Plus or Drägersorb FREE".

- Remove the absorber canister by turning it clockwise.
- Empty the expired CO₂ absorbent from the absorber into an appropriate refuse container.
- Fill the absorber with fresh CO₂ absorbent.


NOTE

Ensure that no CO₂ absorbent dust/particles have been deposited between the gaskets and sealing surfaces. Such dust and particles can cause leaks in the system.

- 1 Fit the absorber canister into position below the breathing system and turn it counterclockwise as far as possible.

CAUTION

Risk of unintended perioperative awareness
Make sure that during ventilation the absorber canister is tightly connected to the COSY.



056

CLIC Adapter*

The disposable CLIC adapter absorber can also be used on the Fabius GS *premium*. For information on installing the CLIC adapter, consult its Instructions for Use.

* optional

Ventilation

WARNING

Risk of strangulation

Use caution when connecting the patient.


Manual/Spontaneous Ventilation Mode

ManSpont (Manual/Spontaneous) is a non-automatic mode of ventilation. However, the ventilation monitor and alarms are still operational. In ManSpont mode, the ventilator piston is moved partially upward to reduce system compliance. Manual ventilation (with APL valve pressure limit) can be delivered with the APL valve in the MAN position. Spontaneous ventilation (APL valve wide-open) can occur with the APL valve in the »**Spont**« position.


The following examples and illustrations describe starting ManSpont ventilation from the present ventilation mode »**Volume Control**«:

For Spontaneous Breathing:

- Rotate the APL valve knob fully counterclockwise until the index mark on the knob lines up with the index mark on the bottom of the valve. The valve is now open for spontaneous patient breathing.
- Set the appropriate fresh-gas flow.




- 1 Press the »**ManSpont**« key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
- 2 The Waveform window is replaced by the ManSpont window and a message that provides instructions to confirm the mode change.



- Confirm the mode change. The ManSpont screen is activated. After the mode change is confirmed, the »**ManSpont**« key LED switches from blinking to constantly on and the waveform is restored.

The ManSpont screen allows the user to adjust two parameters: Apnea Pressure alarm ON/OFF (see page 116) and Volume alarms ON/OFF (see page 114). Pressing the »**ON/OFF**« soft key toggles the corresponding alarm between ON and OFF.




For Manual Ventilation:


NOTE

In ManSpont mode, the apnea volume timer countdown for caution alarms changes from 15 seconds to 30 seconds, and for warning alarms from 30 seconds to 60 seconds.

- Rotate the APL valve adjustment knob to the desired pressure. Clockwise rotation increases the pressure, and counterclockwise rotation decreases the pressure.




- 1 Press the »**ManSpont**« key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
- 2 The Waveform window is replaced by the ManSpont window and a message that provides instructions to confirm the mode change.



- Confirm the mode change. The ManSpont screen is activated. After the mode change is confirmed, the »**ManSpont**« key LED switches from blinking to constantly on and the waveform is restored.


The ManSpont screen allows the user to adjust two parameters: Apnea Pressure alarm ON/OFF and Volume alarms ON/OFF. Pressing the »**ON/OFF**« soft key toggles the corresponding alarm between ON and OFF.



- Press the O₂ flush button, as required, to re-inflate the bag.
- Set the appropriate fresh-gas flow.
- Start manual ventilation. The pressure will be limited to the value set on the APL valve.
- Start manual ventilation by hand via the breathing bag.

To temporarily relieve pressure:

- Pull on the APL valve knob.



Volume Control Ventilation

Ventilator Compliance Compensation

Ventilator compliance compensation is continuously applied during Volume Control so that the tidal volume delivered to the patient corresponds to the VT setting. Ventilator compliance is determined during the leak and compliance test performed from the Standby mode (see "Leak/Compliance Test" on page 122). To have compliance compensation work accurately, it is important that the patient hoses used during the leak/compliance test match the type of hoses used during the procedure.


NOTE

When the ventilator settings for Volume Control cause the ventilator to operate at its limits of performance, it is not possible for the Fabius GS *premium* to apply compliance compensation. If the ventilator's performance limit is reached, it is not possible to increment the VT setting via the Volume Control Settings window.


Starting Volume Control Ventilation

The following examples and illustrations describe starting Volume Control ventilation from the present ventilation mode "Pressure Control":

- 1 Press the »Volume Control« key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
- 2 The Waveform window is replaced by the ventilator settings window and a message that provides instructions to confirm the mode change.



- If the ventilator settings are correct, confirm the mode change.
- If the ventilator settings are not correct, for each parameter that needs to change, press the corresponding soft key, select the correct value, and confirm the change. When the parameter changes are completed, confirm the ventilation mode change.
- After the mode change is confirmed, the »Volume Control« key LED switches from blinking to constantly on, the ventilator switches to the Volume Control mode, and the waveform is restored.



The parameters that can be set for Volume Control mode are shown in the adjacent table, along with their adjustment ranges and factory default values.

Ventilation Parameter (Volume Control Mode)	Adjustment Range	Factory Default Value
Pressure Limitation P _{MAX} [cmH ₂ O] ([hPa])	15 to 70 min. PEEP+10	40
Tidal Volume V _T [mL]	20 to 1400	600
Frequency Freq [bpm] ([1/min])	4 to 60	12
Insp time: Exp time T _i :T _E	4:1 to 1:4	1:2
Insp pause time: Insp time T _{IP} :T _I [%]	0 to 50	10
PEEP [cmH ₂ O] ([hPa])	0 to 20	0


Based on a defined frequency (**Freq**) and a defined ratio of inspiratory time to expiratory time (**Ti:TE**), a tidal volume (**V_T**) is applied at a constant inspiration flow (**Insp Flow**).

The inspiration flow (**Insp Flow**) results from the tidal volume (**V_T**) and the ratio of inspiratory pause time to inspiratory time (**T_{IP}:T_i**).

When **T_{IP}:T_i** is set to 0, the tidal volume (**V_T**) is applied at the lowest inspiration flow (**Insp Flow**) which is possible at the corresponding frequency (**Freq**). In addition, a positive end-expiratory pressure (**PEEP**) can be set.

To avoid too high pressures, the alarm limit **P_{MAX}** can be set according to the physiological state of the patient.

The lower pressure limit **P_{AW low}** is used for pressure monitoring to detect apneas (disconnection) and continuous pressure. An alarm is generated when the pressure curve does not cross the pressure threshold either from above or below.





Pressure Control Ventilation*

Starting Pressure Control Ventilation

The following examples and illustrations describe starting Pressure Control ventilation from the present ventilation mode "Volume Control":

- 1 Press the **»Pressure Control«** key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
- 2 The Waveform window is replaced by the ventilator settings window and a message that provides instructions to confirm the mode change.
 - If the ventilator settings are correct, confirm the mode change.
 - If the ventilator settings are not correct, for each parameter that needs to change, press the corresponding soft key, select the correct value, and confirm the change. When the parameter changes are completed, confirm the ventilation mode change.
 - After the mode change is confirmed, the **»Pressure Control«** key LED switches from blinking to constantly on, the ventilator switches to the Pressure Control mode, and the waveform is restored.



The parameters that can be set for Pressure Control mode are shown in the adjacent table, along with their adjustment ranges and factory default values.


Due to compliance and resistance combinations, the adjusted Freq Min might not be applied accurately in the Pressure Control Mode.

Ventilation Parameter (Pressure Control mode)	Adjustment Range	Factory Default Value
Inspiratory Pressure PINSP [cmH ₂ O] ([hPa])	5 to 65 min. PEEP+5	15
Frequency Freq [bpm] ([1/min])	4 to 60	12
Insp time: Exp time Ti:Te	4:1 to 1:4	1:2
Inspiratory Flow Insp Flow [L/min]	10 to 75	30
PEEP [cmH ₂ O] ([hPa])	0 to 20	0

* optional

Based on a defined frequency (**Freq**) and a defined ratio of inspiratory time to expiratory time (**Ti:TE**), a volume is applied. This volume depends on the set inspiratory pressure (**P_{INSP}**) and the patient compliance. The **Insp Flow** key is used to set the slope of the pressure waveform. In addition, a positive endexpiratory pressure (**PEEP**) can be set.

The lower pressure limit **Paw low** is used for pressure monitoring to detect apneas (disconnection) and continuous pressure. An alarm is generated when the pressure curve does not cross the pressure threshold either from above or below.



Pressure Support Ventilation*

Pressure Support ventilation is intended to reduce the work of breathing and is indicated for use only in patients who are breathing spontaneously. Patients who are not making spontaneous breathing efforts are not candidates for Pressure Support ventilation.

Pressure Support ventilation is triggered by the patient's spontaneous effort to breathe. Most anesthetic agents will cause patients to have reduced ventilatory responses to carbon dioxide and to hypoxemia. Therefore, patient triggered modes of ventilation may not produce adequate ventilation. Additionally, the use of neuromuscular blocking agents will interfere with patient triggering.

Apnea Ventilation is a feature within Pressure Support ventilation. To enable Apnea Ventilation, adjust the **Freq Min** setting to a value other than **OFF**. If the detected patient spontaneous breathing rate falls below the set value, the ventilator automatically delivers a Pressure Support breath.

Apnea ventilation is intended to provide some degree of gas exchange if the patient's respiratory rate falls below the desired minimum setting. It is not intended as a primary mode of ventilation.

When delivering Apnea Ventilation, the Fabius GS *premium* uses the Pressure Support settings for **ΔP_{ps}** , **Freq Min**, **Insp Flow**, and **PEEP**.



If two consecutive Apnea Ventilation breaths occur, the Caution message »**APNEA VENTILATION!!**« appears in the Alarm window. The alarm is cleared when a spontaneous breath is detected.

* optional

Starting Pressure Support Ventilation

The following examples and illustrations describe starting Pressure Support ventilation from the present ventilation mode "Volume Control":


- 1 Press the »Pressure Support« key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
- 2 The Waveform window is replaced by the ventilator settings window and a message that provides instructions to confirm the mode change.
- If the ventilator settings are correct, confirm the mode change.
- If the ventilator settings are not correct, for each parameter that needs to change, press the corresponding soft key, select the correct value, and confirm the change. When the parameter changes are completed, confirm the ventilation mode change.
- After the mode change is confirmed, the »Pressure Support« key LED switches from blinking to constantly on, the ventilator switches to the Pressure Support mode, and the waveform is restored.



The parameters that can be set for Pressure Support mode are shown the adjacent table, along with their adjustment ranges and factory default values.

Ventilation Parameter (Pressure Support mode)	Adjustment Range	Factory Default Value
Support pressure ΔPPs [cmH2O] ([hPa])	3 to 20, OFF	10
Minimum frequency for apnea ventilation Freq Min [bpm] ([l/min])	3 to 20, OFF	3
Trigger Sensitivity Trigger [L/min]	2 to 15	2
Inspiratory Flow Insp Flow [L/min]	10 to 85	30
PEEP [cmH2O] ([hPa])	0 to 20	0

Pressure Support (**PS**) can be used to support the spontaneous breathing of the patient. If the inspiration flow (**Insp Flow**) during inspiratory effort is greater than the set trigger flow (**TRIGGER**), the device supports the patient according to the Pressure Support setting (ΔP_{PS}). The set inspiratory flow (**Insp Flow**) defines how fast the ΔP_{PS} pressure is reached. The end of inspiration is automatically triggered when reaching 25% of maximum inspiratory flow (**Insp Flow**) or after a maximum of 4 s. The value **Freq Min** (e.g., 3 bpm (1/min)) is used to set a safety period (safety period = $1/\text{Freq Min}$, e.g., 20 s). If no inspiratory effort is detected and the safety period has expired, the device applies a pressure-controlled breath with $P_{INSP} = \Delta P_{PS}$.



The lower pressure limit **Paw low** is used for pressure monitoring to detect apneas (disconnection) and continuous pressure. An alarm is generated when the pressure curve does not cross the pressure threshold either from above or below.

SIMV/PS Ventilation*

Synchronized Intermittent Mandatory Ventilation (SIMV) mode is a mixture of mechanical ventilation and spontaneous breathing. In SIMV mode, the patient can breathe spontaneously. SIMV will attempt to synchronize the mandatory ventilation strokes with spontaneous efforts.


The mandatory ventilation strokes are the same as those for volume ventilation. They are defined by the parameters **Vt**, **Freq**, **T_{INSP}**, **T_{IP}:T_I**, and **PEEP**.

Pressure support can be added during SIMV mode to augment the patient's spontaneous breathing efforts. Adjusting the ΔP_{PS} level to a value other than **OFF** will enable Pressure Support during SIMV mode. (Refer to "Pressure Support Ventilation" on page 89 for additional information on Pressure Support ventilation.)

Starting SIMV/PS Ventilation

The following examples and illustrations describe starting SIMV/PS ventilation from the present ventilation mode Volume Control:

- 1 Press the »SIMV/PS« key. The LED associated with this key starts blinking. It remains blinking until the selected mode of operation is confirmed.
 - 2 The Waveform window is replaced by the ventilator settings window and a message that provides instructions to confirm the mode change.
- If the ventilator settings are correct, confirm the mode change.
 - If the ventilator settings are not correct, for each parameter that needs to change, press the corresponding soft key, select the correct value, and confirm the change. When the parameter changes are completed, confirm the ventilation mode change.




* optional

The parameters that can be set for SIMV/PS mode are shown in the adjacent table, along with their adjustment ranges and factory default values.

- To access the **Trigger**, **Insp Flow**, **T_{INSP}**, and **T_{IP}:T_I** parameters, press the »**MORE**« key on the SIMV/PS screen.
- After the mode change is confirmed, the »**SIMV/PS**« key LED switches from blinking to constantly on, the ventilator switches to the SIMV/PS mode, and the waveform is restored.

Ventilation Parameter (SIMV/PS Mode)	Adjustment Range	Factory Default Value
Pressure Limitation P _{MAX} [cmH ₂ O] ([hPa])	15 to 70 min. PEEP+10 and >ΔP _{PS} +PEEP	40
Tidal Volume V _T [mL]	20 to 1100	600
Frequency Freq [bpm] ([1/min])	4 to 60	12
Support pressure ΔP _{PS} [cmH ₂ O] ([hPa])	3 to 20, OFF	10
PEEP [cmH ₂ O] ([hPa])	0 to 20	0
Trigger Sensitivity Trigger [L/min]	2 to 15	2
Inspiratory Flow Insp Flow [L/min]	10 to 85	30
SIMV insp. time T _{INSP} [seconds]	0.3 to 4.0	1.7
Insp pause time: Insp time T _{IP} :T _I [%]	0 to 50	10

The ventilation mode **SIMV** (synchronized intermittent mandatory ventilation) applies volume-controlled breaths at a constant inspiratory flow with defined settings for **V_T**, **T_{INSP}**, **T_{IP}:T_I** and **P_{MAX}**. Ventilation is applied in synchronization with inspiratory effort of the patient. The frequency **Freq** defines the time between the individual volumecontrolled breaths. The synchronization of the breaths is done with a **TRIGGER** which is activated a certain amount of time before a new breath is applied: 5 s for frequencies (**Freq**) below 12 bpm (1/min). At higher frequencies, synchronization is done directly after the preceding expiration. In between these mandatory breaths the patient can breathe spontaneously. Mandatory breaths are synchronized with the spontaneous breaths of the patient. These spontaneous breaths can be supported with Pressure Support.



112

The lower pressure limit **PAW low** is used for pressure monitoring to detect apneas (disconnection) and continuous pressure. An alarm is generated when the pressure curve does not cross the pressure threshold either from above or below.

When Changing Between Ventilation Modes

Selected ventilator settings for the new mode of operation are automatically derived from the settings and performance of the last confirmed automatic ventilation mode. Settings affected in the new mode will be highlighted as shown in the figure.

The settings for **Freq**, **Ti:Te**, and **PEEP** are taken directly from the settings used in the former mode as applicable.

When changing from Volume Control to Pressure Control, **P_{INSP}** is set to the Plateau pressure developed in Volume Control.


When changing from Volume Control or Pressure Support to Pressure Control, the suggested value for **Insp Flow** is either the last used value or the site default value.

When changing from Pressure Control to Volume Control, **V_T** is set by dividing the last minute volume by the respiratory rate.

When changing from Pressure Control to Volume Control, the suggested value for **Ti:P:Ti** is either the last used value or the site default value.

When changing from Pressure Control to Volume Control, **P_{MAX}** is set 10 cmH₂O (hPa) higher than the plateau pressure developed during Pressure Control.

When changing from Volume Control or Pressure Control to Pressure Support, the suggested value for **Insp Flow** is either the last used value or the site default value.



When changing from Volume Control or Pressure Control to Pressure Support, the suggested value for **ΔPPs** is either the last used value or the site default value.

When changing from Volume Control or Pressure Control to Pressure Support, the suggested value for **Trigger** is either the last used value or the site default value.

When switching between Volume Control mode and SIMV/PS mode, the **P_{MAX}** and **PEEP** settings shall automatically be transferred from the previous mode to the new mode.

When switching from Pressure Support mode to SIMV/PS mode, the **ΔPPs** , **Insp Flow**, **Trigger**, and **PEEP** settings shall automatically be transferred from the previous mode to the new mode.

When switching from SIMV/PS mode with Pressure Support enabled to Pressure Support mode, the **ΔPPs** and **Insp Flow** settings shall automatically be transferred from SIMV/PS to Pressure Support.

When switching from SIMV/PS mode to Pressure Support mode, the **Trigger** and **PEEP** settings shall automatically be transferred from SIMV/PS to Pressure Support.

Ventilator Safety Features

- High pressure safety relief valve (A)
- Negative pressure safety relief valve (B)
- Ventilator chamber pressure sensor

Behaviour during Lack of Fresh-Gas

Background

Due to a very low fresh-gas flow or an excessive leakage in the breathing system, a lack of fresh gas can occur. This can be recognised by observing the gradual emptying breathing bag.

NOTE

The user should then take action to resolve this, for example by increasing the fresh-gas flow.

Fabius GS *premium* behaviour in case of no action taken by the user

- breathing bag gradually empties completely
- after two more strokes the alarm
»FRESH GAS LOW« and additional alarms occurs
- the ventilator absorbs its reserve volume since it is not supplied with sufficient fresh gas.


As long as a lack of fresh gas exists, the safety valve (B) for ambient air is opened during expiration.

CAUTION

If remedial actions are omitted, ambient air will be taken in which will dilute the fresh gas.

The concentration of (e.g.) oxygen or other anesthetic gases will decrease.

Advantages: Even in extreme cases emergency ventilation with limited V_T is possible. A "sudden" shutdown of the ventilator does not occur.




Changing Patients

WARNING

Risk of inappropriate alarm settings

As it is possible that Fabius GS *premium* devices within a care area have different site default alarm limit configurations, check whether the pre-set alarm limits are appropriate to the new patient. Also check that the alarm system has not been rendered useless by setting the alarm limits to extreme values. See "Default Settings in Standby Setup" on page 127.

Follow the steps below for successive cases.

1 Press and confirm the »« key (**Standby**).

Monitoring and alarms are turned off and the ventilator stops. Fresh-gas monitoring continues and the current settings are retained.

To activate default settings instead of using the current settings, press the »**Restore Site Defaults**« key on the Standby screen.


- Check all components identified as Pre-use Checkout items in the Daily and Pre-use Checkout form on page 205.
- If needed, perform the leak/compliance test as described on page 122. The leak/compliance test should be performed each time the absorbent or breathing hoses have been changed, or when a vaporizer has been changed or filled.

WARNING


Risk of patient hazard


Do not perform the leak/compliance test with a patient attached to the workstation.

- Set the ventilation mode as described in "Ventilation" on page 81, and proceed with the case.



Ending Operation

1 Press and confirm the »« key (**Standby**). Monitoring and alarms are turned off and the ventilator stops.




- 2 Turn vaporizers off by turning the handwheel to »0« until the button engages.
- Turn off fresh-gas flow. Sleep mode will activate 2.5 minutes after fresh gas is turned off.
 - Close the cylinder valves.

WARNING

Damage of materials and health risks

Never switch off fresh-gas flow before the vaporizer is switched off. A vaporizer must never be left switched on without a fresh-gas flow, because high-concentration anesthetic vapor may leak into machine lines and ambient air, causing damage to materials and health risks.



When Fabius GS *premium* is not in use

If Fabius GS *premium* is not used for an extended period:

- Unplug the medical gas hoses from the wall supply points of the central gas supply.
- Close the cylinder valves on the reserve gas cylinders.

NOTE

Leave the Fabius GS *premium* plugged into mains power in order to charge the battery.

Preparing for Storage or Transport


WARNING





When moving the anesthesia workstation, remove all monitors and equipment from the top shelf and hinged arms, remove the absorber system, vaporizers, and reserve gas cylinders, push in the writing tray.

The anesthesia workstation should only be moved by people who are physically capable of handling its weight. Dräger recommends that two people move the anesthesia workstation to aid in maneuverability.


Exercise special care so that the machine does not tip when moving up or down inclines, around corners, and across thresholds (for example, in door frames and elevators). Do not attempt to pull the machine over any hoses, cords, or other obstacles on the floor.

1 Press and confirm the »« key (**Standby**). Monitoring and alarms are turned off and the ventilator stops.

- Turn vaporizers off by turning the handwheel to »0« until the button engages.
 - Turn off fresh-gas flow.
 - Close the cylinder valves.
 - Remove the O₂ sensor from the inspiratory valve and leave it exposed to air. This precaution prolongs the service life of the sensor.
- 2 Switch off system power using the switch on the back of the machine, and disconnect the power plug.
- Disconnect the scavenger hoses.



- 1 Remove the pipeline supply hoses from the central supply.
- Press the O₂ flush to depressurize the entire system.





This page intentionally left blank

Monitoring

Main Screen	104
Alarms	104
Alarm Indication	104
Sorting of displayed alarms	105
Example of audible alarm notification in the event of several alarms.	105
Silencing Alarms	106
Disabling Volume Alarms	106
Setting Alarm Limits	107
Oxygen Monitoring	108
Oxygen Monitoring Window	108
Setting Oxygen Monitoring Alarm Limits	108
Calibrating the Oxygen Sensor	109
Consequences of Incorrect O ₂ Calibration ...	111
O₂ Low Supply Alarm	112
Respiratory Volume Monitoring	113
Respiratory Volume Monitoring Window	113
Volume Monitoring Alarms	114
Setting Minute Volume Alarm Limits	114
Disabling Volume Alarms	114
Breathing Pressure Monitoring	115
Breathing Pressure Monitoring Windows ...	115
Breathing Pressure Monitoring Alarms	116
Setting Pressure High and Threshold Alarm Limits	116

Main Screen

1 To display the main screen at any time, press the »« key (**Home**).
The Fabius GS *premium* main screen displays current alarms, oxygen monitoring, breathing pressure monitoring, and respiratory volume monitoring information.



Alarms

Fabius GS *premium* alarms are organized into three categories based on urgency:

- **Warning:** highest priority alarm, requiring immediate response
- **Caution:** medium priority alarm, requiring prompt action
- **Advisory:** low priority alarm/message that must be noted and action taken if necessary

Alarm Indication

The priority of Alarms is indicated to the user in three ways:

- a message appears in the alarm window
- an LED indicator (2) lights up
- an acoustic tone or sequence of tones is annunciated

The table to the right summarizes the specific way each type of alarm is indicated.

The alarm messages are only displayed on colored background if the option "Color display" is enabled.

Alarm	Indication
Warning	<ul style="list-style-type: none">– warning message appears in red in alarm window, followed by three exclamation marks (!!!)– red LED alarm indicator (2) blinks– alarm tone sequence (of five beeps repeated two times) sounds every 10 seconds– red LED flashes, accompanied by a repetitive tone sequence. Tone sequence Standard: E-E-E--E-Bb----E-E-E--E-Bb
Caution	<ul style="list-style-type: none">– caution message appears in yellow in alarm window, followed by two exclamation marks (!!)– yellow LED alarm indicator (2) blinks– alarm tone sequence (of three beeps) sounds every 30 seconds– yellow LED flashes, accompanied by a repetitive 3-tone sequence. Tone sequence Standard: G-G-between G# and A
Advisory	<ul style="list-style-type: none">– advisory message appears in alarm window, followed by an exclamation mark (!)– yellow LED alarm indicator (2) lights continuously– yellow LED illuminates continuously, accompanied by single 2-tone sequence. Tone sequence Standard: E-E" <p>with internal Priority ≥6:</p> <ul style="list-style-type: none">– a 2 tone sounds <p>with internal Priority <6:</p> <ul style="list-style-type: none">– no tone sounds

Sorting of displayed alarms

The alarms are sorted according to these categories. In the categories, the alarms are sorted and displayed according to the internal priority system. Priority 31 means the highest and priority 1 the lowest priority. The priority numbers are shown in the table "Fault-Cause-Remedy" on page 150.

A maximum of four alarms can be displayed in a list at the same time. High-priority alarms are displayed before low-priority alarms. Low-priority alarms are sometimes only displayed after the cause for a high-priority alarm has been remedied.

Example of audible alarm notification in the event of several alarms.


If an alarm with the category Warning is currently active and a new alarm with the category Warning is generated, the alarm sequence starts again by issuing an alarm with the same priority.


If alarm with the category Caution is also generated, no new audible alarm is issued. The Warning alarm notification is not interrupted because it has a higher priority.

If an alarm with the category Caution is currently active and a new alarm with the category Caution is generated, the alarm sequence starts again by issuing an alarm with the same priority.


If an alarm with the category Caution is active and an alarm with the category Warning is generated, the alarm sequence is started for the warning because the warning is assigned the highest priority.


Silencing Alarms

- 1 Press the »  « key (**Silence**) to silence all active audible alarms for two minutes. The yellow LED lights up.

The symbol »  « appears in the status bar with an indication of the silence time remaining.


To enable the alarm tone:

- 1 Press the »  « key (**Silence**), the yellow LED turns off.





566

Disabling Volume Alarms

Visual and audible volume alarms can be turned on or off during operation using the »  « key (**Setup**). See "Volume Alarms On/Off" on page 139.

Setting Alarm Limits


- To set the default alarm limits that take effect at machine power-up, see page 127.
- 1 To set alarm limits for the current procedure, press the »  « key (**Alarms**).









- 2 The alarm limits window is displayed on the screen.

The lower pressure limit **Paw low** is used for pressure monitoring to detect apneas (disconnection) and continuous pressure (on the screen represented as a dotted line). An alarm is generated when the pressure curve does not cross the pressure threshold either from above or below.

- Select the alarm limit value that needs to change.
- Confirm the alarm limit value and select a new value.
- Confirm the new value for the alarm limit. The new alarm limit is saved and the cursor moves to the return arrow.



The adjustment range and factory default values for all alarms on the Fabius GS *premium* are shown in the following table.

Alarm Parameter		Adjustment Range	Factory Default Value
O2 %	 	19 to 100 18 to 99	100 20
MV L/min	 	0.1 to 20.0 0.0 to 19.9	12.0 3.0
Pressure cmH2O (hPa)	 	10 to 70 5 to 30	40 8

Oxygen Monitoring

Inspiratory oxygen concentration is measured with a dual galvanic cell sensor, which is attached to the inspiratory valve dome. The sensor contains two independent electrochemical cells, or sensor halves. When the sensor is exposed to oxygen, an electrochemical reaction occurs within each cell. The oxygen monitor measures the current produced in each cell, computes an average for the two cells, and translates the average into an oxygen concentration measurement.

CAUTION

Risk of inaccurate measuring values

Never remove an oxygen sensor from its housing, except to replace it. If a sensor is removed from its housing, you must do the following before continuing normal operations:

– Reinstall the sensor in the housing.

– Calibrate the sensor.

NOTE

When the machine is not in use, remove the oxygen sensor assembly from the inspiratory valve dome, and insert the valve dome plug into the dome.


Oxygen Monitoring Window

The oxygen monitoring window shows the following information:

- 1 numerical value for inspiratory oxygen concentration in percent (%) within the range of 10 % to 100 %
- 2 high oxygen concentration alarm limit
- 3 low oxygen concentration alarm limit

Setting Oxygen Monitoring Alarm Limits

Follow the procedure "Setting Alarm Limits" on page 107 to change the high or low alarm limit.




Calibrating the Oxygen Sensor



To calibrate the oxygen sensor correctly, make sure it is exposed only to room air during the entire calibration period. The oxygen sensor should be calibrated as part of the daily preoperative setup of the anesthesia equipment.

The oxygen sensor can be calibrated during Standby as described in "Calibrate O2 Sensor" on page 121.

To avoid leakage, remove the oxygen sensor assembly from the inspiratory valve dome, and insert the valve dome plug into the dome.

To calibrate the oxygen during operation, follow the procedure below:

- 1 Press the »« key (**Setup**) on the front panel. The Setup window appears at the bottom of the screen.
- 2 Press the »**Calibrate O2 Sensor**« soft key.




- 3 The calibration instruction window replaces the Setup window. Follow the directions provided.

1. Remove O2 sensor and expose to room air for 2 minutes
2. To start O2 Calibration press rotary knob
3. Observe Calibration status in O2 data window
4. Reinsert O2 Sensor after successful Calibration

3

1 During the calibration period, the word »CAL« replaces the O2 value in the oxygen monitoring window. Upon successful completion of the calibration, the O2 measurement value will be restored.



If, at the end of the calibration period, the »O2 SENSOR FAIL!« Advisory message appears in the Alarm window, the calibration was not successful.

An unsuccessful calibration can be caused by several conditions as described in the following table.

Cause	Remedy
Sensor was exposed to an excessively lean or excessively rich oxygen calibration mixture.	Make sure that the sensor is exposed to room air for the entire calibration period.
Sensor was exposed to a constantly changing calibration mixture.	Make sure that the sensor is exposed to room air for the entire calibration period.
Sensor did not receive the proper waiting period.	If the sensor capsule was removed from the sensor assembly, a waiting period equal to the time that the capsule spent outside the sensor assembly is necessary prior to calibration. New sensors require a 15-minute waiting period.
Sensor is exhausted.	If the oxygen sensor has decayed beyond its useful service life (see the "Specifications" section of the manual), replace the exhausted sensor with a new sensor and allow the proper waiting period.
Sensor is disconnected.	When the sensor is disconnected or if there is no cell in the housing, the display area is blank, and the message »O2 SENSOR FAIL!« appears in the Alarm window. If this happens, ensure that the sensor is correctly assembled and recalibrate the oxygen sensor.


Consequences of Incorrect O₂ Calibration

If the oxygen sensor is improperly calibrated, it can cause inaccurate measurements. When a calibration gas mixture is excessively rich or lean in oxygen, the Fabius GS *premium* will not complete an attempted calibration; however, if the calibration gas is rich or lean but is within certain limits, the Fabius GS *premium* will complete the calibration. As a result, when displaying sensor measurements, the Fabius GS *premium* displays an oxygen percentage either higher or lower than the actual oxygen percentage. Therefore, make sure that the sensor is exposed only to room air during the entire calibration period.

The figure illustrates the relationship between the calibration mixture and the accuracy of oxygen measurement.

A Displayed O₂ Percentage
B Actual O₂ Percentage

- 1** At calibration, sensor exposed to <21 % O₂. Thus, displayed % O₂ will be higher than actual O₂.
- 2** Correct calibration of room air (21 % O₂) for entire calibration period. Displayed % O₂ = actual % O₂.
- 3** At calibration, sensor exposed to >21 % O₂. Thus, displayed % O₂ will be lower than actual % O₂.




O₂ Low Supply Alarm

If the O₂ pipeline supply pressure drops below the minimum pressure permitted (approximately 20 psi or 1.4 kPa x 100) an additional

»**O₂ SUPPLY LOW**« alarm is generated and the LED (1) starts blinking.

If the alarm occurs in Standby mode and the user changes to a ventilation mode, a continuous alarm tone sounds for seven seconds.



Respiratory Volume Monitoring

Respiratory volume is measured using thermal anemometry. The flow sensor output is converted into meaningful readings for minute volume, tidal volume, and respiratory rate displays.

CAUTION

The functioning of the respiratory volume monitor may be adversely affected by the operation of electrosurgical equipment or short wave or micro-wave diathermy equipment in the vicinity.


NOTE

Sudden, irregular expiratory flow may cause erratic tidal volume and respiratory rate displays. To avoid such erroneous measurements, defer reading the display until a full minute has elapsed after the irregular flow has stopped.


Respiratory Volume Monitoring Window

The respiratory volume monitoring window shows the following information:

- 1 Frequency (Freq) shows the number of breaths during the previous minute of respiration in units of Breaths Per Minute (bpm) (1/min). Readings appear after two breaths. The display range is from 2 bpm (1/min) to 99 bpm (1/min).
- 2 Tidal Volume Measurement (VT) displays the expired volume for each breath in units of milliliters (mL). The display range is from 0 mL to 1400 mL.
- 3 Minute Volume Measurement (MV) continuously displays the volume of exhaled gas accumulated during the previous minute of respiration in units of liters/minute (L/min). The display range is from 0.0 L/min to 99.9 L/min.



- 1 Minute Volume Alarm High Limit indicates the volume above which an alarm condition occurs (L/min).
- 2 Minute Volume Alarm Low Limit indicates the volume below which an alarm condition occurs (L/min).



Volume Monitoring Alarms


While the ventilator is on and the volume alarms are enabled, apnea alarms are generated if the respiratory volume monitor does not sense a valid breath for a specified period (see »APNEA FLOW« on page 150).

While the ventilator is off and the system is in ManSpont mode, these alarms are generated at 30 seconds (Caution) and 60 seconds (Warning). The Fabius GS *premium*'s volume alarms are automatically enabled when the ventilator is switched from Standby to a ventilation mode.

Setting Minute Volume Alarm Limits

Follow the procedure "Setting Alarm Limits" on page 107 to change the high or low alarm limit.

Disabling Volume Alarms

Visual and audible volume alarms can be turned on or off during operation using the »« key (**Setup**). See "Volume Alarms On/Off" on page 139.

Breathing Pressure Monitoring


Breathing Pressure Monitoring Windows

The breathing pressure monitoring windows show the following breathing pressure information in numeric and graphic form:

NOTE

The Fabius GS *premium* can be configured by DrägerService or your local authorized service organization to display mean pressure (MEAN) instead of plateau pressure (PLAT).

- 1 **PEEP** (Positive End Expiratory Pressure) shows the breathing pressure at the end of exhalation in cmH₂O (hPa). The display range is from 0 to 30 cmH₂O (0 to 30 hPa).
- 2 **PLAT** (Plateau) Breathing Pressure shows the breathing pressure at the end of inspiration in cmH₂O (hPa). The display range is from 0 to 80 cmH₂O (0 to 80 hPa) or
- 2 **MEAN** Breathing Pressure shows the average of all the instantaneous pressure values recorded during each breath in cmH₂O (hPa). The display range is from 0 to 50 cmH₂O (0 to 50 hPa).
- 3 **PEAK** Breathing Pressure shows the highest instantaneous pressure value for each breath in cmH₂O (hPa). The display range is from 0 to 80 cmH₂O (0 to 80 hPa).
- 4 Pressure High Alarm Limit.
- 5 Pressure Threshold Alarm Limit.
- 6 Breathing Pressure Trace Window displays a breathing pressure trace (waveform).
- 7 Breathing Pressure Threshold Limit Line.
- 8 Breathing Pressure Minimum and Maximum Trace Scale Limits Indicator. Pressure measurements are automatically scaled from 0 to 20, 0 to 50, or 0 to 100 cmH₂O (0 to 20, 0 to 50, or 0 to 100 hPa).



Breathing Pressure Monitoring Alarms

While the ventilator is on, apnea pressure alarms are generated if the breathing pressure monitor does not sense a valid breath for a specified period of time (see »**APNEA PRESSURE**« on page 150). While the ventilator is off and the system is in ManSpont mode, these alarms are generated at 30 seconds (Caution) and 60 seconds (Warning).

Setting Pressure High and Threshold Alarm Limits

Follow the procedure "Setting Alarm Limits" on page 107 to change the breathing pressure high or threshold alarm limit.

NOTE

The pressure threshold alarm limit should be as close as possible to the sensed plateau pressure without exceeding it, approximately 4 cmH₂O (hPa) below the plateau pressure.

Configuration

Configuration Functions in Standby Mode 118

Sleep Mode	119
Run System Test	119
Calibrate Flow Sensor	120
Calibrate O ₂ Sensor	121
Leak/Compliance Test	122
Access Alarm Log	125
Restore Site Defaults	125
Standby Setup Screen	126
Default Settings in Standby Setup	127
Configuration in Standby Setup	133

Configuration during Operation 138


Volume Alarms On/Off	139
Auto Set	139
Calibrate O ₂ Sensor	140
Des Comp On/Off	141
Automatic Desflurane Compensation	143
Access Alarm Log	144
Access Alarm Volume	144

Configuration Functions in Standby Mode

The configuration functions available in Standby include calibrations, system tests, and the management of default settings.


To access Standby mode:

- 1 Press the »⏻« key (Standby).




The waveform window is replaced by a confirmation message and the instruction to shut off flow. The LED on the Standby key starts blinking and will remain blinking until Standby is confirmed.

NOTE
If confirmation does not occur within 15 seconds, the ventilator remains in the previous mode and the waveform window is restored.




- Confirm the mode change. The ventilator enters Standby mode, the Standby screen replaces the previous screen, and the Standby LED stops blinking and remains on.
The following soft key labels appear at the bottom of the Standby screen:
 - »Run System Test«
 - »Calibrate Flow Sensor«
 - »Calibrate O2 Sensor«
 - »Leak/Compl Test«
 - »Access Alarm Log«
 - »Restore Site Defaults«
- Turn off fresh-gas flow.



NOTE


If the flow control valves were not shut off before entering Standby mode, a »**Gas still flowing**« message appears on the Standby screen. The message will disappear once the flow is turned off.

**Sleep Mode**

If 2.5 minutes elapse in Standby mode with no user input, Sleep mode is activated. The monitor screen is replaced by the screen saver. The screen saver displays a message that provides instructions on how to activate Standby mode.


**Run System Test**

- 1 Press the »**Run System Test**« key. This test performs the power-up diagnostic tests (as described in "Power-Up Standby Screen" on page 74). Pressing this key restores the site defaults.



The test results are posted on the screen. Following successful completion, the system returns to the Standby screen.

This System Test checks the functionality of the electronics of the system.



Calibrate Flow Sensor

- Press the »**Calibrate Flow Sensor**« key on the Standby screen. The Standby soft key window is replaced by instructions for performing the calibration.
- Follow the instructions on the screen:
 - Close all fresh-gas control valves.
 - Remove expiratory hose from breathing system.
 - To start Flow Sensor Calibration press rotary knob.
- When the calibration begins, the instructions are removed, and a »**Flow Calibration in progress**« message is displayed above the Standby soft keys.
- When the calibration is completed, one of two messages is posted above the Standby soft keys: »**Flow Calibration completed – reconnect expiratory hose**« or »**Flow Calibration Failed**«.

Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

525

1. Close all fresh gas control valves
2. Remove expiratory hose from breathing system
3. To start Flow Sensor Calibration press rotary knob

526

Flow Calibration in progress					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

526

Flow Calibration completed - reconnect expiratory hose					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

527

Troubleshooting Flow Calibration Failure

If the flow sensor cannot be calibrated, retry the calibration.

If the flow sensor still cannot be calibrated, call DrägerService or your local authorized service organization.

Flow Calibration Failed					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

528

Calibrate O2 Sensor

- Press the »**Calibrate O2 Sensor**« key on the Standby screen. The Standby soft key window is replaced by instructions for performing the calibration.
- Follow the instructions on the screen:
 - Remove O2 sensor and expose to room air for 2 minutes.
 - To start O2 Calibration press rotary knob.

Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

1. Remove O2 sensor and expose to room air for 2 minutes
2. To start O2 Calibration press rotary knob

- When the calibration begins, the instructions are removed, and a »**O2 Calibration in progress**« message is displayed above the Standby soft keys.

O2 Calibration in progress					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

- When the calibration is completed, one of two messages is posted above the Standby soft keys: »**O2 Sensor Calibration completed – reinsert O2 sensor**« or »**O2 Sensor Calibration Failed**«.

O2 Sensor Calibration completed - reinsert O2 sensor					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults

Troubleshooting O2 Sensor Calibration Failure

If the O2 sensor cannot be calibrated, replace the O2 capsule in the O2 sensor housing (see page 179).


If the O2 sensor still cannot be calibrated, call DrägerService or your local authorized service organization.

O2 Sensor Calibration Failed					
Run	Calibrate	Calibrate	Leak /	Access	Restore
System	Flow	O2	Compl	Alarm	Site
Test	Sensor	Sensor	Test	Log	Defaults



Leak/Compliance Test

The »Leak/Compl Test« key is used to initiate a system compliance test, a system leak test, a ventilator leak test, and a safety relief valves test.


- 1 Press the »Leak/Compl Test« key on the Standby screen. The Standby soft key window is replaced by a ventilator preparation message and then instructions for performing the test.



- Follow the instructions on the screen:
 - Close all fresh-gas control valves.
 - Place Y-piece on plug located on bag mount.
 - Seal sample-line connector (if applicable).
 - Switch APL valve to “MAN” and set pressure to 40 to 50.
 - Press O2 flush button, build up a pressure of 15 to 30.



- Upon completion of the test, the results are posted on the screen.
- Press the rotary knob to return to the Standby screen.




Compliance Test Results

The system compliance test determines the current compliance of the patient system with any filters, hoses, and Y-piece. The compliance value is used during volume-controlled ventilation for applying a tidal volume matching accurately the set tidal volume. A system compliance value of up to 6.5 mL/cmH₂O (6.5 mL/hPa) is posted as »**PASSED**« on the leak test result screen, and the compliance value is also displayed on the Standby screen.

Ventilator Leak Test Results

If a ventilator leak test is posted as »**PASSED**«, the value is displayed on the leak test result screen and the Standby screen.

Measured ventilator leak [mL/min]	Displayed result [mL/min]
≤150	measured value and PASSED
151 to 250	measured value and FAILED
>250	>250 and FAILED




116

System Leak Test Results

System leak test results are posted on the leak test result screen.

Measured system leak [mL/min]	Displayed result [mL/min]
≤250	measured value and PASSED
251 to 350	measured value and FAILED
>350	>350 and FAILED



115

Safety Relief Valves Test

CAUTION

The high pressure safety relief valve (80 cmH₂O (hPa)) is tested during the leak test. The test result is posted on the leak test result screen. In case the test has failed, the machine is conditionally functional. The valve may not be able to relieve an unexpected high pressure.

- Clean the valve or activate the valve manually, and repeat the leak test.

If the test fails again

- Contact DrägerService.

Possible Causes of Leaks

If the leak tests fail, check the following components of the breathing system, and repeat the leak test.

- damaged breathing hoses
- gas sample line fitting not plugged
- breathing bag/diaphragm defective
- vaporizer not connected correctly or filling device open
- absorber canister not firmly mounted in place
- flow sensor not installed properly
- breathing system not assembled and installed correctly
- microbial filters not connected securely
- breathing bag arm not tight or defective



Access Alarm Log

- 1 Press the »Access Alarm Log« key on the Standby screen. The Standby soft key window is replaced by the alarm log, which lists all alarms with their dates and times.

- To scroll through the alarm log, turn the rotary knob.
- To delete all alarms from the log, select and confirm the »Clear Alarm Log« label.
- To exit the alarm log and return to the Standby screen, select and confirm the return arrow.

CAUTION

Alarm log data is deleted if Fabius GS *premium* is switched off or a total loss of electrical power supply occurs.





Restore Site Defaults

- 2 Press the »Restore Site Defaults« key on the Standby screen. The predefined site defaults are restored, and a »Site Default settings restored« message is displayed above the Standby soft keys.

The site default settings are password protected. Changes of the settings can be made via the Standby Setup screen (see page 126).

WARNING


Risk of inappropriate ventilation settings
After site default settings have been restored check whether the ventilation and monitoring settings are appropriate to the patient.



Standby Setup Screen


Pressing the Setup key while in Standby provides access to various default and configuration settings. The settings made in this screen will be saved as Site Defaults.

In order for these settings to go into effect, press the »**Restore Site Defaults**« key on the Standby screen. The Site Defaults are also restored any time power is cycled or the system test is performed (see page 119).

- 1 Press the »« key (**Setup**) while in Standby mode.

The operator is requested to enter a four-digit password in order to prevent unauthorized changes to the basic functions. This password is allocated when commissioning the workstation. If desired, DrägerService can set an individual password or disable this functionality.

- Select and confirm the figures successively from the line displayed using the rotary knob.
- The Standby Setup screen replaces the Standby screen. The cursor allows the user to select »**Default Settings**« (see below) or »**Configuration**« (see page 133). (Selecting and confirming the return arrow on the right of the Setup screen will exit the Standby Setup screen and redisplay the Standby screen.)



554

Standby Setup		
Default Settings	Configuration	Hone →
Exit →	Exit →	
Volume Settings	Time Set	
Pressure Settings	Time Format	
Pressure Support Settings	Date Set	
SIMU/PS Settings	Date Format	
Alarm Limits	Acoustic Confirmation	
Alarm Volume	Alarm Tone Sequence	
Restore Factory Defaults	Waveform Display	
	Display Background	


504

Default Settings in Standby Setup

- Select and confirm the »**Default Settings**« label on the Standby Setup screen. (Selecting and confirming the return arrow will exit the Default Settings column and redisplay the main Setup screen.)


The following settings are available under Default Settings:

- »**Volume Settings**«
- »**Pressure Settings**«
- »**Pressure Support Settings**«
- »**SIMV/PS Settings**«
- »**Alarm Limits**«
- »**Alarm Volume**«
- »**Restore Factory Defaults**«




Volume Settings

- Select and confirm the »**Volume Settings**« label on the Standby Setup screen. The Default Volume Settings window appears at the bottom of the screen.



- Press the soft key for the parameter that needs to be changed (»**P_{MAX}**« in the example illustration). The key becomes highlighted.
- Select a new **P_{MAX}** value (in the example illustration, the value was changed from 40 to 50), and confirm as instructed by the message displayed above the soft keys.
- If necessary, repeat the process for the other Volume Settings parameters.




- When all Volume Settings parameters are set to desired values, confirm the default Volume Settings as instructed by the message displayed above the soft keys.

The Default Volume Settings window is then removed from the screen, and the cursor returns to the return arrow.

Pressure Settings, Pressure Support Settings, and SIMV/PS Settings

Use the procedure described in "Volume Settings" to change the parameters associated with these ventilator modes.




Alarm Limits


- Select and confirm the »Alarm Limits« label on the Standby Setup screen. The Default Alarm Limits window appears.

NOTE


Set the alarm limits to appropriate values.



- Select the alarm limit value that needs to change.



- Confirm the alarm limit value and select a new value. (In the example illustration, the O2 alarm limit was changed from »20« to »25«.)
- Confirm the new value for the O2 alarm limit. The new alarm limit is saved and cursor moves to the return arrow.
- If necessary, repeat the process for the other parameter alarm limits.




The adjustment range and factory default values for all alarms on the Fabius GS *premium* are shown in the following table.

Alarm Parameter		Adjustment Range	Factory Default Value
O2	/▲	19 to 100	100
%	▼/	18 to 99	20
MV	/▲	0.1 to 20.0	12.0
L/min	▼/	0.0 to 19.9	3.0
Pressure	/▲	10 to 70	40
cmH2O	▼/	5 to 30	8
(hPa)			

Alarm Volume


- Select and confirm the »Alarm Volume« label on the Standby Setup screen. The current alarm volume value appears on the screen.



- Select and confirm the new alarm volume value from 1 (minimum) to 10 (maximum) (range: >45 dB(A) to <85 dB(A)).

In the example illustration, the value was changed from »4« to »5«.

The Alarm Volume Setting window is then removed from the screen, and the cursor returns to the return arrow.




Current settings

The current settings can not be saved as default settings.

To change the site defaults follow the instructions on page 126.

Restore Factory Defaults

- Select and confirm the »**Restore Factory Defaults**« label on the Standby Setup screen. The Restore Factory Default setting window appears on the screen.
- Select and confirm »**Yes**« or »**No**«. When »**Yes**« is selected, the factory defaults are restored and replace the current default settings.



The factory defaults for the Fabius GS *premium* are shown in the table below:

Parameter	Factory Default Settings
Volume Control	P _{MAX} = 40 V _T = 600 Freq = 12 T _I :T _E = 1:2.0 T _{IP} :T _I = 10 PEEP = 0
Pressure Control	P _{INSP} = 15 Freq = 12 T _I :T _E = 1:2.0 Insp Flow = 30 PEEP = 0
Pressure Support	ΔP _{PS} = 10 Freq Min = 3 Trigger = 2 Insp Flow = 30 PEEP = 0


Parameter	Factory Default Settings
SIMV/PS	$P_{MAX} = 40$ $V_T = 600$ $Freq = 12$ $\Delta P_{PS} = 10$ $PEEP = 0$ $Trigger = 2$ $Insp\ Flow = 30$ $T_{INSP} = 1.7$ $T_{IP}:T_I = 10$
Alarm Default Settings for O ₂	$High = 100$ $Low = 20$
Alarm Default Settings for MV	$High = 12.0$ $Low = 3.0$
Alarm Default Settings for Pressure	$High = 40$ $Low = 8$
Alarm Audio Volume	Volume level = 5

Configuration in Standby Setup

- Select and confirm the »**Configuration**« label on the Standby Setup screen. (Selecting and confirming the return arrow will exit the Configuration column and redisplay the main Setup screen.)


The following settings are available under Configuration:

- »**Time Set**«
- »**Time Format**«
- »**Date Set**«
- »**Date Format**«
- »**Acoustic Confirmation**«
- »**Alarm Tone Sequence**«
- »**Waveform Display**«
- »**Display Background**«




Time Set

- Select and confirm the »Time Set« label on the Standby Setup screen. The cursor appears over the hour field.




- Select and confirm a new hour time value (in the example illustration, the hour was changed from »13« to »20«). The cursor moves to the minutes field.




- Select and confirm a new minute time value (in the example illustration, the value was changed from »15« to »30«).

The new time values are saved, the Time Set window is removed from the screen, and the cursor returns to the Time Set label.




Time Format

- Select and confirm the »**Time Format**« label on the Standby Setup screen. The Time Format window appears next to the label.



- Select and confirm the new time format value (in the example illustration, the value was changed from »**24 Hour**« to »**AM/PM**«).


The new time format value is saved, the Time Format window is removed from the screen, and the cursor returns to the »**Time Format**« label.



Date Set

The values that can be selected are two-digit numerical values for day, month, and year.


Use the procedure described in "Time Set" on page 134 to change the date parameter.



Date Format

The values that can be selected for the date format are »MM-DD-YY« or »DD-MM-YY«.

Use the procedure described in "Time Format" on page 135 to change the date format parameter.




549

Acoustic Confirmation

The values that can be selected for the acoustic confirmation are »On« or »Off«.

If »On« is selected, an acoustic confirmation is annunciated every time that the rotary knob is pressed.

Use the procedure described in "Time Format" on page 135 to change the acoustic confirmation parameter.




550

Alarm Tone Sequence

The values that can be selected for the alarm tone sequence are »Standard« or »Dräger«.

Use the procedure described in "Time Format" on page 135 to change the alarm tone sequence parameter.




551


Waveform Display

The values that can be selected for the waveform display are »**Normal**« or »**Filled**«.

Use the procedure described in "Time Format" on page 135 to change the waveform display parameter.




If »**Normal**« is selected, the waveform is not filled with a solid pattern, but appears as a line, as shown in the example illustration.



Display Background (only available with optional color screen)

The values that can be selected for the display background are »**Dark**« or »**Light**«.

Use the procedure described in "Time Format" on page 135 to change the display background parameter.




Configuration during Operation


The user can perform O2 calibrations and view and change certain monitoring settings for the current operation while in Volume Control, Pressure Control, Pressure Support, SIMV/PS, and ManSpont mode.

NOTE
To set default monitoring settings to be used at the power-up of each operation, see "Standby Setup Screen" on page 126.

- 1 Press the »[Menu]« key (**Setup**) while in Volume Control, Pressure Control, Pressure Support, SIMV/PS, or ManSpont mode.



- The Setup window replaces the waveform and soft keys for the current ventilator mode.
- The following soft key labels appear in the Setup window:
- »Volume Alarms On/Off«
 - »Auto Set«
 - »Calibrate O2 Sensor«
 - »Des Comp On/Off«
 - »Access Alarm Log«
 - »Access Alarm Volume«



There is a 15-second timeout period for any of the Setup functions during operation. If no rotary knob activity occurs within 15 seconds, the Setup window is removed and the waveform window is redisplayed. The waveform window can be also be displayed by pressing the »[Home]« key (**Home**).

Volume Alarms On/Off

- 1 Press the **»Volume Alarms On«** soft key in the Setup window. The key label changes from **»Volume Alarms On«** to **»Volume Alarms Off«**, and the volume alarms are disabled.

NOTE

The **»Volume Alarms On/Off«** soft key label does not appear in ManSpont mode because it is selectable on the ManSpont screen.

Auto Set

- 2 Press the **»Auto Set«** soft key in the Setup window. The breathing pressure threshold is set to 4 cmH₂O (hPa) below the current plateau pressure data value.

NOTE


The threshold setting may not be less than 5 cmH₂O (5 hPa) or greater than 30 cmH₂O (30 hPa).

NOTE

In the absence of a current plateau pressure data value, pressing the soft key will have no effect.

NOTE

In SIMV/PS mode, the breathing pressure threshold will be set relative to the mandatory ventilation stroke.




Calibrate O2 Sensor

To calibrate the oxygen sensor correctly, make sure it is exposed only to room air during the entire calibration period.

To avoid leakage, remove the oxygen sensor assembly from the inspiratory valve dome, and insert the valve dome plug into the dome.

- 1 Press the »Calibrate O2 Sensor« soft key in the Setup window.




- The calibration instruction window replaces the Setup window. Follow the directions provided:
 - Remove O2 sensor and expose to room air for 2 minutes.
 - To start O2 Calibration press rotary knob.
 - Observe Calibration status in O2 data window.
 - Reinsert O2 sensor after successful Calibration.

1. Remove O2 sensor and expose to room air for 2 minutes
2. To start O2 Calibration press rotary knob
3. Observe Calibration status in O2 data window
4. Reinsert O2 Sensor after successful Calibration

- 1 During the calibration period, the word "**CAL**" replaces the O₂ value in the oxygen monitoring window. Calibration time is approximately 15 seconds. Upon successful completion of the calibration, the O₂ measurement value will be restored.

If the O₂ sensor cannot be calibrated, replace the O₂ capsule in the O₂ sensor housing (see page 179).


If the O₂ sensor still cannot be calibrated, call DrägerService or your local authorized service organization.



Des Comp On/Off

This parameter is used to activate or deactivate desflurane compensation.

- 2 Press the »Des Comp Off« soft key in the Setup window. The key label changes from »Des Comp Off« to »Des Comp On«, and desflurane compensation is activated.



- 1 The message »Des on« appears in the status bar when desflurane compensation is activated.

CAUTION

Ensure that Desflurane compensation is only activated whenever Desflurane is used. Failure to activate when Desflurane is used will affect measured volume accuracy. Activating when Desflurane is not used will affect measured volume accuracy.

CAUTION


The Fabius GS *premium* will automatically compensate for Desflurane when agent concentration data is available through communication with an external agent analyzer. Inaccurate data from the analyzer may affect measured volume accuracy.

CAUTION

Desflurane has characteristics that affect the sensitivity of the Fabius GS *premium* flow sensor. To help assure that the volume measurements from the monitor are accurate, activate Desflurane compensation when Desflurane is used in the breathing circuit. The Fabius GS *premium* will automatically compensate for the change in flow measurement characteristics caused by using Desflurane.

NOTE

If Desflurane concentration data is communicated to the Fabius GS *premium* by an external agent analyzer, the Fabius GS *premium* will automatically perform the corresponding flow compensation. In this case, the communicated data always overrides the functionality of the Desflurane compensation soft key.




Automatic Desflurane Compensation

If Desflurane concentration data is communicated to the Fabius GS *premium* by an external agent analyzer, the following occurs:

- 1 **Des auto** appears in the status bar at the top of the screen
- 2 the »**Des Comp On/Off**« soft key label is removed
- the Fabius GS *premium* will automatically perform the corresponding flow sensor compensation.

Automatic Desflurane compensation always overrides the functionality of the Desflurane compensation soft key.



If communication is disconnected or lost between the Fabius GS *premium* and an external agent analyzer while Desflurane is in use:


- The **Des auto** message is removed from the status bar.
- The »**Des Comp On/Off**« soft key label reappears as »**Des Comp Off**«.

To maintain Desflurane compensation, manually activate Desflurane compensation to ensure accurate volume measurements.

Access Alarm Log

1 Press the »Access Alarm Log« key in the Setup window. The Setup window is replaced by the alarm log, which lists all alarms with their dates and times.


- To scroll through the alarm log, turn the rotary knob.
- To delete all alarms from the log, select and confirm the »Clear Alarm Log« label.
- To exit the alarm log and return to the Setup window, select and confirm the return arrow.



Access Alarm Volume

2 Press the »Access Alarm Volume« key in the Setup window.

- The Setup window is replaced by the Alarm Volume Setting window.
 - Select and confirm a new alarm volume value in the range of 1 (minimum) to 10 (maximum).
- The value is saved and the Alarm Volume Setting window is replaced by the Setup window.



Fault-Cause-Remedy

Power Failure Backup 146

Ventilator Fail State 148


Overriding the Ventilator 148

Fault-Cause-Remedy 150

Power Failure Backup

When AC power is interrupted from the Fabius GS *premium*, the internal battery backup will provide full operation of the ventilator and internal monitors for up to two hours after the power interruption. The battery depletion rate depends upon ventilator settings and the condition of the battery (age and level of charge), but under no circumstances should a fully charged battery provide less than 45 minutes of full functionality.

The transition to battery-powered operation will not interrupt any machine functions. At the transition, and as the battery is discharged, the following information will be displayed:

- The battery symbol () appears in the status bar and the Mains Power LED turns off.
- The »**POWER FAIL!**« Advisory alarm message is displayed in the alarm window.
- When the battery is discharged to 20 % of its reserve power, the »**BATTERY LOW!**« Advisory alarm message is displayed in the alarm window.
- When the battery is discharged to 10 % of its reserve power, the »**BATTERY LOW!!**« Caution alarm message replaces the Advisory alarm message in the alarm window.
- When the battery is almost fully discharged, the ventilator will stop and the Ventilator Fail Warning alarm message (»**VENTILATOR FAIL!!!**«) is displayed in the alarm window.
- If manual ventilation is not provided, the Apnea Pressure Warning (»**APNEA PRESSURE!!!**«), Apnea Flow Warning (»**APNEA FLOW!!!**«), and Minute Volume Low Caution (»**MINUTE VOLUME LOW!!**«) alarm messages are displayed in the alarm window.
- The internal monitors continue to operate until the battery is completely discharged and all electronics are shut down.

WARNING

When the »BATTERY LOW!!« Caution alarm message is first displayed, the ventilator will continue to operate for up to an additional 10 minutes. Then, automatic ventilation is not available until AC power is restored.

CAUTION

Never allow the battery to completely discharge. If the battery is discharged completely, recharge immediately. Do not use the device until the battery is recharged completely as injury to the patient may occur if the battery is unavailable.

When the battery is completely discharged Fabius GS *premium* switches off. As a consequence all individual settings including alarm limits, which are not saved in the default settings, will be lost.

All pneumatic functions of the Fabius GS *premium* continue to be available (APL valve, breathing pressure gauge, cylinder and pipeline gauges, fresh gas and agent delivery, S-ORC, and O₂, AIR, and N₂O flowmeters). Manual or spontaneous ventilation can be maintained.

When the power supply is recovered and Fabius GS *premium* restarted, all ventilation and alarm settings are reset to the saved default settings.

WARNING

Danger of patient hazard by wrong device or patient settings

Parameters for ventilation or monitoring may be set user-specific.

After restart of the device, check the settings and adapt them to your patient.

Ventilator Fail State

If the Fabius GS *premium* does not recover from a »**VENTILATOR FAIL!!!**« condition:



- Switch to ManSpont mode by pressing the ManSpont key and confirming the mode change by pressing the rotary knob.
- Set the APL valve to MAN position.
- Adjust the APL pressure limit for the desired inspiratory plateau pressure.
- Press the O₂ flush button on the Fabius GS *premium* as required to sufficiently inflate the breathing bag.
- Manually ventilate the patient by squeezing the breathing bag.

NOTE

In the ventilator fail situation, the ventilator piston assembly position may not be locked. As a result, airway pressure may initially push the piston back to its limit stop, increasing the volume of the breathing circuit. It may be necessary to press the O₂ flush button again to reinflate the breathing bag.

Overriding the Ventilator

In the unlikely event of a fault in which the ventilator does not recover, and the user cannot switch to manual ventilation mode through the use of the ManSpont key and rotary knob, manual ventilation is still possible.

- Locate the ON/OFF switch on the rear panel.
- Toggle the ON/OFF switch to "off" () and then
- Toggle the ON/OFF switch back to "on" ().
The ventilator now performs as in ManSpont mode.
- Set the APL valve to MAN position.

- Adjust the APL pressure limit for the desired inspiratory plateau pressure.
- Press the O₂ flush button on the Fabius GS *premium* as required to sufficiently inflate the breathing bag.
- Manually ventilate the patient by squeezing the breathing bag.

NOTE

After toggling the main power switch, the Fabius GS *premium* will perform its diagnostic tests. During the diagnostic tests, manual ventilation is possible. If the diagnostic tests result in **FUNCTIONAL**, the Fabius GS *premium* will automatically switch to ManSpont mode if a fresh-gas flow is detected. Fabius GS *premium* respiratory monitoring is available. If the diagnostic tests result in **NON-FUNCTIONAL**, manual ventilation is still possible but Fabius GS *premium* respiratory monitoring is not available.

NOTE

In ventilator override situation, the ventilator piston position may not be locked, as in ManSpont mode. As a result, airway pressure may push the piston backwards to its limit stop, thus increasing the volume of the breathing circuit. It may be necessary to press the O₂ flush button again to reinflate the breathing bag.

- Contact DrägerService or your local authorized service organization before using the ventilator.

Fault-Cause-Remedy

The Fabius GS *premium* divides alarm messages into three categories based on priority. Exclamation marks indicate the priority. The alarm messages are displayed on colored background if the option "Color display" is enabled:

!!!	Warning (red)	high priority
!!	Caution (yellow)	medium priority
!	Advisory (white)	low priority

Internal priority numbers, see page 105, for the ranking within an alarm category are written below in brackets, e.g. (23 / 31).

Priority	Alarm Message	Probable Cause	Remedy
!!! (31)	AIRWAY PRESSURE HIGH	Upper alarm limit for airway pressure has been exceeded, ventilation hose is kinked. Alarm limit has been set too low.	Check hose system on anesthesia workstation. Check breathing circuit or alarm limit value.
!! / !!! (23 / 31)	APNEA FLOW¹⁾	Breathing/ventilation stops. Leak or disconnect in breathing circuit.	Check ventilator. Check breathing circuit.
!! / !!! (23 / 31)	APNEA PRESSURE²⁾	Breathing/ventilation stops. Leak or disconnect in breathing circuit.	Check ventilator. Check breathing circuit.

1) APNEA FLOW alarm priorities are based on alarm duration and ventilation mode:

In Volume Control, Pressure Control, SIMV/PS with Freq ≥ 6 , or Pressure Support with Apnea Ventilation OFF:

Caution = $V_T < 20$ mL for >15 seconds

Warning = $V_T < 20$ mL for >30 seconds

In ManSpont, SIMV/PS with Freq <6, or Pressure Support with Apnea Ventilation ON:

Caution = $V_T < 20$ mL for >30 seconds

Warning = $V_T < 20$ mL for >60 seconds

2) APNEA PRESSURE alarm priorities are based on alarm duration and ventilation mode:

In Volume Control, Pressure Control, SIMV/PS with Freq ≥ 6 , or Pressure Support with Apnea Ventilation OFF:

Caution = PAW does not cross the pressure threshold for >15 seconds

Warning = PAW does not cross the pressure threshold for >30 seconds

In ManSpont, SIMV/PS with Freq <6, or Pressure Support with Apnea Ventilation ON:

Caution = PAW does not cross the pressure threshold for >30 seconds

Warning = PAW does not cross the pressure threshold for >60 seconds

Priority	Alarm Message	Probable Cause	Remedy
!! (20)	APNEA VENTILATION	Breathing/ventilation stops. Leak or disconnect in breathing circuit. If two or more consecutive Apnea Ventilation breaths are auto triggered the Pressure Support settings are incorrect.	Check ventilator. Check breathing circuit. A spontaneous patient breath is detected by the Fabius GS <i>premium</i> . Check Pressure Support settings.
! (7)	BATTERY LOW	AC failure and battery <20 %	Restore mains power.
!! (17)	BATTERY LOW	AC failure and battery <10 %	Restore mains power.
!!! (26)	CHECK APL VALVE	APL bypass valve fault.	Check ventilator diaphragm and close cover. Check APL bypass valve connection for disconnect or leak. Select Standby Mode and switch back to the previous ventilation mode. Check the APL valve setting.
! (7)	CHECK BATTERY	The reserve power is 0 % of a full charge.	Replace fuse. Call DrägerService or your local authorized service organization.
!!! (31)	CONTINUOUS PRESSURE	Breathing pressure above threshold for more than 15 seconds.	Check breathing circuit. If in ManSpont mode, check fresh-gas flow. Check actual limit ▼/ for "Pressure threshold alarm limit"
!! (15)	EXP PORT LEAKAGE	Expiratory flow of more than 15 mL measured during inspiration in Volume Control, Pressure Control, or Pressure Support mode.	Check expiratory valve and valve disk. Check tubing of expiration control line. Check flow sensor. Follow the procedure to calibrate flow sensor. Call DrägerService or your local authorized service organization.

Priority	Alarm Message	Probable Cause	Remedy
!! (16)	EXP PRESSURE HIGH	PEEP is more than 4 cmH ₂ O (hPa) above the PEEP setting in an automatic ventilation mode.	Check PEEP/PMAX, etc. hoses for kinks.
! (4)	FLOW SENSOR CAL DUE	More than 18 hours passed since last flow sensor calibration. Cable has been removed and reconnected.	Follow the procedure to calibrate flow sensor (see page 120).
! (8)	FLOW SENSOR FAIL	Sensor cable is disconnected. Flow sensor has not been properly calibrated. Sensor faulty.	Reconnect sensor cable to sensor at breathing system. Follow the procedure to calibrate sensor (see page 120). Replace sensor and calibrate. Call DrägerService or your local authorized service organization.
!! (21)	FRESH GAS LOW	Inadequate fresh-gas supply in all ventilation modes. Blocked/kinked hose. Leak or disconnect in breathing circuit.	Ensure adequate fresh-gas supply. Check hoses. Check breathing circuit.
!! (13)	INSP O2 HIGH	Inspiratory O ₂ concentration exceeds the upper alarm limit.	Check flowmeter settings and O ₂ high alarm limit.
!!! (31)	INSP O2 LOW	Inspiratory O ₂ concentration is below lower alarm limit.	Check O ₂ supply. Check flowmeter settings and O ₂ low alarm limit.
!! (11)	INSP PRES NOT REACH	Plateau pressure is more than 3 cmH ₂ O (hPa) below the P _{INSP} setting and the expected PLAT while ventilating in Pressure Control, Pressure Support, or SIMV/PS mode.	Check ventilator, patient circuit, and P _{INSP} settings.

Priority	Alarm Message	Probable Cause	Remedy
!! (14)	MINUTE VOLUME HIGH	Minute volume has exceeded upper alarm limit. Flow sensor has not been calibrated. Sensor faulty.	Calibrate flow sensor. Replace if necessary.
!! (22)	MINUTE VOLUME LOW	Minute volume has fallen below lower alarm limit. Blocked/kinked hose. Leak in breathing system. Reduced volume due to pressure limitation. Reduced lung compliance. Flow sensor not calibrated or faulty.	Check breathing circuit and alarm limit. Check breathing circuit. Check breathing system. Check P _{MAX} setting on ventilator control panel. Check ventilator settings. Follow the procedure to calibrate flow sensor (see page 120), and replace if necessary.
!!! (31)	NO FRESH GAS	Inadequate fresh-gas supply. Fresh-gas control valve closed Negative pressure safety relief valve opens automatically.	Ensure adequate fresh-gas supply. Open fresh-gas control valve.
! (6)	O2 SENSOR CAL DUE	More than 18 hours passed since last O ₂ sensor calibration.	Follow the procedure to calibrate O ₂ sensor (see page 121).
! (8)	O2 SENSOR FAIL	O ₂ sensor has not been correctly calibrated. O ₂ sensor replaced and/or not calibrated. O ₂ sensor used up. O ₂ sensor disconnected. Faulty sensor cable.	Follow the procedure to calibrate O ₂ sensor (see page 121). Follow the procedure to calibrate O ₂ sensor. Replace sensor capsule and calibrate. Connect O ₂ sensor assembly. Replace O ₂ sensor housing assembly.

Priority	Alarm Message	Probable Cause	Remedy
!!! (30)	O2 SUPPLY LOW	O2 supply line has less than minimum pressure permitted (approximately 20 psi) (approximately 1.4 kPa x 100).	Check O2 supply and cylinder backup.
! (9)	PEEP HIGH	PEEP is higher than 4 cmH2O (hPa) in ManSpont mode.	Check APL valve setting and/or fresh-gas flow.
! (7)	POWER FAIL	Mains not connected. Facility power failure.	Connect mains.
! (1)	PRES APNEA ALARM OFF	Pressure alarms off in Man-Spont.	
! (9)	PRESSURE LIMITING Volume Control mode	Measured pressure equals or exceeds P _{MAX} ventilator setting.	Check ventilator and P _{MAX} settings.
!!! (25)	PRESSURE NEGATIVE	Measured P _{AW} is <-6.5 cmH2O (hPa)	Check breathing circuit and ventilator settings.
! (8)	PRESSURE SENSOR FAIL	Faulty sensor or pressure not calibrated.	Call DrägerService or your local authorized service organization.
! (2)	PRES THRESHOLD LOW	Ventilation parameters were changed without changing alarm settings (see page 129).	Push the Auto Set soft key and check ventilator settings.
! (1)	RS232 COM1 FAIL	External monitor cable disconnected from External Communication Port 1.	Check monitor interface cable.
! (1)	RS232 COM2 FAIL	External monitor cable disconnected from External Communication Port 2.	Check monitor interface cable.

Priority	Alarm Message	Probable Cause	Remedy
! (1)	SPEAKER FAIL	Speaker failed	Call DrägerService or your local authorized service organization.
!!! (28)	VENTILATOR FAIL	Ventilator not assembled correctly.	Check diaphragm and close cover. Check PEEP/PMAX line for disconnect or leak. Select Standby Mode and switch back to the previous ventilation mode.
! (1)	VOLUME ALARMS OFF	Volume alarms disabled by operator.	

This page intentionally left blank

Cleaning

Safety information on reprocessing	158	Reinstalling the Scavenger System	171
Pre-cleaning	158	Reconnecting the Anesthetic Gas Receiving System (AGS)	171
Reprocessing methods	158	Reinstalling the Suction System	173
Machine cleaning and disinfection	158	Reconnecting the Suction System	173
Manual cleaning	159	Checking Readiness for Operation	174
Manual disinfection	159		
Visual inspection	160		
Sterilization	160		
Reprocessing and disinfection	160		
Removing the Compact Breathing System	161		
Removing the Inspiratory Valve	161		
Removing the Expiratory Valve	161		
Removing the Waste-Gas Port	162		
Removing the Flow Sensor	162		
Removing the APL Valve	163		
Removing Parts of the Ventilator	163		
Removing anesthetic gas scavenging system (AGSS)	164		
Removing the Suction System	164		
Reprocessing Breathing system	164		
O ₂ Sensor	165		
Spirolog Infinity ID and SpiroLife flow sensors	165		
Sterilization	165		
Care List for Fabius GS premium Components	166		
Reassembling the Breathing System	168		
Attaching the Inspiratory Valve	168		
Attaching the Expiratory Valve	168		
Attaching the APL Valve	168		
Screw the waste-gas port	169		
Installing Remaining Breathing System Components	169		
Reinstalling the Ventilator	170		

Safety information on reprocessing

CAUTION

To reduce the risk of infection to both hospital staff and patients, clean and disinfect medical devices after each use. Protective clothing, eye protection etc. must be worn.

- Comply with the hospital hygiene regulations!
- Reprocess the medical device after every patient.

The reprocessing recommendations do not exempt staff from the obligation to adhere to the hygiene requirements and directives on occupational health and safety relating to the reprocessing of medical devices.

To ensure the professional reprocessing of medical devices, the recommendations provided by the Robert Koch Institute in "Demands on Hygiene in Reconditioning Medical Products" should be followed.

Pre-cleaning

NOTE

To prevent heavy soiling of the breathing system, which is comparable to surgical instruments (proteins, blood, etc.), Dräger recommends the use of disposable filters on the medical device.

Otherwise, the described contamination requires a pre-cleaning in a ultrasonic bath. A positive cleaning effect, in the scope of the total pre-cleaning, has been shown in a test with the disinfection agent Gigasept AF (4 % solution).

Affected parts: compact breathing system, valve cover, expiration nozzle, absorber and APL valve
Afterwards rinse all parts thoroughly under running water until no residue of the cleaning agents is detected (approx. 5 min).

Reprocessing methods

Machine cleaning and disinfection

Use a washer-disinfector in accordance with EN ISO 15883, preferably with a cart for anesthesia and ventilation accessories, for automatic cleaning and disinfection. Use mild alkaline or enzymatic (with neutral pH) cleaning agents. The user must strictly observe the manufacturer's instructions for use for the cleaning agent.

Placing parts in washer-disinfector

- Place parts in washer-disinfector. Observe Instructions for Use of washer-disinfector.
- Position parts so that all interior spaces are completely flushed (e.g. hoses) and water can drain off freely.

Cleaning program

- Select suitable program (preferably anesthesia program). Cleaning is carried out at 40 to 60 °C (104 to 140 °F) for at least 5 minutes.

Thermal disinfection

- Thermal disinfection is carried out at 80 to 95 °C (176 to 203 °F) and with corresponding contact time.
- Carry out final rinsing with deionized water.

After completion of cleaning and disinfection program

- Immediately remove parts from washer-disinfector.
- Inspect parts for visible soiling and damage. If necessary, repeat cycle or clean manually.
- Allow parts to dry thoroughly.

Cleaning agents

The material compatibility of reusable Dräger accessories has been tested with various mildly alkaline and enzymatic cleaning agents at 95 °C (203 °F) for 10 minutes.

The following cleaning agents showed good material compatibility at the time of the test:

- Neodisher FA, Neodisher Medizym manufactured by Dr. Weigert

The user must strictly observe the manufacturer's instructions for use for the cleaning agent.

Manual cleaning

If no washer-disinfector is available, clean parts manually under running water with commercially available cleaning agents. The user must strictly observe the manufacturer's instructions for use for the cleaning agent.

- Wash off soiling on surfaces under running water.
- Use cleaning agents in accordance with manufacturers specifications. Make sure that all surfaces to be cleaned can be efficiently reached (e.g. inside hoses). Use suitable brushes if necessary.

Do not use any brushes for the flow sensor. Observe the relevant Instructions for Use.

- Rinse parts under running water until no cleaning agent residues are discernible.
- Check parts for visible soiling and damage. Repeat manual cleaning if necessary.

Manual disinfection

Manual disinfection should preferably be carried out with disinfectants based on aldehydes or quaternary ammonia compounds. The efficiency of the disinfectants used must be proven. Observe the applicable country-specific listings. The user must strictly observe the manufacturer's instructions for use for the cleaning agent.

Disinfectants

The material compatibility of Dräger accessories to be reprocessed has been tested with various disinfectants.

The test showed that the following disinfectants have a good material compatibility:

Surface disinfectant (for device surfaces)

- Incidin Extra N from Ecolab
- Incidur from Ecolab

Instrument disinfectant (for components or accessories):

- Korsolex extra manufactured by Bode Chemie
- Gigasept FF manufactured by Schülke & Mayr

The composition of the disinfectant is the responsibility of the manufacturer and can change over time.

Disinfecting surfaces

WARNING

Penetrating liquid may lead to failure of the medical device or damage to the medical device and endanger the patient! Only disinfect parts by wiping and make sure no liquids penetrate into the device.

- Following manual cleaning, carry out surface disinfection.
- Remove disinfectant residues.

Disinfecting components or accessories

- Disinfect parts by immersing.
- Sufficiently rinse parts under running water until no disinfectant residues can be recognized.
- Inspect parts for visible soiling and damage. Repeat manual disinfection if necessary.
- Shake out remaining water thoroughly. Allow parts to dry thoroughly.

Visual inspection

- Inspect all parts for damage and wear, e.g., cracking, embrittlement or pronounced hardening and residual soiling.

CAUTION

Even accessories designed to be reused (e.g. after reprocessing) have a limited service life. Due to a number of factors connected with handling and reprocessing (e.g. disinfectant residues can attack the material more intensely during auto-claving), increased wear can occur and the service life can be markedly shortened. These parts must be replaced if signs of wear become visible, such as cracks, deformation, discoloration, peeling, etc.

Reprocessing and disinfection

This section contains instructions for dismantling and cleaning the Fabius GS *premium* anesthesia workplace.

During the reprocessing cycles, the vaporizers remain attached to the medical device.

CAUTION

When moving the writing tray, the holding arms and drawers, keep a distance from the edges to avoid crushing.

Device surfaces

CAUTION

Risk of damage to the medical device

The surfaces of Fabius GS *premium*, the pressure gas hoses and cables must not be treated with alcohol containing agents.

Sterilization

Use a vacuum steam sterilizer (in accordance with DIN EN 285), preferably with fractional vacuum, for sterilization.

CAUTION

Do not sterilize parts in ethylene oxide! Ethylene oxide may diffuse into the parts and cause damage to health.

CAUTION

The Spirolog Flow Sensor and the Infinity ID Flow Sensor must not be sterilized in hot steam. The flow sensors are not resistant to high temperatures and may be damaged.

- Hot steam sterilization can be carried out at 134 °C (273.2 °F). Observe Instructions for Use of medical device.

Removing the Compact Breathing System


- Remove all breathing hoses.
 - Disconnect the breathing bag extension and bag by loosening the two thumb screws.
 - Remove the ventilation hose.
 - Remove the fresh-gas hose from the breathing system.
 - Remove the scavenger hose.
 - Remove the flow sensor cable.
 - Remove the O₂ sensor cable.
 - Remove the breathing pressure cable.
 - Remove the COSY shielding, being careful to guide any cables from the slots in the side of the cover.
 - Detach the APL-bypass and the PEEP/PMAX lines from the breathing system and from the side of the machine.
 - Remove the absorber (for complete instructions, see page 179).
- Remove the compact breathing system.
 - 1 Remove plug for the inspiration dome.

Removing the Inspiratory Valve

- 2 Unscrew the retaining nut.
- 3 Remove the inspection cap.
- 4 Extract the valve disc.
- 5 Remove the gasket on top of the valve disc.


Removing the Expiratory Valve

- 6 Unscrew the retaining nut.
- 7 Remove the inspection cap.
- 8 Extract the valve disc.
- 9 Remove the gasket on top of the valve disc.



Removing the Waste-Gas Port

- Unscrew the waste-gas port.



Removing the Flow Sensor

- 1 Loosen fitting on the expiration port.
- 2 Remove the flow-sensor guard.
- 3 Extract the flow sensor.

CAUTION

Risk of flow measurement failure

Disinfecting or cleaning the flow sensors by machine will damage them and cause the flow measurement to fail.


Disinfect and clean the flow sensors as described in the Instructions for Use of the Spirolog, Infinity ID flow sensor and SpiroLife flow sensors.

CAUTION

Risk of flow measurement failure

Sterilizing the Spirolog and Infinity ID flow sensors in high-temperature steam will damage them and cause the flow measurement to fail.

Disinfect and clean the flow sensor as described in the Instructions for Use of the Spirolog, Infinity ID flow sensor and SpiroLife flow sensors.




Removing the APL Valve

- Unscrew the retaining nut.
- Remove the APL valve.
- Unscrew the waste-gas outlet port.

Removing Parts of the Ventilator

- 1 Open the ventilator door.
- 2 Disconnect the pressure sensor line of the ventilator chamber from the respective connector.
- 3 Unlock the three clasps.
- 4 Remove the cover.
- 5 Remove the ventilator diaphragm.



Removing anesthetic gas scavenging system (AGSS)

- Remove the anesthetic gas receiving system (AGS), including scavenging hose and exhaust hose from the medical device.

NOTE

For cleaning/disinfection instructions for the passive scavenger system, refer to its Instructions for Use.

Removing the Suction System

- Remove suction bottle assembly, including bottle and regulator.

WARNING

Risk of infection

Always wear protective gloves when emptying the suction bottle.

Observe the hospital hygiene regulations.

NOTE

Reprocessing/disinfection instructions for the reusable suction bottle and the suction regulator, refer to their respective Instructions for Use.

Reprocessing Breathing system

All parts of the respiratory system, ventilator diaphragm, Y-piece, respiratory hoses, respiratory bag, parts of the absorber, parts of the secretion suction unit and parts of the anesthetic gas scavenging system.

- Thermally disinfect in the cleaning/disinfection machine at 200 °F (93 °C) /10 minutes.

Only use neutral or mild alkaline cleaning agents (e.g. Neodisher Medizym, Neodisher FA) and completely demineralized water!

When using thermal disinfection, the addition of disinfectant chemicals is not necessary; risk of corrosion!

WARNING

After washing, a hot steam sterilization is required to completely dry the breathing system.

Insufficient drying of the control areas found in the valve plate can lead to impairment of device function or to failure of the medical device!

O₂ Sensor

CAUTION

Risk of equipment damage

The O₂ Sensor must not be sterilized or disinfected!

Spirolog Infinity ID and SpiroLife flow sensors

Reprocess the flow sensors in accordance with the corresponding Instructions for Use.

CAUTION

The flow sensors must not be reprocessed in a washer-disinfector. Do not clean with compressed air, water jet, brush, etc. Otherwise, the thin wires in the flow sensors may be destroyed. The Spirolog and Infinity ID flow sensors must not be sterilized in hot steam. The flow sensors are not resistant to high temperatures and will be destroyed.

CAUTION

Only use clean disinfectant solutions to disinfect the flow sensors. Contaminants, e.g., lint, may lead to the destruction of the flow sensors.

WARNING

Risk of fire hazard

Allow the flow sensors to dry in air for at least 30 minutes after the use of disinfectants containing flammable substances. These substances give off vapors that could ignite during calibration.

CAUTION

The flow sensors can only be reused as long as automatic calibration is possible.

Sterilization

CAUTION

Risk of damage to the medical device

The Spirolog and Infinity ID flow sensors must not be sterilized.

Strictly follow the correct Instructions for Use.

Steam sterilization at 273 °F (134 °C).

CAUTION

Risk of damage to the medical device

SpiroLife flow sensors are not suitable for plasma or radiation sterilization.

Strictly follow the correct Instructions for Use. All components with the suitable reprocessing options are listed in the care list for Fabius GS *premium* components page 166. Follow the hygiene regulations of the hospital!

Care List for Fabius GS *premium* Components

The following table lists Fabius GS *premium* components with recommended processing methods. Processing refers to cleaning, disinfection, and/or sterilization, as appropriate for a given component. The table is intended as a guide. Follow the institution's policies regarding specific methods and agents for cleaning and sterilization.

Applicable for non-infectious patients

CAUTION

For infectious patients, all parts that come into contact with breathing gas also have to be sterilized after disinfection and cleaning.

The list is only intended as a rough guideline. The instructions of the hospital's hygiene officer shall prevail and must be observed!

CAUTION

Fabius GS *premium* and its components must not be treated with formaldehyde vapors or ethylene oxide.

Fabius GS <i>premium</i> components which can be reprocessed	Recommended reprocessing intervals	Manual pre-cleaning ¹⁾	Machine cleaning and thermal disinfection ²⁾	Manual disinfection ³⁾		Hot steam sterilization
				Surface disinfection	Immersion bath disinfection	
Surfaces						
Device surfaces	Per patient	No	No	Yes ⁴⁾	No	No
Power supply cable, pressure gas hoses	Per patient	No	No	Yes ⁴⁾	No	No
Respiratory pressure meter	Daily	No	No	Yes	No	No
Components for carrying breathing gas						
Breathing system	Per patient	Yes	Yes ⁵⁾	No	Yes	Yes
Inspiratory valve, expiratory valve, APL valve	Per patient	Yes ⁶⁾	Yes	No	Yes	Yes
Expiratory port	Per patient	Yes	Yes	No	Yes	Yes
Exhaust port valve	Per patient	Yes ⁶⁾	Yes	No	Yes	Yes
Ventilator cover	Per patient	Yes ⁶⁾	Yes	No	Yes	Yes
Ventilator diaphragm ⁷⁾	Per patient	Yes	Yes	No	Yes	Yes
Ventilator hose	Per patient	No	Yes ⁵⁾	No	Yes	Yes
Absorber and insert	Per patient	Yes	Yes	No	Yes	Yes
Infinity ID/Spirolog/ SpiroLife flow sensor	Note the Instructions for Use of the flow sensors					

Fabius GS <i>premium</i> components which can be reprocessed	Recommended reprocessing intervals	Manual pre-cleaning ¹⁾	Machine cleaning and thermal disinfection ²⁾	Manual disinfection ³⁾		Hot steam sterilization
				Surface disinfection	Immersion bath disinfection	
Manual bag valve mask holder	Per patient	Yes	Yes	No	Yes	Yes
Other						
AGS scavenging system	Daily	Reprocessing according to appropriate Instructions for Use.				
COSY shielding	Per patient	No	No	Yes ⁴⁾	No	No
Suction system and suction bottle assembly accessories	Daily	Reprocessing according to appropriate Instructions for Use.				

- 1) It is generally recommended to perform a pre-cleaning under running water for approx. 5 minutes. For dried soiling an additional pre-cleaning step using an ultrasonic bath is recommended. The addition of a quaternary ammonium compound supports the cleaning performance effectively (e. g. Gigasept AF). Perform pre-cleaning in the ultrasonic bath for approx. 15 minutes. Afterwards rinse under clear running water for approx. 5 minutes (waste water must be free of visible cleaning residues).
- 2) Use mild alkaline or neutral cleaner
- 3) Use disinfectants based on aldehydes and quaternary ammonium compounds.
- 4) Do not use any agents containing alcohol.
- 5) After the machine cleaning and disinfection, a hot steam sterilization is required to dry the breathing system. Insufficient drying of the control areas found in the valve plate can lead to an adverse effect on the functions of the medical device or to its failure!
- 6) Valves, ventilator cover and AGS sleeve: Make sure that the cleaning and rinsing liquids can flow in the opening direction of the valve.
- 7) Remove any water which may have accumulated in the ventilator diaphragm. Large quantities of condensed water can negatively effect the operation of the device and lead to failure of the medical device!


Reassembling the Breathing System

Attaching the Inspiratory Valve

- 1 Place the gasket on top of the valve disc.
- 2 Place the valve disc in the valve seat.
- 3 Fit the inspection cap (with port).
- 4 Tighten the retaining nut securely.
- 5 Insert the plug for the inspiration dome.

Attaching the Expiratory Valve

- 6 Place the gasket on top of the valve disc.
- 7 Place the valve disc in the valve seat.
- 8 Fit the inspection cap.
- 9 Tighten the retaining nut securely.




Attaching the APL Valve

WARNING


Route all lines/cables away from the APL valve to prevent interference with the APL valve adjustment knob. Lines/cables caught underneath the APL valve adjustment knob could interfere with proper functioning of this valve.

- 10 Position the APL valve in the valve seat, and tighten securely with the retaining nut.



Screw the waste-gas port

- Screw in the waste-gas port from below into the compact breathing system. Make sure there is a tight seal.




Installing Remaining Breathing System Components

- Follow instructions beginning on page 46 to reinstall the following breathing system components:
 - flow sensor
 - breathing system
 - ventilation hose
 - fresh-gas hose
 - breathing bag extension* and bag
 - flow sensor and breathing pressure cables
 - APL bypass and PEEP/PMAX cables
 - COSY shielding
 - O₂ sensor cable
 - breathing system hoses
- Follow instructions on page 179 to reinstall the absorber system

* optional

Reinstalling the Ventilator

- 1 Open the ventilator door with the attached ventilator unit.
- 2 Unlatch the three clasps.
- 3 Remove the cover.
- 4 Insert the diaphragm.
- Fit the cover and lock the three clasps.
- 5 Connect pressure sensor line to the ventilator chamber to the respective connector.
- Close the ventilator door with the attached ventilator unit.



Reinstalling the Scavenger System

Reconnecting the Anesthetic Gas Receiving System (AGS)

Every Anesthetic Gas Scavenging System (AGSS) used on the Fabius GS *premium* must follow ISO standard 8835-3.

The scavenging system is used with vacuum waste-gas disposal systems.

The AGS is not applied as an independent system. It is used as one of the three components of the AGSS.

WARNING

Risk of patient injury

If the side openings of the receiving system are blocked, negative pressure may result in the breathing system and the patient's lungs. Always make sure the side openings of the receiving system are not blocked.


NOTE

Remove the socket from the scavenger hose before connecting.

NOTE

The scavenger hoses must not be pinched, kinked, or blocked in any manner.

- Hook receiving system with the slots over the appropriate pins of the basic device and allow it to slide down into place.
- 1 Connect the scavenging hose to the relevant socket of the receiving system.
- Connect the connector of the scavenging hose to the terminal unit of the disposal system.
- 2 Close the connection that is not used with a screw cap.
- Push the transfer hose on the designated socket.
- Connect the other end of the transfer hose to the waste-gas port located on the underside of the breathing system.




- 1 Install the particle filter and tighten the retaining nut.
 - 2 Reinstall the flow tube with the scale facing the front of the machine.
 - 3 Tighten the retaining nut.
- Reinstall the buffer volume container into the scavenger body.

WARNING

Danger to the patient

Do not cover the side openings of the receiving system. Otherwise there may be a shortage of fresh gas in the breathing system.

For detailed information on the AGS, refer to the specific Instructions for Use provided with the anesthetic gas receiving system AGS (9038579).



Reinstalling the Suction System

Reconnecting the Suction System

The optional aspiration system for the Fabius GS *premium* consists of an suction regulator and a suction bottle. The suction regulator is attached to a holder, which is fastened on the side channel of the anesthesia device. The suction bottle desired by the customer is attached to a separate swivel rail on the side channel.

- Attach the carrier arm of the suction system on the side channel on the side of the anesthesia device.
- 1 Mount the suction regulator onto the bracket.
- Reprocess the suction bottle according to the instructions for use included with the bottle.
- 2 Attach the suction bottle on the swivel rail.

Depending on the aspiration system used:

With use of air or O₂ as driving gas:

- Connect the air connection hose of the suction system on the air exhaust of the gas supply block (optional) or directly on the gas supply line.


For vacuum aspiration:

- Connect the vacuum hose of the suction system directly on the gas supply line.

Make sure that the suction system is ready for operation according to the included Instructions for Use.

WARNING

The aspiration system must only be used in the »Man/Spont« mode or if the Y-piece is not connected.



Checking Readiness for Operation

At the completion of the reassembly of the Fabius GS *premium*, perform the Daily and Pre-use Checkout procedure provided in the Appendix of this manual to ensure that the machine is ready for operation.

Maintenance

Overview	176
Definition of Maintenance Concepts	176
Inspection	176
Safety Checks	177
Preventive maintenance	178
Routine Maintenance	179
Replacing the O ₂ Sensor Capsule	179
Replacing CO ₂ Absorbent	179
CLIC Adapter (Optional)	181
Checking Readiness for Operation	181

Overview

This chapter describes all maintenance steps necessary to maintain the proper functioning of the device. These maintenance steps must be performed by professionals.

CAUTION

Clean and disinfect device or device parts before each maintenance step and also before returning for repair.

CAUTION

Risk of electric shock
Do not open the housing of the device. All service and repair work must be performed by professionals. Dräger recommends DrägerService to perform these tasks.

Definition of Maintenance Concepts

Concept	Definition
Maintenance	The combination of all technical and administrative measures taken during the life cycle of a medical device intended to retain or restore operating condition so that the medical device can perform its required functions.
Inspection	Measures intended to determine and assess the actual state of a medical device and to determine the cause of wear and deducing consequences necessary for future use.
Preventive maintenance	Measures intended to delay the depletion of the wear margin.
Repair	Measures intended to restore a medical device to operating condition, not including enhancement.

Inspection

Inspections must be carried out regularly according to the following specifications and in the specified intervals.

Check	Interval	Personnel responsible
Inspection and Safety Checks	every 12 months	professionals

Safety Checks

The safety checks are no substitute for the preventive maintenance measures (including preventive replacement of wear parts) indicated by the manufacturer.

CAUTION

The safety checks must be carried out in the specified intervals. Otherwise, the correct functioning of the medical device can be impaired.

- 1 Check accompanying documents:
 - latest Instructions for Use are available
- 2 Verify that the device combination is in good condition:
 - all labels are complete and legible
 - there is no visible damage
 - Fuses which are accessible from the outside are in compliance with the specified values
- 3 Check that the equipment of the medical device is complete according to the Instructions for Use.
- 4 Check the electrical safety according to IEC62353
- 5 Check safety features:
 - Check correct functioning of the alarm generator.
 - Check correct functioning of the alarm generation of lack of O₂.
 - Check correct functioning of O₂ measurement.
 - Check correct functioning of flow measurement.
 - Check correct functioning of PAW, PEEP, APL and P_{MAX} pressure measurement.
 - Check correct functioning of power fail alarm and battery backup function.
 - Check correct functioning of Vaporizer Interlock function.
 - Check correct functioning of auxiliary air supply and safety valves of ventilator.
 - Check correct functioning of S-ORC.
 - Check correct functioning of vaporizers according the IfU of vaporizers.

Preventive maintenance

CAUTION

This device must undergo inspection and preventive maintenance in the intervals specified by the manufacturer.

The following table shows the preventive maintenance intervals:

Component	Interval	Measure	Personnel responsible
Fabius GS <i>premium</i>	Every 12 months	Inspection and service	Professionals
Breathing systems	Every 12 months	Inspection and service	Professionals
Vaporizers	Every 12 months	Inspection and service	Professionals
Sensors	Every 12 months	Inspection and service	Professionals
Service set major overhaul for high pressure cylinder connection ¹	After 6 years	Replace	Professionals
Service set major overhaul for high pressure cylinder connection label gas types ¹	After 6 years	Replace	Professionals

1 optional

NOTE

If desired, the customer may receive a list of those parts and their assembly instructions to be replaced in the event of repairs being necessary.

Routine Maintenance

Routine maintenance must be performed regularly to ensure safe and effective operation. Regularly check the condition of the absorbent and the overall condition of the machine, power cord, hoses, and breathing bag.


CAUTION

Risk of electric shock

Do not remove cover. Refer servicing to a DrägerService representative.

Replacing the O₂ Sensor Capsule

- 1 Unscrew the cap from the sensor housing.
- Remove the new sensor capsule from its packaging.
- 2 Insert the capsule in the housing, with the ring-shaped conductors against the contacts in the housing.
- Screw the cap on firmly by hand.



Replacing CO₂ Absorbent

The CO₂ absorbent in the compact breathing system should be replaced when two-thirds of the CO₂ absorbent has changed color. Dräger recommends the use of Drägersorb 800 Plus or Drägersorb FREE. The color change indicates that the CO₂ absorbent can no longer absorb CO₂ (Drägersorb 800 Plus and Drägersorb FREE change from white to violet).

NOTE

Please refer to the specific Instructions for Use for "Drägersorb 800 Plus or Drägersorb FREE".

WARNING

Do not flush dry gas continuously for unnecessarily long periods through the soda lime in the anesthesia workstation.

Otherwise the soda lime will dehydrate. If the moisture level falls below a minimum level, undesirable reactions generally occur, regardless of the type of soda lime and the inhalation anesthetic used:

- **reduced CO₂ absorption,**
- **increased heat generation in the absorber and therefore increased breathing gas temperature,**
- **CO formation,**
- **absorption and/or breakdown of the inhalation anesthetic.**

The above mentioned reactions may endanger the patient, e.g.:

- **CO poisoning**
- **insufficient depth of anesthesia**
- **burns of the airway.**

CAUTION

Soda lime irritates the skin and there is a risk of serious damage to eyes.

If soda lime has leaked:

- Powdered soda lime must not be inhaled or swallowed.
- Put on protective gloves and goggles, or a face mask.
- In case of coming in contact with eyes, rinse immediately with large amounts of water and consult a physician immediately, otherwise it may lead to eye damage.
- Powdered soda lime on the skin must be washed off immediately, because it may irritate the skin.

- Remove the absorber canister by turning it clockwise.
- Empty the expired CO₂ absorbent from the absorber into an appropriate refuse container.
- Fill the absorber with fresh CO₂ absorbent.

NOTE

Ensure that no CO₂ absorbent dust/particles have been deposited between the gaskets and sealing surfaces. Such dust and particles can cause leaks in the system.


- 1 Fit the absorber canister into position below the breathing system and turn it counterclockwise as far as possible.

CLIC Adapter (Optional)

The disposable CLIC adapter absorber can also be used on the Fabius GS *premium*. For information on installing the CLIC adapter, consult its Instructions for Use.

Checking Readiness for Operation

Perform the Daily and Pre-use Checkout procedure provided in the Appendix of this manual to ensure that the machine is ready for operation.



This page intentionally left blank

Disposal

Disposal of the Medical Device 184

Disposal of Non-Rechargeable Batteries . . . 184

Disposal of O2 Sensors 184

Disposal of Bacterial Filter 184

Disposal of Flow Sensor 184

Disposal of the Medical Device

When disposing of the medical device:

- Consult the relevant waste disposal company for appropriate disposal.
- Comply with the applicable laws and regulations.

Disposal of Non-Rechargeable Batteries

WARNING

Risk of explosion and chemical injury

Do not throw batteries into fire.

Do not force batteries open.

- Do not recharge batteries.

The medical device battery contains pollutant substances.

Observe the applicable laws and regulations for battery disposal.

Disposal of O₂ Sensors

NOTE

O₂ sensors are special waste. Dispose of the O₂ sensors according to local waste disposal regulations.

Expired O₂ sensors can be returned to:

Dräger Medical GmbH
Moislinger Allee 53 – 55
D-23542 Lübeck
Germany

Disposal of Bacterial Filter

Must be disposed of as infectious special waste.

Can be incinerated at temperatures above 1472 °F (800 °C) with minimal environmental pollution.

Disposal of Flow Sensor

Dispose of spent sensor with infectious special waste. We recommend low-emission incineration at more than 1472 °F (800 °C).

Technical Data

Ambient Conditions	186
Machine Data	186
Mains fuses	188
Battery fuse	188
Electromagnetic Compatibility (EMC)	189
General information	189
Electromagnetic emissions	190
Electromagnetic immunity	191
Recommended separation distances	193
Electrical Safety Conformance	194
General Safety Standards for Anesthesia .	194
Freedom from Latex	194
Ventilator	194
Anesthesia Gas Supply Module	197
Anesthetic Agent Vaporizer Interface	198
Breathing System	200
Low Oxygen Supply Pressure Alarm	202
S-ORC (Sensitive Oxygen Ratio Controller)	202
Serial Interface	203
Diagram	204
Gas flow diagram	204

Ambient Conditions

During operation

Temperature	50 to 95 °F (10 to 35 °C)
Atmospheric pressure	700 to 1060 cmH ₂ O (hPa)
Relative humidity	20 to 80 % (no condensation)

During storage

Temperature	14 to 140 °F (–10 to 60 °C)
Atmospheric pressure	700 to 1060 cmH ₂ O (hPa)
Relative humidity	10 to 90 % (no condensation)

The service conditions for supplementary equipment must be noted. These may restrict the area of use for the system as a whole. Vaporizer units and the anesthetic agents used may restrict the area of use of the workstation in regards to its temperature range and maximum fresh-gas flow. The corresponding Instructions for Use of the supplementary equipment must be noted.

Machine Data

Gas supply from medical gas pipeline system

Pipeline System Pressure Range at Machine Connector

O ₂ , N ₂ O, AIR:	50 to 55 psi (3.4 to 3.8 kPa x 100) Note: Pipeline system supply pressure variation shall not exceed ±10 %
---	---

Gas supply connectors: NIST or DISS (where required)

Each inlet is fitted with a non-return valve

Pipeline Pressure Indicator Accuracy	±3 % of full scale from 40 to 120 psi (2.7 to 8.3 kPa x 100)
--------------------------------------	---

Gas supply from supplementary O₂ and N₂O cylinders (with pin-index connections)

Cylinder Connections	Pin-indexed hanger yokes (CGA V-1-1994)	
Cylinder Gas Pressure (typical full loads at 70 °F, 21 °C)	O ₂ , AIR	1900 psi (131 kPa x 100)
	N ₂ O	745 psi (51.3 kPa x 100)
Cylinder Gauges	Conform to ASME B40.1 Grade B	
Cylinder Gauge Range	O ₂	0 to 3000 psi (206.8 kPa x 100)
	N ₂ O	0 to 3000 psi (206.8 kPa x 100)
	AIR	0 to 3000 psi (206.8 kPa x 100)

Compressed gas supply at workstation inlet

Dew point	>41 °F (5 °C) at ambient temperature
Oil content	<0.1 mg/m ³
Particles	dust-free air (filtered with pores <1 µm)

Internal Regulator Safety Relief Valve Pressure 70 psi (4.8 kPa x 100) opening pressure

Fresh-gas outlet for non-rebreathing system (optional) Male cone 22 ISO, Female cone 15 ISO, (with thread to secure)

Pressure limitation Max. 80 hPa (cmH₂O) at 18 L/min


Fresh-gas flow 0 and 0.2 to 18 L per minute volume flow

Protection Class

I, in accordance with IEC 60601-1

Applied parts:

Breathing system (nozzles, breathing hoses)

Type BF 

Ingress of Fluids

IPX0

Dimensions and Weight (Approximate)

Weight:

Base unit with COSY and without supplementary cylinders and vaporizers 296 lb (134.2 kg)

Dimensions W x H x D (with COSY and 3-Vaporizer Mount)¹⁾: approx. 40.7 x 52 x 33 in (103.5 x 132 x 84 cm)

Dimensions W x H x D (without COSY, with 2-Vaporizer Mount)¹⁾: approx. 30 x 52 x 33 in (76 x 132 x 84 cm)

Power supply, Rating Non-configurable

100 to 240 VAC, 50/60 Hz, 70 VA

1) Width may vary with COSY arm position

Rechargeable batteries

Rating:	24 V; 3.5 Ah
Type:	sealed, gelled lead-acid
Recharging time:	≤16 hours on the mains or full operation time
Operation time with fully charged batteries:	45 minutes, minimum

Fuses

Mains fuses

For 100 to 240 V supply voltage:
2x T2.5AH 250 V IEC 60127-2/V

Battery fuse

1x T3.15AH 250 V IEC 60127-2/V

Electromagnetic Compatibility (EMC)

General information

The EMC conformity includes the use of following external cables:

Designation	Order no.
O2 Sensor housing with cable	8606055
Data cable 2 m Sub-D9 F/M	8601474
Data cable 3 m Sub-D9 F/M	8601528

Additionally, accessories may be used which do not affect EMC compliance, if no other reasons interdict the use of them. The non-observance may result in increased emissions or decreased immunity of Fabius GS *premium*.

The Fabius GS *premium* should not be used adjacent to or stacked with other equipment; if adjacent or stacked use is inevitable, Fabius GS *premium* should be observed to verify normal operation in the configuration in which it will be used.

Electromagnetic emissions

The Fabius GS *premium* is intended for use in the electromagnetic environment specified below. The user should assure that it is used only in such an environment.

Emissions	Compliance according to	Electromagnetic environment
RF emissions (CISPR 11)	Group 1	The Fabius GS <i>premium</i> uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment.
	Class A	The Fabius GS <i>premium</i> is suitable for use in all establishments excluding domestic establishments and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.
Harmonic emissions (IEC 61000-3-2)	not applicable	not applicable
Voltage fluctuations / flicker (IEC 61000-3-3)	not applicable	not applicable


Information regarding electromagnetic emissions
(IEC 60601-1-2: 2001, table 201)

Electromagnetic immunity

The Fabius GS *premium* is intended for use in the electromagnetic environment specified below. The user should assure that it is used only in such an environment.

Immunity against	IEC 60601-1-2 test level	Compliance level (of this equipment)	Electromagnetic environment
electrostatic discharge, ESD (IEC 61000-4-2)	contact discharge: ± 6 kV air discharge: ± 8 kV	± 6 kV ± 8 kV	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity shall be at least 30 %.
electrical fast transients / bursts (IEC 61000-4-4)	power supply lines: ± 2 kV longer input / output lines: ± 1 kV	± 2 kV ± 1 kV	Mains power quality should be that of a typical commercial or hospital environment.
surges on AC mains lines (IEC 61000-4-5)	common mode: ± 2 kV differential mode: ± 1 kV	± 2 kV ± 1 kV	Mains power quality should be that of a typical commercial or hospital environment.
power frequency magnetic field 50/60 Hz (IEC 61000-4-8)	3 A/m	3 A/m	In close vicinity to the Fabius GS <i>premium</i> , no equipment with extraordinary power frequency magnetic fields (power transformers, etc.) should be operated.
voltage dips and short interruptions on AC mains input lines (IEC 61000-4-11)	dip >95 %, 0.5 periods dip 60 %, 5 periods dip 30 %, 25 periods dip >95 %, 5 seconds	>95 %, 0.5 per. 60 %, 5 per. 30 %, 25 per. >95 %, 5 sec.	Mains power quality should be that of a typical commercial or hospital environment. If user requires continued operation during power mains interruptions, it is recommended to power the Fabius GS <i>premium</i> from an uninterruptible supply or a battery.
radiated RF (IEC 61000-4-3)	80 MHz to 2.5 GHz: 10 V/m	10 V/m	Recommended separation distance from portable and mobile RF transmitters with transmission power P_{EIRP} to the Fabius GS <i>premium</i> including its lines: $1.84 \text{ m} * \sqrt{P_{EIRP}^{(1)}}$

Immunity against	IEC 60601-1-2 test level	Compliance level (of this equipment)	Electromagnetic environment
RF coupled into lines (IEC 61000-4-6)	150 kHz to 80 MHz: 10 V within ISM bands, 3 V outside ISM bands ²⁾	10 V 3 V	Recommended separation distance from portable and mobile RF transmitters with transmission power PEIRP to the Fabius GS <i>premium</i> including its lines: $1.84 \text{ m} * \sqrt{\text{PEIRP}}^{1)}$

- 1) For PEIRP the highest possible “equivalent isotropic radiated power” of the adjacent RF transmitter has to be inserted (value in Watt). Also in the vicinity of equipment marked with the symbol  interference may occur. Field strengths from fixed, portable or mobile RF transmitters at the location of the Fabius GS *premium* should be less than 3 V/m in the frequency range from 150 kHz to 2.5 GHz and less than 1 V/m above 2.5 GHz.
- 2) ISM bands in this frequency range are: 6.765 MHz to 6.795 MHz, 13.553 MHz to 13.567 MHz, 26.957 MHz to 27.283 MHz, 40.66 MHz to 40.70 MHz.

Information regarding electromagnetic immunity
(IEC 60601-1-2: 2001, tables 202, 203, 204)

Recommended separation distances

Recommended separation distances between portable and mobile RF telecommunication devices and the Fabius GS <i>premium</i>			
max. PEIRP (W)	3 V/m distance ¹⁾ (m)	1 V/m distance ¹⁾ (m)	Note
0.001	0.06	0.17	
0.003	0.10	0.30	
0.010	0.18	0.55	
0.030	0.32	0.95	e.g. WLAN 5250 / 5775 (Europe)
0.100	0.58	1.73	e.g. WLAN 2440 (Europe), Bluetooth
0.200	0.82	2.46	e.g. WLAN 5250 (not in Europe)
0.250	0.91	2.75	e.g. DECT devices
1.000	1.83	5.48	e.g. GSM 1800- / GSM 1900- / UMTS- mobiles, WLAN 5600 (not in Europe)
2.000	2.60	7.78	e.g. GSM 900 mobiles
3.000	3.16	9.49	

1) 3 V/m distance to transmitters with frequencies from 150 kHz to 2.5 GHz, otherwise 1 V/m distance.

Information regarding separation distances
(IEC 60601-1-2: 2001, tables 205 and 206)

Electrical Safety Conformance

Conforms to:

- UL 60601-1
- IEC 60601-1
- CAN/CSA C22.2 No. 601.1-M90

General Safety Standards for Anesthesia

- IEC 60601-2-13 plus US deviations
- ISO 8835-2
- EN 740

Freedom from Latex

Fabius GS *premium* is latex-free!

Latex-free breathing bags and breathing hoses must be used for latex-free use.

Ventilator

Conforms to:

- ISO 8835-5

Control Inputs Ranges

PMAX	Pressure limiting	15 to 70 cmH ₂ O (1 cmH ₂ O resolution) (15 to 70 hPa (1 hPa resolution)) (setting must be at least 10 cmH ₂ O (10 hPa) above PEEP; and in SIMV/PS mode, the PMAX setting must also be greater than $\Delta P_{PS} + PEEP$)
V _T	Tidal volume	20 to 1400 mL (10 mL resolution)
V _T (SIMV/PS)	Tidal volume	20 to 1100 mL (10 mL resolution)
f	Breathing frequency	4 to 60 bpm (1 bpm resolution) (4 to 60 1/min (1/min resolution))
Ti:TE	Inspiration/expiration ratio	4 : 1 to 1 : 4
Ti:P:Ti	Inspiration pause	0 % to 50 % (1 % resolution)
PEEP	End-expiratory pressure	0 to 20 cmH ₂ O (1 cmH ₂ O resolution) (0 to 20 hPa (1 hPa resolution))
PINSP	Inspiratory pressure	5 to 65 cmH ₂ O (1 cmH ₂ O resolution) (5 to 65 hPa (1 hPa resolution)) (setting must be at least 5 cmH ₂ O (5 hPa) above PEEP)

Insp Flow	Inspiratory flow	10 to 75 L/min (1 L/min resolution) in Pressure Control mode 10 to 85 L/min (1 L/min resolution) in PS and SIMV/PS modes
ΔP_{PS} (Pressure Support)	Support Pressure	3 to 20 cmH ₂ O (1 cmH ₂ O resolution) (3 to 20 hPa (1 hPa resolution))
ΔP_{PS} (SIMV/PS)	Support Pressure	3 to 20 cmH ₂ O, OFF (1 cmH ₂ O resolution) (3 to 20 hPa, OFF (1 hPa resolution))
Freq Min	Apnea Ventilation minimum frequency	3 to 20 bpm (1 bpm resolution) and "OFF" (3 to 20 1/min (1/min resolution) and "OFF")
Trigger	Trigger Level	2 to 15 L/min (1 L/min resolution)
T _{INSP}	SIMV Inspiratory Time	0.3 to 4.0 sec

Pressure Support Ventilation Mode

The Pressure Support Ventilation mode has been verified under the following range of simulated patient conditions:

Endotracheal Tube Size:	4.5 mm to 8 mm
Patient Lung Compliance:	10 mL/cmH ₂ O to 100 mL/cmH ₂ O (10 mL/hPa to 100 mL/hPa)
Unassisted Patient Tidal Volume:	50 mL to 1000 mL
Patient Breath Rate (bpm) (1/min):	10 to 35

Delivery Accuracy

P _{MAX}	Pressure limiting	±5 cmH ₂ O (±5 hPa) of setting
V _T	Tidal volume	±5 % of setting or 20 mL, whichever is greater (discharged to atmosphere, no compliance compensation)
f	Breathing frequency	±1 bpm (1/min) of setting
T _I :T _E	Inspiration/expiration ratio	±5 % of setting
T _I P:T _I	Inspiration pause	±25 % of setting
PEEP	End-expiratory pressure	±2 cmH ₂ O (±2 hPa) or ±20 % of setting, whichever is greater

High Pressure Safety Relief Valve

75 ±5 cmH₂O (75 ±5 hPa)

**Negative Pressure Safety Relief Valve
(Ambient Air Inlet Valve)**

−7.5 to −9 cmH₂O (−7.5 to −9 hPa)

Minimal Limit Pressure

−8.5 cmH₂O (−8.5 hPa)

System Compliance Measurement

0.2 to 6.0 mL/cmH₂O (0.2 to 6.0 mL/hPa)

±0.2 mL/cmH₂O (±0.2 mL/hPa) or ±10 % of actual compliance, whichever is greater

Anesthesia Gas Supply Module

Fresh-Gas Flow Indicators:

O₂, N₂O, AIR: Range and accuracy: 0.0 to 12.0 L/min ± 10 % of reading or 0.12 L/min into an ambient atmosphere of 14.7 psi (1.013 kPa x 100) at 68 °F (20 °C).
Resolution: 0.1 L/min

Fresh-Gas Flow Stability:

O₂ and N₂O : ± 10 % of setting with pipeline pressures between 45 to 65 psi (3.1 to 4.5 kPa x 100)
AIR: ± 10 % of setting with pipeline pressures between 50 to 55 psi (3.4 to 3.8 kPa x 100)
Air flow rate will vary proportionally with supply pressures outside 50 to 55 psi (3.4 to 3.8 kPa x 100).

Total Fresh-Gas Flowmeter:

Range and accuracy: 0 to 10 L/min ± 10 % of full scale at STP, calibrated with 50 % O₂/ 50 % N₂O gas mixture
0 to 10 L/min ± 15 % of full scale at STP for all other gas mixtures
Resolution: 0.5 L/min from 0.5 to 2 L/min
1.0 L/min from 2 to 10 L/min

O₂ Flush (bypass): at 55 psi (3.8 kPa x 100): max. 50 L/min
at 50 psi (3.4 kPa x 100): min. 35 L/min

Common Gas Outlet Pressure Limit: 13 psi (0.9 kPa x 100), maximum

Auxiliary Oxygen Flowmeter (optional)

Connection Staged connector for use with different hose diameters
Fresh-gas flow 0 to 10 L/min
Accuracy ± 5 % of full scale
Resolution 0.5 L/min

Anesthetic Agent Vaporizer Interface

Dräger Vapor quick-change plug-in system for up to three anesthetic agent vaporizers.

The connections are automatically closed and sealed when the vaporizer is removed.

Dräger Halothane Vapor
 Dräger Enflurane Vapor
 Dräger Isoflurane Vapor
 Dräger Sevoflurane Vapor
 Datex-Ohmeda Devapor/D-Tec for Desflurane
 Dräger D-Vapor

See specific Instructions for Use manuals for technical data of anesthetic agent vaporizers.

Monitoring and Measurement Display		Range	Resolution	Accuracy	Condition
PAW	Airway pressure (numeric)	–20 to 99 cmH2O (hPa)	1 cmH2O (hPa)	±4 % ¹⁾	
	Airway pressure (wave)	0 to 99 cmH2O (hPa)			
	Pressure gauge (mechanical)	–20 to 80 cmH2O (hPa)	2 cmH2O (hPa)	1.28 cmH2O (hPa)	
VE	Expiratory minute volume	0 to 99.9 L/min	0.1 L/min	±15 % ²⁾	with reference to 68 °F (20 °C), ambient pressure and saturated gas
	Expiratory tidal volume	0 to 1500 mL	1 mL	±15 % ²⁾ or ±20 mL, whichever is greater	
Note: For end-tidal values of Desflurane exceeding 12 %, tidal and minute volume accuracies may exceed ±15 %.					
f	Breathing frequency	2 to 99 bpm (1/min)	±1 bpm (1/min)	±1 bpm (1/min)	
FiO2	O2 measurement in the main gas flow	10 to 100 vol.%	1 vol.%	±(2.5 vol.% + 2.5 % of the measured value) as per ISO 21647	with reference to ambient pressure during calibration

1) Max. ±4 % of the measured value or ±2 cmH₂O (±2 hPa), whichever is greater.

2) At standard test conditions per IEC 60601-2-13.

O₂ Cell Measurement Performance

Response time	Less than 16 seconds	measured values are not pressure compensated
Warm-up time	after 5 min	error ≤ 3 % of measured value
Drift Sensitivity		± 1 % of measured value / 8h
Cross Sensitivity		≤ 1 vol.% O ₂ at 70 vol.% N ₂ O and 5 vol.% CO ₂ with 4 vol.% Halothane or with 5 vol.% Enflurane or with 15 vol.% Desflurane or with 5 vol.% Isoflurane or with 10 vol.% Sevoflurane
Effect of humidity / sensitivity	max. ± 0.02 % of measured value / % relative humidity	
Service life of O ₂ sensor cell	>12 months at 77 °F (25 °C), 50 % relative humidity, 50 % O ₂ gas mixture (or >5000 hours at 100 Vol.% O ₂)	

Breathing System

Volume with reusable absorber

incl. filled absorber, excl. hoses 1.7 L + bag

Volume with Drägersorb CLIC adapter

incl. filled absorber, excl. hoses 1.7 L + bag

excl. absorber, excl. hoses 0.8 L + bag

Volume absorber

reusable absorber, filled 1.5 L

Clic absorber
(Drägersorb CLIC Free) 1.2 L

Compliance

(in automatic ventilation modes, e.g. Volume Control, excluding patient hoses)

with reusable absorber 0.35mL/cmH₂O (0.35 mL/hPa)

with Drägersorb CLIC adapter,
including absorber 0.35mL/cmH₂O (0.35 mL/hPa)

with Drägersorb CLIC adapter,
excluding absorber 0.35mL/cmH₂O (0.35 mL/hPa)


Resistance

(Reusable absorber or CLIC absorber with or without flexible bag arm, normal operation, filled with Drägersorb 800 +)

	Inspiratory	Expiratory
As per ISO 8835-2, dry, max. ±6 hPa (±6 cmH ₂ O), with hose set for adults M30146	−4.7 cmH ₂ O (−4.7 hPa)	4.4 cmH ₂ O (4.4 hPa)
As per ISO 8835-2, dry, sole bre- athing system without patient hoses	−3.7 cmH ₂ O (−3.7 hPa)	3.7 cmH ₂ O (3.7 hPa)

Typical leak

<50 mL/min



Classification

II b

Conforming to Directive 93/42/EEC Appendix IX

UMDNS Code

10-134

Universal Medical Device Nomenclature System

Control Inputs Ranges

APL-Valve	MAN mode	5 to 70 cmH ₂ O (hPa)
	SPONT mode	1.5 cmH ₂ O (hPa)
Accuracy from 5 to 15 L/min		±15 % of set value or ±3 cmH ₂ O (mbar) (greater applies)
Pressure drop at 30 L/min		3.4 cmH ₂ O (hPa) (wet and dry)

Low Oxygen Supply Pressure Alarm

Alarm limit	Warning signal when the pressure drops below 20 ±4 psi (1.4 ±0.3 kPa x 100)
Alarm signal	High priority alarm (Warning)
LED indicator	The red LED indicator in the O ₂ area of the gas flow control interface will flash until the O ₂ supply is restored.

S-ORC (Sensitive Oxygen Ratio Controller)

S-ORC is a control element which guarantees a minimum O₂ concentration in the fresh-gas flow. As from a flow rate of approx. 300 mL/min, the N₂O concentration in the fresh gas can be freely set between 0 and 75 %.

During O ₂ shortage	S-ORC limits the N ₂ O concentration in the fresh gas, so that the O ₂ concentration does not drop below 23 vol.%.
N ₂ O metering valve open and O ₂ metering valve closed or O ₂ flow less than 0.2 L/min	S-ORC prevents N ₂ O flow
During N ₂ O failure	O ₂ may still be administered. No alarm.


Serial Interface

Type:	RS-232-C
Connector:	9-pin Sub D Female, Shield on housing
	Pin 2 TXD
	Pin 3 RXD
	Pin 5 GND
	Galvanic Isolation 500 V
Baud Rates:	1200, 2400, 4800, 9600, 19200, 38400
Parity:	Odd, Even, None
Data Bits:	7 or 8
Start Bits:	1
Stop Bits:	1 or 2
Protocol:	Vitalink, MEDIBUS

Diagram

Gas flow diagram

Compact Breathing System



100

Appendix – Daily and Pre-use Checkout Form

Before operating the Fabius GS *premium*, the following checkout verification form must be completed to ensure that the machine is ready for use. Do not insert any additional components into or modify the anesthesia workstation after the checkout procedure is started.

This is a recommended procedure. Follow your institution's policies for specific checkout procedures.

CAUTION

If any check cannot be carried out satisfactorily, the machine must not be used.

Call DrägerService or your local authorized service organization.

NOTE:

Throughout this section, cmH₂O = mbar = hPa

This page intentionally left blank

Please note that this Daily Pre-use check list takes into consideration all possible configurations of the Fabius GS *premium*. The clinician need only use those areas that apply to their specific Fabius GS *premium* configuration.

All checks must be carried out daily before equipment is used. The person who carries out the checks must be fully conversant with the Instructions for Use. Checks marked with a **P** must be carried out before each patient use. These pages should be removed and copied to establish a daily record of machines checks.

Mark each function when checks have been satisfactorily completed.

Fabius GS *premium*
Serial Number

Pre-conditions

- ☐ Inspection intervals for machine and accessories are current
- P** ☐ Machine fully assembled and connected
- ☐ Monitors (O₂, P, V, CO₂, anesthetic agent) (when present) switched on and functioning, self test carried out satisfactorily
- ☐ System diagnostics for Fabius GS *premium* carried out
- P** ☐ Sampling line for gas monitoring (when present) connected to Luer Lock on the Y-piece, correct anesthetic agent selected
- P** ☐ D-Vapor (when being used) powered on

Checking Reserve Power

- P** ☐ Verify that battery is fully charged. (If the battery does not show full a charge, the battery operation time is not guaranteed to be 45 minutes.)

Checking the Medical Gas Connections

- ☐ Visually inspect all gas supplies from the medical gas pipeline system and cylinders to make sure that they connect properly and fit securely.
- ☐ Verify that all medical gas pipeline supplies are within acceptable pressure ranges.
- ☐ Open reserve gas cylinders (when present).
- ☐ O₂ pressure more than 1000 psi (70 kPa x 100).
- ☐ N₂O pressure greater than 600 psi (43 kPa x 100) if present.
- ☐ AIR pressure greater than 1000 psi (70 kPa x 100) if present.
- ☐ Close reserve gas cylinders.

O₂ Flush Function

- ☐ Press O₂ flush: A strong flow of gas should be emitted from the patient connection.
- ☐ Release O₂ flush button: flow of gas from patient connection stops.

Checking the Flow Control/Metering System

- ☐ Activate ManSpont mode.
- ☐ Fully open the O₂ metering valve. O₂ flow of at least 10 L/min present.
- ☐ Close air metering valve. Fully open the N₂O metering valve. N₂O flow of at least 10 L/min present.
- ☐ Verify that the float ball of the total fresh-gas flow meter moves up.
- ☐ Turn off the O₂ supply. Remove the O₂ connector and close the O₂ cylinder valve. The O₂ Low Supply Pressure Alarm LED is blinking. N₂O does not flow.
- ☐ Verify that the float ball of the total fresh-gas flow meter shows 0 L/min
- ☐ Restore the O₂ supply: N₂O flow is present.
- ☐ Set O₂ metering valve to 1.5 L/min. N₂O flow = 3 L/min to 5 L/min

- ☐ Close the O₂ metering valve:
No N₂O flow.

Checking the Flow Control/Metering System

- ☐ Open the AIR flow control valve. Air flow of at least 10 L/min present.
- ☐ Close all metering valves.

Sensor Calibration

- ☐ Remove O₂ sensor housing from inspiratory valve dome
- ☐ Calibrate O₂ sensor
- ☐ Calibrate flow sensor
- ☐ Replace O₂ sensor

Checking the Gas Type

- ☐ Set the O₂ metering valve to approx. 3 L/min.
- ☐ Verify an O₂ concentration indication of approx. 100 vol.%.
- ☐ Close O₂ metering valve.

Vapor 19.n, Vapor 2000 (Tec 5)

- P** ☐ Fastening; Latched down firmly and set vertically
- P** ☐ Handwheel; In zero position and engaged
- P** ☐ Filling level between min. and max.
- P** ☐ Interlock; Locking function OK (when present)
- P** ☐ Key-indexed filling system; Sealing key or pin inserted and closed tight. (when present)
Filler opening locked shut.
- P** ☐ Quik Fil or Funnel filling system; Locking screw tight (when present)

D-Vapor (when present)

- P** ☐ Fastening; Latched down firmly and set vertically
- P** ☐ Handwheel; In zero position and engaged
- P** ☐ Filling level between min. and max.
- P** ☐ Operational light lit

Selectatec

- P** ☐ Fastening; Latched down firmly and set vertically
- P** ☐ Handwheel; In zero position and engaged
- P** ☐ Filling level between min. and max.
- P** ☐ Interlock; Locking function OK (when present)

Checking the Condition of CO₂ Absorbent

- P** ☐ Color change is no more than half the canister of CO₂ absorbent.

Testing the Paw sensor

Switch to standby mode and press the function key for the leak test.

- ☐ Close all fresh-gas valves.
- ☐ Fit the Y-piece to the fixture on the bag holder.
- ☐ Seal the sample line connection, if necessary.
- ☐ Remove the hose of the connection socket for the breathing pressure sensor on the rear.
- ☐ Check the pressure display on the leak test start screen: "0" to ± 2 is OK. If the deviation is greater, contact DrägerService.
- ☐ Reconnect the hose of the connection socket for the breathing pressure sensor on the rear.

Leak Testing the Fresh-Gas Circuit

Test once without the vaporizer and once with each Dräger Vapor with the handwheel set to zero. (Selectatec vaporizers must be turned on in order to perform the leak test, and then turned off again at the completion of the test.)

- ☐ Go to Standby and press the Leak Test soft key. Follow the instructions on the screen.

If the system leaks (i.e. pressure drops):

- Check that all plug-in, push-fit and screw connectors fit tightly.
- Replace any missing or damaged seals. If necessary, call DrägerService or your local authorized service organization.

Inspiratory and Expiratory Valves (Compact Breathing Systems)

- Press the ManSpont key and confirm.
 - Set APL-valve to MAN position and adjust to 30 cmH₂O (hPa).
 - Press O₂ flush.
- P** ☐ Breathing bag for manual ventilation fills
- P** ☐ Inspiratory and expiratory valve discs move freely when the breathing bag is squeezed and released.

Pressure-Limiting (APL) Valve (Compact Breathing System)

- P** ☐ Set APL valve to MAN and 30 cmH₂O (hPa).
Set fresh-gas flow to 20 L/min.
- P** ☐ Press the ManSpont key and confirm.
- P** ☐ When the pressure waveform on the Breathing Pressure Trace window stabilizes (e.g., a flat line), flip the APL-valve to SPONT to release pressure.
- P** ☐ Peak pressure display on monitor reads 24 to 36 cmH₂O (hPa).

Checking Ventilator Operation

- P** ☐ Connect a breathing bag to the Y-piece to act as test lung.
- P** ☐ Press the Pressure Control key and confirm.
- P** ☐ Check that ventilation measurements are displayed.
- P** ☐ Check that the ventilator piston is cycling.
- P** ☐ Monitor the operation of the inspiratory and expiratory valve discs.
- P** ☐ Check that the breathing bag (test lung) on the Y-piece is ventilating.
- P** ☐ Press the Standby key and confirm.

Monitors

The alarm function can be tested by setting alarm limits to levels that are certain to trigger an alarm.

Check the alarm limit settings. The monitor alarm limits are automatically set to a default configuration when the ON/OFF switch is turned on. Check these settings and adjust them if necessary. Alarm limits can be adjusted at the beginning of or during a procedure. Also, make sure that any external monitors (if any) are connected properly.

Test the alarm functions for all monitors. Simulate alarm conditions and check for appropriate alarm signals.

- ☐ Test the O₂ monitor and alarm module.
- ☐ Test the volume monitor and alarm module.
- ☐ Test the pressure monitor and alarm module.
- ☐ Press the Standby key and confirm.

Additional Monitors (when present)

- ☐ Check the CO₂ monitor and alarm module.
- ☐ Check the anesthetic agent monitor and alarm module.

Anesthetic Gas Scavenging System

- P ☐ Check the hose connections.
- P ☐ Adjust the flow regulator to place the float between the "Minimum" and "Maximum" marks.

☐ Close all flow control valves on the machine, with Y-piece occluded.
- P ☐ Change to Standby screen.

– Select the APL valve for Spontaneous Breathing:
Rotate the APL valve knob fully counter-clockwise to spont mark.
Press and hold the O2 flush button and verify that airway pressure is less than 10 cmH2O (hPa) with Y-piece occluded.

– Release the O2 Flush button and verify that airway pressure is equal or greater 0 cmH2O (hPa).

Manual Ventilation Bag for Emergency Ventilation

- ☐ Check that the bag is functioning correctly by pumping manually.
- ☐ When the bag is squeezed, air must audibly and tangibly flow out of the mask cone; when the bag is released, it must rapidly recover its original shape.
- ☐ Block off the mask connector (cone) with the ball of your thumb: you should only be able to squeeze the bag a little.

P ☐ Before Connecting to Patient

- Verify that
- all vaporizers are off (the handwheels are set to zero),

– the APL Valve is set as desired,

– all flowmeters indicate 0,

– the patient suction is level adequate, and

– the breathing system is ready to use (the bag is in place and all hoses are connected properly).

If any check can not be carried out satisfactorily, the machine must not be used.

Daily Checkout Signature

Name

Date

Pre-use Checkout Signature

Name

Date

Pre-use Checkout Signature

Name

Date

Pre-use Checkout Signature

Name

Date

Pre-use Checkout Signature

Name

Date

Pre-use Checkout Signature

Name

Date

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature**Name****Date**

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Pre-use Checkout Signature

Name	
Date	

Index

A

Abbreviations	28
Absorbent	80
AC Power	66
Acoustic Confirmation	136
AGS Scavenger System	54
Alarm Indication	104
Alarm Limits	37, 107, 129
Alarm Log	125, 144
Alarm Tone Sequence	136
Alarm Volume	130
Alarms	104
Anesthetic Gas Scavenging System	54
APL Bypass	62
APL valve	24, 81, 83, 163, 168
Apnea	82
Auto Set	139
Auxiliary Oxygen Flowmeter	23

B

Bacterial Filters	59
Battery	44, 146
Breathing bags	48
Breathing Hoses	58, 59
Breathing Pressure Monitoring	115
Breathing System	168

C

Calibrate Flow Sensor	120
Calibrate O2 Sensor	121, 140
Calibrating	109
Causes of leaks	124
Cleaning	157
CLIC adapter	45, 80
CO2 absorbent	78
COM 1	25
COM 2	25
Communication Ports	25
Compact Breathing System	17, 46, 161
Compliance Test	123
Configuration	117
Configuration during Operation	138
Configuration Functions in Standby Mode	118
Configuration in Standby	133
Contents	5
Control Panel	32
COSY Shielding	63

Cylinder pressures	52
--------------------	----

D

Date Format	136
Date Set	135
Desflurane compensation	142
Diagram	204
Display Background	137
Disposal	181, 184
Dräger Auto Exclusion 2	21
Drägersorb	78

E

Electromagnetic Compatibility (EMC)	189
Endotracheal Tubes	59
Equipotential Bonding	66

F

Factory Defaults	131
Fault-Cause-Remedy	150
Flexible Bag Arm	48
Flow Sensor	47, 62, 162
Fresh Gas Control	39
Fresh Gas Flow	41, 74
Function Keys	34

G

Gas Cylinders	50
Gas System Color Coding	42
Gauge	61

I

Inflammable solvents	11
Intended Use	14
Interlock 2 System	20

L

Leak/Compliance Test	122
LED	42
Low Flow	78

M

Main Screen	104
Maintenance	175
Manual Ventilation	82
Manual/Spontaneous	81
MEDIBUS	14

N

Nitrogen Wash-Out	78
-------------------------	----

O

O2 Flush	77
O2 Monitoring Disabled	112
O2 Sensor	60
ON/OFFswitch	70
Operation	73
Operation Concept	31
Oxygen Monitoring	108
Oxygen Sensor	109

P

Passive Scavenger	56
PEEP/PMAX Hoses	62
Pin-Index	50
Pipeline Supply	49
Power Failure Backup	146
Power-Up	74
Powering-Up	70
Pre-use Checkout Form	205
Pressure Sensor	61

R

Respiratory Volume Monitoring	113
Rotary Knob	34

S

S-ORC	74
Scavenger System	171
Screen Display	33
Selectatec	21
Self-test	70
Sensitive Oxygen Ratio Controller	74
Silencing Alarms	106
Sleep Mode	119
Soda Lime	59
Soft Keys	35
SpiroLife	165

SpiroLife flow sensor	165
Spirolog flow sensor	165
Spontaneous Breathing	81
Standby	36
Suction System	57, 164
Symbols	29
System Test	119

T

Technical Data	185
Time Format	135
Time Set	134

U

UMDNS Code	202
------------------	-----

V

Vapor	76
Vaporizers	20
Ventilation	81
Ventilation Parameters	38
Ventilator	163, 170
Ventilator Fail	148
Vitalink	14
Volume Alarms	139
Volume Monitoring	114

W

Waste Gas Outlet	48
Waveform Display	137

Y

Y-pieces	59
----------------	----

This page intentionally left blank

These Instructions for Use only apply to
Fabius GS premium SW 3.n
with the Serial-Nr.:

If no Serial No. has been filled in by Dräger,
these Instructions for Use are provided for
general information only and are not
intended for use with any specific machine
or device.

This document is provided for customer
information only, and will not be updated or
exchanged without customer request.



Directive 93/42/EEC
Concerning Medical Devices

Manufactured by

Dräger Medical GmbH



Moislinger Allee 53 – 55
D-23542 Lübeck
Germany



+49 451 8 82-0

FAX +49 451 8 82-20 80



<http://www.draeger.com>

Distributed in US by

Draeger Medical, Inc.



3135 Quarry Road
Telford, PA 18969-1042
U.S.A.



(215) 721-5400

(800) 4DRAGER (800 437-2437)

FAX (215) 723-5935

90 38 906 – GA 5330.650 enUS

© Dräger Medical GmbH

Edition: 7 – 2015-01

(Edition: 1 – 2006-03)

Dräger reserves the right to make modifi-
cations to the equipment without prior
notice.



As of 2015-08:
Dräger Medical GmbH
changes to
Drägerwerk AG & Co. KGaA